

Kobelco EXCAVATOR PARTS----Monitor

CMPB-A001	CMPB-A002	CMPB-A003	CMPB-A004
			
Kobelco Gauge, Monitor Cluster	Kobelco Gauge, Monitor Cluster	Kobelco Gauge, Monitor Cluster	Kobelco Gauge, Monitor Cluster
SK100 SK100L SK120 SK120-V SK120-5 SK200-5 SK200LC-V SK100-2 SK200-2	SK330-6 SK200-6 SK210-6 SK250-6 SK200 mark V1	SK330-6E SK200-6E SK210-6E SK250-6E	SK200-6E SK230-6ESK250-6E
YN59S00002F2 YN59S00002F3 YN59S00002F4 YN59S00002F5	YN59E00004F1/2/3 YN59E00004F4/5/6 YN59E00002F1/2/3/4/5/6/7/8	YN59S00012F1 YN59S00012F2	YV59S00003F2 YV59S00009F1
CMPK-B005	CMPB-A006	CMPB-A007	CMPB-A008
			
Kobelco Gauge, Monitor Cluster	Monitor LCD, LCD, Kobelco LCD	Monitor LCD, LCD, Kobelco LCD	Monitor LCD, LCD, Kobelco LCD
SK200-8 SK210-8 SK230-8 SK250-8 SK350-8	SK-3 SK200-3 SK100-3 SK120-3	SK-2 SK-5 SK200-2 SK200-5 SK100-2 SK120-5	SK-6 SK-6E SK200-6 SK200-6E
YN59S00021F1 YN59S00021F2 YN59S00021F3			
CMPB-B009			
Monitor LCD, LCD, Kobelco LCD			
SK-2 SK-5 SK200-2 SK200-5 SK100-2 SK120-5			

Kobelco EXCAVATOR PARTS---Controller

CMPB-B001	CMPB-B002	CMPB-B003	CMPB-B004
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
SK100-3 SK120-3 SK300-3 SK220-3 SK60-3	SK100-5 SK120-5 SK200-5 SK220-5	SK120-5 SK200-5 SK120LC-5	SK120-2 SK120-5
2480U371F2 2480U371F1 2480U371F3 2480U371F4	YN22E00013F4 YN22E00013F3 YN22E00013F2 YN22E00013F1	LP22E00004F2 LP22E00004F5	YW22E00007F1 YW22E00007F2 YW22E00007F3 YW22E00007F4
CMPB-B005	CMPB-B006	CMPB-B007	CMPB-B008
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
SK120-5 SK200-5 SK120LC-5	SK120-5 SK120-3	SK120-5 SK200-2 SK200-5 SK200-3	SK120-5 SK200-5 SK200-3
LP22E00006F1 LP22E00006F2 LP22E00006F3 LP22E00006F4	LP22E00020F1	YN22E00015F3 YN22E00015F1 YN22E00015F2	YN22E00020F1 YN22E00020F2 YN22E00020F3
CMPB-B009	CMPB-B010	CMPB-B011	CMPB-B012
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
sk200-3 SK120-3	sk200-3 sk220-3	SK200-6E SK210-6E SK230-6E SK300-6E	SK200-6 SK210-6 SK230-6 SK300-6
YN22E00041F2 YN22E00041F1 YN22E00041F3	YN22E00358F1=2480U332F6 2480U332F1/2/3/4/5/6/7/8/9 2480U332F10/11/12/13/14	YN22E00149F3 YN22E00149F2 YN22E00149F1	YN22E00037F6 YN22E00037F2 YN22E00037F3 YN22E00037F4 YN22E00037F5 YN22E00037F1
CMPB-B013	CMPB-B014	CMPB-B015	CMPB-B016
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
SK200-6 SK210-6 SK230-6 SK300-6	SK250-6	SK200-6 SK210-6 SK210LC-6 SK230-6 SK300-6 SK480-6	SK330-6 SK320-6
lq22e00031F1	LS22E00029F3 LS22E00029F2 LS22E00029F1	YN22E00069F1 YN22E00069F2 YN22E00069F3/4 YN22E00069F5/6	LC22E00009F6 LC22E00009F5 LC22E00009F4/3 LC22E00009F2/1
CMPB-B017	CMPB-B018	CMPB-B019	CMPB-B020
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
SK-6 SK250-6	SK330-6	SK-6	SK230-6E
LQ22E00024F1 LQ22E00024F2 LQ22E00024F3 LQ22E00024F4 LQ22E00024F5/6 LQ22E00024F7/8	LC22E00044F1 LC22E00044F2 LC22E00044F3 LC22E00044F4 LC22E00044F5 LC22E00044F6/7	YN22E00087F3 YN22E00087F2 YN22E00087F1	YN22E00123F1 YN22E00123F2 YN22E00123F3 YN22E00123F4 YN22E00123F5

EMAIL: service@sinocmp.com sales@excavator-parts.com sales@cmpparts.com
 Whatsapp: +8615328181468 +8613242057399 +8613434784596
 Skype: Mou Mark(CMP) sinocmp-daisy



Kobelco EXCAVATOR PARTS---Controller

CMPB-B021	CMPB-B022	CMPB-B023	CMPB-B024
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	
sk290-6e sk200-6e	sk210-6e sk200-6e	SK230-6E	SK250-6E
LB22E00007F1	YN22E00146F2=YN22E00146F1	YM22E00007F1	LQ22E00065F1
CMPB-B025	CMPB-B026	CMPB-B027	CMPB-B028
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
SK200-8 SK210-8 SK250-8 SK330-8 SK350lc-8 sk250lc-8 sk260lc-8 sk210lc-8	SK200-8 SK250-8 SK330-8	SK200-8 SK210-8 SK240-8 SK250-8 SK290-8 SK330-8 SK450-8	SK200-8 SK210-8 SK240-8 SK250-8 SK290-8 SK330-8
YT22E00036F4	YN22E00354F3 YN22E00354F3 YN22E00354F5 YN22E00354F6 YN22E00354F7	YN22E00214F1	YN22E00193F1 YN22E00193F2 YN22E00193F3 YN22E00193F4 YN22E00193F5 YN22E00193F6
CMPB-B029	CMPB-B030	CMPB-B031	CMPB-B032
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	
SK200-8 SK210-8 SK240-8 SK250-8 SK290-8 SK330-8	SK200-8 SK210-8 SK240-8 SK250-8 SK290-8 SK330-8	SK330-6E SK350-6E SK450-6	
YN22E00234F1 YN22E00234F2 YN22E00234F3 YN22E00234F4 YN22E00234F5 YN22E00234F6	LQ22E00102F1 LQ22E00102F2 LQ22E00102F3	ME441124	YN02P00042F1 VH89661E0010 275800-4211
CMPB-B033	CMPB-B034	CMPB-B035	CMPB-B036
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Kobelco Air Conditioner Control Panel	Kobelco Air Conditioner Control Panel
SK200-6 SK210-6 SK210LC-6 SK230-6 SK300-6 SK480-6	SK330-6E	SK200-6 SK200-6E SK330-6E	SK200-8 SK230-8 SK250-8 SK230-8 SK210-8 SK350-8
LQ22E00018F8 LQ22E00018F7 LQ22E00018F6 LQ22E00018F5 LQ22E00018F4 LQ22E00018F3/2	LC22E00048F1 LC22E00048F2	YN20M01299P1 51589-17530	51586-17813 YN20M01468P2 YN20M01468P1
CMPB-B037			
Module			
SS2B003			

EMAIL: service@sinoamp.com sales@excavator-parts.com sales@cmpparts.com
 Whatsapp: +8615328181468 +8613242057399 +8613434784596
 Skype: Mou Mark(CMP) sinoamp-daisy







Kobelco EXCAVATOR PARTS----Solenoid valve

CMPB-C001	CMPB-C002	CMPB-C003	CMPB-C004
			
Solenoid valve	Solenoid valve	Solenoid valve	Solenoid valve with screw
2436U1453S11	2436U1453S8	2436U1453F1 2436U1453F2 2436U1453F3	White plug 609-74211200
CMPB-C005	CMPB-C006	CMPB-C007	CMPB-C008
			
Pump solenod valve	Pump solenod valve	Pump solenod valve	Pump solenod valve
SK200-6E SK210-6E SK250-6E SK290-6E	SK200-8 SK210-8 SK250-8 SK260-8 SK350-8	SK200-6E SK230-6E SK330LC-6E SK190-6E SK160-6E	SK200-6E SK230-6E SK330LC-6E SK190-6E SK160-6E
YN35V00041F1 KDRDE5K-31/30C50-102	YN35V00048F1 YN35V00048F2 YN35V00048F3 KDRDE5K-31/30C50-122	YB35V00003F1 KDRDE5K-31/3040-111	YB35V00005F1 KDRDE5K-31/30C50-107
CMPB-C009	CMPB-C010	CMPB-C011	CMPB-C012
			
Pump solenod valve	Pump solenod valve	Pump solenod valve	Pump solenod valve
SK200-6E SK230-6E SK330LC-6E SK190-6E SK160-6E	SK200-6 SK290-6 SK250-6 SK330-6	sk120-5 sk200-5 sk200-6 sk200-6e	SK-6/SK-6E SK200-3/ SK230-6/SK320-6 sk210-6E SK330-6E SK200-5
YB35V00006F1 KWE5K-31/G24YA50	YN35V00018F1 YN35V00018F2 KDRDE5K-31/30C40-111	YN35V00019F1 KDRDE5K-31/30C40-101	YN35V00020F1 KWE5K-31/G24DA40 KWE5K-31/G24D40
CMPB-C013	CMPB-C014	CMPB-C015	CMPB-C016
			
Pump solenod valve	Pump solenod valve	Pump solenod valve	Pump solenod valve
sk200-3 sk200-5 sk200-6 sk200-6e	SK200-8 SK210-8 SK250-8 SK260-8 SK350-8	SK200-8 SK210-8 SK250-8 SK260-8 SK350-8	SK200-8 SK210-8 SK250-8 SK260-8 SK350-8
YN35V00021F1 KWE5K-31/G24YA40 KWE5K-31/G24Y40	YN35V00049F1 KDRDE5K-31/40C50-213	YN35V00050F1 KWE5K-31/G24DB50	YN35V00052F1 YN35V00052F2 KDRDE5K-31/30C50-123
CMPB-C017	CMPB-C018	CMPB-C019	CMPB-C020
			
Pump solenod valve	Pump solenod valve	Pump solenod valve	Pump solenod valve
SK200-6E/SK210-6E/SK230-6E/SL250-6E	SK200-2 SK200-3 SK200-5	SK200-2 SK200-3 SK200-5 sk120-5	SK200-2 SK200-3 SK200-5 sk120-5
YT35V00013F1 YT35V00013F1 KWE5K-31/G24DA50	YN35V00004F1 KDRDE5K-20/30C12A-111	YN35V00004F2 KDRDE5K-20/30C12A-101	YN35V00005F1 KWE5K-20/G24D12A

EMAIL: service@sinocmp.com sales@excavator-parts.com sales@cmpparts.com
 Whatsapp: +8615328181468 +8613242057399 +8613434784596
 Skype: Mou Mark(CMP) sinocmp-daisy



Kobelco EXCAVATOR PARTS----Monitor

CMPB-C021	CMPB-C022	CMPB-C023	CMPB-C024
			
<p>Pump solenoid valve</p>	<p>Pump solenoid valve</p>	<p>solenoid valve Assy</p>	<p>SK-6 Solenoid valve plug</p>
<p>SK200-2 SK200-3 SK200-5 sk120-5</p>	<p>SK200-8 SK210-8 SK250-8 SK260-8 SK350-8</p>		
<p>YN35V00005F2 KWE5K-20/G24Y12A</p>	<p>YN35V00051F1 KWE5K-31/G24YB50</p>		
CMPB-C025			
			
<p>SK-8 solenoid plug</p>			

Kobelco EXCAVATOR PARTS----sensor

CMPB-D001	CMPB-D002	CMPB-D003	CMPB-D004
kobelco Excavator Revolution Sensor,RMP sensor	kobelco Excavator Revolution Sensor,RMP sensor	Kobelco pressure sensor (3MPa)	Pressure: 3MPa
sk200-3 sk200-5 sk120-3 sk120-5	SK200-6 SK200-6E Engine: 6D34T	SK200-5	
VAMC845235 MC845235	VAMC849577 MC849577	YN52S00028P1=LC52S00013F1	YN52S00003P1
CMPB-D005	CMPB-D006	CMPB-D007	CMPB-D008
Pressure sensor: 3MPa	Pressure: 3MPa	Pressure: 3MPa	Pressure: 3MPa
sk170-8 sk210-8 sk200-8 sk250-8 SK350-8	SK190-6E SK200-6E SK160-6E SK210-6E SK250-6E SK290-6E	sk200	
LC52S00019P1	YX52S00010P1	LC52S00001P1 LC52S00001P3 LC52S00001P2	LS52S00019P2 LS52S00019P3
CMPB-D009	CMPB-D010	CMPB-D011	CMPB-D012
Pressure sensor: 3MPa	Pressure sensor: 3MPa	Pressure sensor: 3MPa	High Pressure sensor 49MPa
	SK100 SK120-5 SK200-5		
LC52S00013F1 YT13EO1082P1	YW52S00002P1 LC52S00013F1	YW52S00002P2 YW52S00002P3	LS52S00027P1 LS52S00027P2 LS52S00027P3 LS52S00027P4
CMPB-D013	CMPB-D014	CMPB-D015	CMPB-D016
High Pressure sensor 50MPa	High Pressure sensor 50MPa	High Pressure sensor 50MPa	High Pressure sensor 50MPa
SK-6E	SK-6E		SK-8 SK170-8 SK200-8 sk210-8 sk350-8
LC52S00012P1	YY52S00033F1 YY52S00033F2 YY52S00033F3	LC52S00013F2	YN52S00048P1
CMPB-D017	CMPB-D018	CMPB-D019	CMPB-D020
High Pressure sensor 50MPa	High Pressure sensor 50MPa	Pressure: 4.9MPa Type: Negative pressure sensor	Pressure: 4.9MPa Type: Negative pressure sensor
sk120-5 sk200-5 sk200-6 sk200-6e sk200-8		SK200-6 SK250-6 SK290-6 SK330-6	SK480-6E SK210-6 SK330-6E
LS52S00015P1	LC52S00027P1	YN52S00016P1	YN52S00016P2 YN52S00016P3

EMAIL: service@sinocmp.com sales@excavator-parts.com sales@cmpparts.com
 Whatsapp: +8615328181468 +8613242057399 +8613434784596
 Skype: Mou Mark(CMP) sinocmp-daisy



Kobelco EXCAVATOR PARTS----sensor

CMPB-D021	CMPB-D022	CMPB-D023	CMPB-D024
			
Pressure: 4.9MPa Type: Negative pressure sensor	Pressure sensor	Pressure sensor	Pressure sensor: 3MPa
SK200-6 SK210-6 SK230-6 SK250-6	SK135SRLC SK200SR SK250	SK135SRLC SK200SR SK250	SK200-3 SK200-5 SK200-6
LC52S00016P2 LC52S00016P3	LC52S00002P1 LC52S00002P2 LC52S00002P3 =LS52S00015P1	YY5200033F2 YY5200033F1	LC52S00019P1
CMPB-D025	CMPB-D026	CMPB-D027	CMPB-D028
			
LOW pressure switch	Kobelco Water Temperature Alarm Sensor (Double Pins)	kobelco Excavator Water Temperature Sensor Single Pin	kobelco Excavator Water Temperature Sensor
SK330LC-6E	SK200-6 6D31 6D34	SK200-6 6D31 6D34	sk200-6e
YX52S00012F1 YX52S00012F2 YX52S00012F3 YX52S00012F4 YX52S00012F1=YX52S00005P1	ME049265	ME039860	YT52S00001P1
CMPB-D029	CMPB-D030	CMPB-D031	CMPB-D032
			
Oil Pressure Sensor	Ignition key	Ignition key	Convert plug
SK200-3 SK200-5 SK200-6 SK200-6E	SK-1/2/3/5/6/6E	SK-8	sk-6 to sk-6E, SK200-6 to SK200-6E
VAME840219 ME840219	YN50S00026F1 YN50S00026F2 YN50S00026F3 YN50S00029F1 YN50S00002P1		
CMPB-D033			
			
Convert plug			
SK200-8 to sk200-6			

Kobelco EXCAVATOR PARTS----relief valve, main valve

CMPB-E001	CMPB-E002	CMPB-E003	CMPB-E004
			
verglow relief valve	overglow relief valve	Kobelco Main Relief Valve	Kobelco Main Relief Valve
SK120-5 SK200-5 SK200-6 SK230-6 SK200-6E SK230-6E SK250-6E	SK290-6E SK330-6E SK350-6E SK140LC-8	SK250-5 SK250-6	SK220-3 SK300-6 SK330LC-6 SK115DZ SK300-IV K912LC
YN22V00002F1 YN22V00002F2 YN22V00002F3	YN22V00002F4 YN22V00002F5 YN22V00002F6	2436R683F4 2436R683F3	2436R837F2 2436R837F1 2436R837F4 2436R837F3
CMPK-E005	CMPB-E006	CMPB-E007	
			
Kobelco Main Relief Valve	Kobelco Main Relief Valve	Kobelco Main Relief Valve	
SK200-6E SK230-6E SK250-6E SK330-6E SK250-8 SK460-8 SK480LC-8 R210-5	SK100-5 SK110-5	SK200-1 SK200-4	
YN22V00001F8 YN22V00001F3 YN22V00001F4 YN22V00001F5 YN22V00001F1/2 YN22V00001F6/7			

Kobelco EXCAVATOR PARTS----Wire harness

CMPB-F001	CMPB-F002	CMPB-F003	CMPB-F004
			
Hydraulic pump wire harness	Kobelco Wiring harness	Kobelco wiring harness	Kobelco engine wire harness
SK450-8 SK250-8	SK200-3	engine 6D34 Mitsubishi SK210-6E	sk210-8 sk200-8
		YN16E01021P1	LQ16E01015P1 YN13E01444P2 LQ16E00010F1
CMPK-F005	CMPB-F006	CMPB-F007	
			
Kobelco engine wire harness	Kobelco engine wire harness	Kobelco engine wire harness	
SK200-3	sk200-6E	sk200-6	

Kobelco EXCAVATOR PARTS----Others

CMPB-G001	CMPB-G002	CMPB-G003	CMPB-G004
Kobelco Excavator Console, Control Plate Switch Assy Panel	Kobelco Excavator Console, Control Plate Switch Assy Panel	Kobelco Relay Assembly , Kobelco Fuse Assy	kobelco Locking Key, Kobelco Excavator Lock Switch
SK200-3 SK100-3	sk120-5 sk200-5	SK200-8 SK230-8 SK250-8 SK230-8 SK210-8 SK350-8	SK60-5 SK200-6 SK230-6
YN50E00001P5 YN17M00008F5 YN50E00001F1	YN17M00008F5 YN50E00001F3	YY24E00008F2 YN24E00016F2 YN24E00016F1 YN24E00019F1 YN73E01024P2 YN73E01023P2	YN50S01001P2
CMPB-G005	CMPB-G006	CMPB-G007	CMPB-G008
kobelco Locking Key, Kobelco Excavator Lock Switch	battery relay assembly	Battery Relay	Relay
SK60-5			
YN50801001P2	2479R1470F1	77279310 2479R1470F1 YT24S00001F1	VAME077148 ME077148 R8T30173
CMPB-G009	CMPB-G010	CMPB-G011	CMPB-G012
Relay	Relay	water pump	Turbocharger
		6D16T	SK200-6E SK210-6E
YN24S00008F1	YN24S00012P1		49185-01030
CMPB-G013	CMPB-G014	CMPB-G015	CMPB-G016
kobelco regulator	Pilot pump	Hour Meter	electric motor clutch
	SK100-3-5 SK200-5 SK200-3		SK200-2 SK-2
LC10C01002F2			
CMPB-G017	CMPB-G018	CMPB-G019	
throttle knob	throttle knob	Injector	
sk120-6 sk200-6	SK200-6 SK200-6E	sk200-8 sk210-8	
YN52S00032P1	YN52S00009P1	97095000-6353	

EMAIL: service@sinocmp.com sales@excavator-parts.com sales@cmpparts.com
 Whatsapp: +8615328181468 +8613242057399 +8613434784596
 Skype: Mou Mark(CMP) sinocmp-daisy

