

00011# Fault code Fault description
00022# Cylinder injector solenoid valve
00033# Cylinder injector solenoid valve
00044# Cylinder injector solenoid valve
00055# Cylinder injector solenoid valve
00066# Cylinder injector solenoid valve
0041 Cylinder injector solenoid valve
0042 8V DC power supply
0091 The injector actuates the control valve
0094 Throttle position signal
0100 Fuel pressure country sensor
0110 Engine oil pressure sensor
0164 Engine coolant temperature sensor
0168 Actuating pressure of the injector
0172 System voltage
0175 Inlet manifold air temperature
0190 Engine oil temperature sensor
0253 Engine speed sensor
0261 Personality module
0262 Engine timing check
0268 Dc power supply for 5V sensor
0273 Check the programmable parameter
0274 Turbocharger outlet pressure sensor
0286 Atmospheric pressure sensor
0342 Machine oil lamp
0617 Secondary engine speed sensor
1627 Air intake heating relay

0091 Fuel pump relay

0096 Throttle position signal

0110 Fuel oil level sensor

0167 Engine coolant temperature sensor

0168 Generator

0190 Key gate voltage

0248 Speed sensor

0286 CAT data line

0374 Engine oil pressure low signal

0376 Rotary brake solenoid valve

0581 Walking alert

0586 Power shift proportional pressure reducing valve

0587 Engine speed disc switch

0590 Feedback signal of regulator transmission device

0598 Engine controller

0600 Traveling speed solenoid valve

1161 Hydraulic oil temperature sensor

1162 Pump

1524 Pump

1525 Negative flow control proportional solenoid valve

1590 Straight line travel solenoid valve

FMI Negative flow control proportional solenoid valve

FMI Fault code

0 Fault description

1 The figures are correct, but above the normal range

2 The data is correct, but below normal range

3 Data is unstable, intermittent or incorrect

- 4 Voltage higher than normal or suddenly
- 5 Voltage below normal or suddenly low
- 6 Current below normal or open
- 7 Current higher than normal or short circuit
- 8 The machine system did not react correctly
- 9 Abnormal frequency, pulse or period
- 10 Exception update
- 11 Rate of abnormal change
- 12 Failure mode cannot confirm
- 13 Bad device or component
- 14-31 Out of calibration range