

1100-2 engine speed is abnormal

11101-3 High pressure sensor of engine speed control knob is abnormal

11101-4 Low pressure sensor of engine speed control knob is abnormal

11200-3 Abnormal high pressure of oil pressure sensor of pump 1

11200-4 Abnormal low pressure of oil pressure sensor of pump 1

11202-3 Pump 2 oil pressure sensor high pressure abnormal

11202-4 Pump 2 oil transmission pressure sensor low pressure abnormal

11206-3 Pump 1 pump control pressure sensor high pressure abnormal

11206-4 Pump 1 pump control pressure sensor for low and high pressure anomalies

11208-3 Pump 2 pump control pressure sensor high pressure abnormal

11208-4 Pump 2 pump control pressure sensor for low and high pressure abnormality

11301-3 Abnormal high pressure of rotary pilot pressure sensor

11301-4 Abnormal low pressure of rotary pilot pressure sensor

11302-3 boom lift pilot pressure sensor high pressure abnormal

11302-4 boom lift pilot pressure sensor low pressure abnormal

11303-3 Bucket rod recovery pilot pressure sensor high pressure abnormal

11303-4 Bucket rod recovery pilot pressure sensor low pressure abnormal

11304-3 Abnormal high pressure of the walking pilot pressure sensor

11304-4 Abnormal low pressure of walking pilot pressure sensor

Abnormal high pressure of the pilot pressure sensor of the front-end working device

Abnormal low pressure of the pilot pressure sensor of the front-end working device

Abnormal current feedback in pump 2 maximum flow limit control solenoid valve

11400-3 Pump 2 maximum flow limit control solenoid valve feedback high current anomaly

11400-4 Pump 2 maximum flow limit control solenoid valve feedback low current abnormal

Abnormal current feedback of torque-controlled solenoid valve

11401-3 Torque controlled solenoid valve feedback high current abnormal

11401-4 Torque control solenoid valve feedback low current abnormal

11402-2 Solenoid Valve Unit (SF) (Excavation Regeneration) Current Feedback Abnormal

11402-3 Solenoid Valve Unit (SF) (Mining Regeneration) Feedback High Current Abnormal

11402-4 Solenoid Valve Unit (SF) (Excavation Regeneration) Feedback Low Current Abnormal

11403-2 Solenoid valve unit (SC) (bucket rod regeneration) abnormal current feedback

11403-3 Solenoid valve unit (SC) (bucket rod regeneration) feedback high current abnormal

11403-4 Solenoid valve unit (SC) (bucket rod regeneration) feedback low current abnormal

11404-2 Solenoid Valve Unit (SG) (Overflow Pressure Control) Abnormal current feedback

11404-3 Solenoid valve unit (SG) (overflow pressure control) feedback high current abnormal

11404-4 Solenoid Valve Unit (SG) (Overflow Pressure Control) Feedback Abnormal Low Current

11405-2 Solenoid Valve Unit (SI) (Quick selection of walking motor) Abnormal current feedback

11405-3 Solenoid Valve Unit (SI) (Walking Motor Quick Selection) Feedback High Current Abnormal

11405-4 Solenoid Valve Unit (SI) (Walking Motor Quick Selection) Abnormal low current feedback

11410-2 Pump 1 maximum flow limit control solenoid valve (optional) abnormal current feedback

11410-3 Pump 1 maximum flow limit control solenoid valve (optional) feedback high current anomaly

11410-4 Pump 1 maximum flow limit control solenoid valve (optional) feedback low current abnormal

11910-2 Actual engine speed received from ECM

11918-2 Operational mode received from the monitor

11911-2 Safety signals received from ECM

11920-2 Fuel flow received from ECM

11914-2 Radiator coolant temperature received from ECM

11901-3 hydraulic oil temperature sensor high pressure

11901-4 Hydraulic oil temperature sensor low pressure

11905-3 Bottom pressure sensor of boom high pressure (optional) abnormal

11905-4 Abnormal low pressure of the bottom pressure sensor of the boom (optional)