



**SINOCMP**

*CMP Technology Co., Limited*

# PRODUCT CATALOG

**KOMATSU**

**HITACHI**

**KOBELCO**

**VOLVO**

**CATERPILLAR**

**HYUNDAI**  
CONSTRUCTION EQUIPMENT

**Sumitomo**

**DOOSAN**

  
**DAEWOO**

**LIUGONG**

**ZOOMLION**

**XCMG**  
徐工集团

 **SANY**



Worldwide professional  
excavator parts  
supplier

# Contents

Komatsu Excavator Parts.....	Page 1~ Page 17
Hitachi Excavator Parts.....	Page18~ Page 40
Volvo Excavator Parts.....	Page 41~ Page 50
Caterpillar Excavator Parts.....	Page 51~ Page 64
Kobelco Excavator Parts.....	Page 65~ Page 74
Daweoo/Doosan Excavator Parts.....	Page 75~ Page 83
Sumitomo Excavator Parts... ..	Page 84~ Page 91
Hyundai Excavator Parts.....	Page 92~ Page100
Kato Excavator Parts. ....	Page 101~ Page 107
Other Excavator Parts.....	Page 108~ Page 111
Tool.....	Page 111~ Page 112

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp/wechat:+8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinocmp-daisy

## KOMATSU EXCAVATOR PARTS---Controller




CMPK-A001	CMPK-A002	CMPK-A003	CMPK-A004
Komatsu Controller, Control Panel, ECU, Control Box Assy	Komatsu Controller, Control Panel, ECU, Control Box Assy	Komatsu Controller Governor, Control Panel, ECU	Komatsu Controller Governor, Control Panel, ECU
PC200-5 PC200LC-5 PC220-5 PC220LC-5 PC100-5 PC120-5 PC150-5 PC300-5	PC100-5 PC120-5 PC200-5 PC220-5 PC300-5 PC400-5	PC100-6 PC120-6 PC130-6 PC200-6 PC220-6 PC230-6 PC250-6	PC210-6 PC240-6 PC210LC-6
7824-12-2000/1 7824-10-2000/1/3 7824-14-2000/1	7824-32-1100 7824-30-1100 7824-34-1100	7834-21-6000/1/2/3 7834-21-3000	7834-21-5000/1/2/3 7834-21-3000
CMPK-A005	CMPK-A006	CMPK-A007	CMPK-A008
Komatsu Controller, Control Panel, ECU, Control Box Assy	Komatsu Controller Governor, Control Panel, ECU	Komatsu Controller Governor, Control Panel, ECU	Komatsu Controller Pump, Control Panel, ECU
PC300-6 PC340NLC-6 PC350-6 PC400-6 PC450-6	PC200-6 PC210-6 PC220-6 PC230-6	PC200-6 PC210-6 PC220-6 PC250-6 PC290-6	PC100-6 PC120-6 PC130-6 PC200-6 PC220-6 PC230-6
7834-20-5000/1/3/4/5/6 7834-20-4000/1 7834-20-2001	7834-21-4000/1/2/3/4	7834-21-7000/1/2/3	7834-10-2000 7834-10-2001 7834-10-2002 7834-10-2003 7834-10-9001
CMPK-A009	CMPK-A010	CMPK-A011	CMPK-A012
Komatsu Controller, Control Panel, ECU, Control Box Assy	Komatsu Controller, TVC controller	Komatsu Controller, TVC controller	Komatsu Controller, Control Panel, ECU, Control Box Assy
PC100-6 PC120-6 PC130-6 PC200-6 PC220-6 PC230-6	PC100-6 PC120-6 PC130-6 PC200-6 PC220-6 PC230-6	PC300-6 PC340NLC-6 PC350-6 PC400-6 PC450-6	PC130-7
7834-30-2000 7834-30-3000	7834-27-2002 7834-27-2000 7834-27-2001	7834-27-3003 7834-27-3001 7834-27-3002	7835-26-5000 7835-26-5001
CMPK-A013	CMPK-A014	CMPK-A015	CMPK-A016
Komatsu Controller, Control Panel, ECU, Control Box Assy	Komatsu Controller, GP controller, Control Panel, ECU, Control Box Assy	Komatsu Controller, Control Panel, ECU, Control Box Assy	Komatsu CONTROLLER ASSEMBLY, engine controller, ECM
PC200-7 PC210-7 PC220-7 PC230-7 PC270-7 PC290-7	PC300-7 PC340-7 PC350-7	PC400-7 PC450-7 PC600-7	PC400-8 PC450-8
7835-26-1001/2/3/4/5/6/7/8/9	7835-26-2003 7835-26-2002 7835-26-2000 7835-26-2001	7835-28-3000 7835-28-3002 7835-28-3001 7835-26-4002(PC228US-3)	600-461-1100
CMPK-A017	CMPK-A018	CMPK-A019	CMPK-A020
Komatsu CONTROLLER ASSEMBLY, engine controller, ECM number 4921776	Komatsu controller, Pump controller, ECU, control panel	Komatsu controller, Pump controller, ECU, control panel	Komatsu controller
PC200-8 PC220-8 pc270-8 PC210-8 PC240-8 PC290-8	PC200-8 PC210-8 PC220-8 PC230-8 PC240-8 PC270-8 PC290-8	PC200-8M0 PC220-8M0 PC300-8M0 PC300-8 PC350-8 PC400-8 PC400-8	PC300-8 PC350-8 PC400-8 PC400-8
600-467-1100 600-467-1200 600-468-1200 600-475-1102 600-475-1100 600-462-1202	7835-46-1000/1/2/3/4/5/6/8/9 7835-46-1010 7835-46-3005	7835-46-3000 7835-46-3001 7835-45-4000/1/2 7835-45-5002	7826-23-3012 7826-23-3011

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinocmp-daisy

## KOMATSU EXCAVATOR PARTS----Controller

CMPK-A021	CMPK-A022	CMPK-A023
		
<p>Komatsu control panel assembly, Air conditioner Panel, A/C panel ( NEW type)</p>	<p>Komatsu control panel assembly, Air conditioner Panel, A/C panel ( OLD type)</p>	<p>Komatsu controller, Air conditioner Panel, A/C panel</p>
<p>PC200-7</p>		
<p>20Y-979-7630 20Y-979-6141 Denso 146570-0160 237040-0021</p>	<p>208-979-7630 (Denso 146570-0160 237040-0021)</p>	<p>20Y-810-1231 17A-979-3180</p>



## KOMATSU EXCAVATOR PARTS---Monitor and LCD

CMPK-B001	CMPK-B002	CMPK-B003	CMPK-B004
			
Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel
PC20MR-2 PC27MR-2 PC30MR-2 PC35MR-2 PC40MR-2 PC50MR-2	PC20MR-2 PC27MR-2 PC30MR-2 PC35MR-2 PC40MR-2 PC50MR-2	PC200-5 PC220-5 PC300-5 PC400-5 PC410-5	PC100-5 PC120-5
22M-06-23200 22M-06-23101	22M-06-23101 22M-06-R3101 22M-06-23100 22M-06-32100	7824-72-2001 7824-72-4100 7824-72-7100 7824-72-3000 7824-70-2001 7824-72-3100	7824-70-4000
CMPK-B005	CMPK-B006	CMPK-B007	CMPK-B008
			
Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel
PC100-5 PC120-5 PC150-5	PC200-5 PC210-5 PC220-5 PC240-5 PC300-5 PC350-5 PC400-5	PC60-6	PC100-6 PC120-6 PC130-6 PC130-6
7824-70-3100/1/2/3 7824-70-2100/1/2	7824-72-7000 7824-72-6100 7824-72-4000	7824-83-3000	7834-70-4002 7834-70-4000 7834-70-4100
CMPK-B009	CMPK-B010	CMPK-B011	CMPK-B012
			
Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel
PC100-6 PC120-6 PC130-6 PC130-6 PC200-6 PC220-6 PC210-6 PC230-6	PC200-6 PC220-6 PC210-6 PC230-6	PC200-6 PC200LC-6	PC300LC-6 PC300-6 PC400LC-6 PC200-6 PC210-6 PC220-6 PC450-6
7834-70-6001/2/3 7834-76-2001/2/3	7834-72-4000/1/2	7834-70-5000/2 7834-70-5100/2 7834-71-7001/2	7834-76-3001 7834-76-3002
CMPK-B013	CMPK-B014	CMPK-B015	CMPK-B016
			
Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel
PC100-6 PC100L-6 PC120-6 PC120LC-6 PC130-6	PC200-6 PC210-6 PC220-6 PC220LC-6 PC230-6 PC250-6 PC300-6 PC400-6	PC210-6 PC240-6 PC290-6 PC340-6 PC380-6 PC450-6	PC100-6 PC120-6 PC130-6 PC200-6 PC220-6 PC130LC-6 PC200LC-6
7834-77-2000/1/2	7834-77-3000/1/2	7834-77-7000 7834-77-7001	7834-71-6000 7834-71-6001 7834-71-6002 7834-71-6101
CMPK-B017	CMPK-B018	CMPK-B019	CMPK-B020
			
Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel
PC120-6Z PC200-6Z PC200LC-6Z PC220-6Z PC220LC-6Z PC400-6Z	PC220-6Z PC400-6Z PC220LC-6Z PC200LC-6Z	PC60-7 PC70-7 PC75uu-2	PC60-7 PC70-7
7834-75-2000 7834-75-2001 7834-75-2002 7834-75-2003	7834-75-2100 7834-75-2101 7834-75-2102 7834-75-2103	7834-73-2000 7834-73-2001 7834-73-2002	7834-73-2100 7834-73-2101 7834-73-2102

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinocmp-daisy

## KOMATSU EXCAVATOR PARTS---Monitor and LCD







CMPK-B021	CMPK-B022	CMPK-B023	CMPK-B024
			
Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel
PC200-7 PC220-7 PC228US-3 PC270-7 PC300-7 PC400-7 PC450-7 PC160-7	PC160LC-7E0 PC180NLC-7E0 PC228US-3E0	PC130-7	PC128US-2 PC138US-2
7835-10-2002 7835-10-2003 7835-10-2004 7835-10-2005	7835-16-5002 7835-16-5001	7835-10-5000	7835-10-3002 7835-10-3001
CMPK-B025	CMPK-B026	CMPK-B027	CMPK-B028
			
Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel
PC400-7 PC450-7	PC200-7 PC210LC-7 PC220-7 PC300-7 PC340NLC-7 PC290NLC-7 PC240-7	PC300-7E0 PC350-7E0 PC400-7E0 PC450-7E0	PC400-7 PC450-7
7835-12-2003/7835-12-4000 7835-12-2001	7835-12-1001 7835-12-1002 7835-12-1003 7835-12-1004 7835-12-1005 7835-12-1006 7835-12-1007 7835-12-1008 7835-12-1009	7835-16-1003 7835-16-1002	7835-12-2008
CMPK-B029	CMPK-B030	CMPK-B031	CMPK-B032
			
Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel
PC360-7	PC200-7 PC210LC-7 PC220-7 PC300-7 PC340NLC-7 PC290NLC-7 PC240-7	PC200-8 PC270-8 PC220-8 PC210-8 PC240-8	PC200-8 PC270-8 PC220-8 PC210-8 PC240-8
7835-12-3007 7835-12-3000 7835-12-3006 7835-12-3005	7835-12-1010 7835-12-1011 7835-12-1012 7835-12-1013 7835-12-1013	7835-31-1000 7835-31-1001 7835-31-1010 7835-31-1003 7835-31-1011 7835-31-1005 7835-31-1006 7835-31-1007 7835-	7835-30-1002 7835-30-1006 7835-30-1007 7835-30-1008 7835-30-1009 7835-31-1212
CMPK-B033	CMPK-B034	CMPK-B035	CMPK-B036
			
Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel
PC300-8 PC350-8 PC400-8 PC450-8	PC300-8 PC350-8 PC400-8 PC450-8	PC138US-8	PC138US-8 PC130-8
7835-31-5001 7835-31-5002 7835-31-5003 7835-31-5004 7835-31-5005 7835-31-5006	7835-31-5006 7835-31-5007 7835-31-5008 7835-31-5009	7835-31-3008 7835-31-3002 7835-31-3016	7835-31-3009 7835-31-3006
CMPK-B037	CMPK-B038	CMPK-B039	CMPK-B040
			
Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Komatsu Monitor Assy, Monitor Panel, Instrument Panel
PC130-8 PC160-8 PC138US-8	PC600-8 PC600LC-8	PC200-8	PC200-8M0
7835-31-3013 7835-31-3017	7835-16-2003	7835-31-9001	7835-34-1202 7835-34-1203

EMAIL: [service@sinoomp.com](mailto:service@sinoomp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinoomp-daisy

## KOMATSU EXCAVATOR PARTS----Monitor and LCD

CMPK-B041	CMPK-B042	CMPK-B043	CMPK-B043
			
<p>Komatsu LCD, Monitor LCD, LCD</p>	<p>Komatsu LCD, Monitor LCD, LCD</p>	<p>Komatsu LCD, Monitor LCD, LCD</p>	<p>Komatsu LCD, Monitor LCD, LCD</p>
<p>PC100-5 PC120-5 PC200-5 PC210-5 PC220-5 PC300-5 PC400-5 PC-5</p>	<p>PC200-6 PC100-6 PC120-6 PC130-6 PC210-6 PC220-6 PC300-6 6D95</p>	<p>PC200-6 PC210-6 PC220-6 PC300-6 PC350-6 PC290-6 PC400-6 PC450-6 6D95</p>	<p>PC-7 PC200-7 PC130-7 PC210-7 PC300-7 PC400-7</p>
CMPK-B044	CMPK-B045		
			
<p>komatsu monitor LCD Module, LCD modele</p>	<p>Komatsu Monitor and controller Plug, connectors</p>		
<p>PC-8 PC130-8 PC200-8 PC200-8 PC300-8 PC400-8</p>	<p>PC-5 PC-6 PC-7 PC-8</p>		

## KOMATSU EXCAVATOR PARTS----Motor

CMPK-C001	CMPK-C002	CMPK-C003	CMPK-C004
			
Komatsu governor motor, motor assy, throttle motor	Komatsu governor motor, motor assy, throttle motor	Komatsu governor motor, motor assy, throttle motor	Komatsu governor motor, motor assy, throttle motor
PC228US-1 PC228US-2 PC60-7 PC138US-2 PC70-7	PC120-6 PC120LC-6 PC200-6 PC200LC-6 PC220-6 PC220LC-6 PC250-6	PC130-7 PC200-7 PC200LC-7 PC220-7 PC220LC-7 PC270-7 PC200/220-7	PC120-5 PC150-5 PC200-5 PC200LC-5 PC220-5 PC220LC-5 PC120/200/220-5
22U-06-11790 22U-06-11113 201-43-72120 22B-43-11142 22B-43-11141 22B-43-	7834-40-2000/1/2/3/4/5/6/7 7834-40-3000 7834-40-3002	7834-41-2000/1/2/3 7834-41-3000/1/2/3	7824-30-1600 7824-31-3600
CMPK-C005	CMPK-C006	CMPK-C007	CMPK-C008
			
Komatsu governor motor, motor assy, throttle motor	blower motor	blower motor	blower motor
PC228US-1 PC228US-2 PC60-7 PC138US-2 PC70-7	PC-5 PC200-5 PC100-5	PC-5 PC200-5 PC100-5	PC-6 6D95
22U-06-11790 22U-06-11113 201-43-72120 22B-43-11142 22B-43-11141 22B-43-			
CMPK-C009	CMPK-C010	CMPK-C011	CMPK-C012
			
blower motor	blower motor	blower motor	blower motor
PC-6 6D102	PC300-7	PC200-7 PC-7	PC-8 PC200-8 PC220-8 PC300-8

## KOMATSU EXCAVATOR PARTS----wire harness

CMPK-D001	CMPK-D002	CMPK-D003	CMPK-D004
			
Komatsu wire harness harness	Komatsu wiring harness, external outer wire harness	Komatsu wiring harness, internal cabin wire harness	Komatsu main wiring harness
PC300-8 PC350-8	PC200-7 PC210-6 PC220-6 PC230-6 PC250-6	PC200-7 PC210-6 PC220-6 PC230-6 PC250-6	PC200-8 PC220-8 PC270-8 PC240-8
207-06-77411 207-06-76511 207-06-76511	20Y-06-22713 20Y-06-22712 20Y-06-22711	20Y-06-25120	20Y-06-42411 20Y-06-42721 20Y-06-42720 20Y-06-48313 20Y-06-48312 20Y-06-
CMPK-D005	CMPK-D006	CMPK-D007	CMPK-D008
			
Komatsu main wiring harness	Komatsu engine wiring harness	Komatsu injector wire harness	Komatsu wire harness(Monitor)
PC200-8 PC220-8 PC270-8 PC240-8	PC200-8 PC220-8 PC270-8 PC240-8	PC200-8 PC220-8 PC270-8 PC240-8	PC200-7 PC210-7 PC220-7 PC270-7
20y-06-41113 20Y-06-41112 20Y-06-41110	6754-81-9440 6754-81-9310	6754-81-9450 7861-93-1780 6754-81-9210	20Y-06-31120
CMPK-D009	CMPK-D010	CMPK-D011	CMPK-D012
			
Komatsu wiring harness	Komatsu wire harness(Monitor)	Komatsu Excavator external wiring harness(old type)	Komatsu Excavator external wiring harness(old type)
PC300-8 PC130-8 PC350-8 pc400-8 pc450-8	PC-7 PC200-7 PC130-7 PC210-7 PC220-7 PC300-7 PC350-7 PC400-7 PC450-7	PC200-7 PC220-7 PC210-7 PC230-7 PC240-7 PC270-7	PC200-7 PC220-7 PC210-7 PC230-7
20Y-06-41151	208-53-12920	20Y-06-31611	20Y-06-31612 20Y-06-316123 20Y-06-31614
CMPK-D013	CMPK-D014	CMPK-D015	CMPK-D016
			
Komatsu cabine wire harness(old type)	Komatsu Excavator external wiring harness (new type)	Komatsu cabine wire harness (new type)	Komatsu engine harness
PC200-7 PC220-7 PC230-7 PC210-7 PC270-7	PC200-7 PC220-7 PC270-7	PC200-7 PC220-7 PC230-7 PC210-7 PC270-7	PC300-7 PC350-7
20Y-06-31110	20Y-06-31614 20Y-06-31613	20Y-06-71510 20Y-06-71511 20Y-06-71512	6743-81-8310
CMPK-D017	CMPK-D018	CMPK-D019	CMPK-D020
			
Komatsu engine harness	Komatsu Excavator external wiring harness	Komatsu wiring harness	Komatsu internal cabin wiring harness
PC400-7E0 PC450-7E0 PC400-8 PC450-8	PC300-7 PC350-7	PC300-7 PC350-7 PC400-7 PC450-7	PC300-7 PC350-7
6251-81-9810	207-06-71341 207-06-71110 207-06-71114 207-06-71112	207-06-71141	207-06-71562

EMAIL: [service@sinoamp.com](mailto:service@sinoamp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596


















Skype: Mou Mark(CMP) sinoamp-daisy








## KOMATSU EXCAVATOR PARTS----wire harness

CMPK-D021	CMPK-D022	CMPK-D023	CMPK-D024
			
<p>Komatsu Excavator external wiring harness</p>	<p>Komatsu cabin internal wiring harness</p>	<p>Komatsu engine injector harness</p>	<p>Komatsu engine sensor harness</p>
<p>PC400-7 PC450-7</p>	<p>PC400-7 PC450-7</p>	<p>PC400-7 PC450-7</p>	
<p>208-06-71113</p>	<p>208-06-71511 208-06-71510</p>	<p>6156-81-9211</p>	<p>6156-81-9320</p>
CMPK-D025			
			
<p>Komatsu harness</p>			
<p>PC20-8 PC78US-8 PC88US-8 PC130-8 PC138US-8</p>			
<p>6271-81-8240</p>			

## KOMATSU EXCAVATOR PARTS----ENGINE parts (Injector, pump, rebuild kits)

<p>CMPK-E101</p>  <p>Komatsu injector</p> <p>PC200-8 PC220-8 PC228US-3 PC270-8 4D107E-1 6D107E-1</p> <p>6754-11-3010 6754-11-3011</p>	<p>CMPK-E102</p>  <p>Komatsu injector</p> <p>PC300-8 PC350-8 6D114E-3</p> <p>6745-11-3100 6745-11-3102 6745-12-3100</p>	<p>CMPK-E103</p>  <p>Komatsu injector</p> <p>PC300-7 PC350-7 PC360-7 6D114E-2</p> <p>6743-11-3320</p>	<p>CMPK-E104</p>  <p>Komatsu injector</p> <p>PC450-8 6D125E-6</p> <p>6252-11-3100 095000-6070</p>
<p>CMPK-E104</p>  <p>Komatsu injector</p> <p>PC400-7 PC450-7 6D125E-3</p> <p>6156-11-3300 095000-1211</p>	<p>CMPK-E105</p>  <p>Komatsu injector</p> <p>PC300-8</p> <p>6745-11-3102 Bosch 0445120236</p>	<p>CMPK-E106</p>  <p>Komatsu injector</p> <p>Komatsu S4D95L S6D95L PC100-5 PC200-6</p> <p>6202-13-3110</p>	
<p>CMPK-E201</p>  <p>Fuel pump 6D125</p> <p>PC400-7 PC450-7</p> <p>6156-71-1112 6156-71-1111 094000-0383</p>	<p>CMPK-E202</p>  <p>ISF3.8 Cummins</p> <p>ISF3.8</p> <p>4450201220 4988595 5256607</p>	<p>CMPK-E203</p>  <p>Fuel pump 6D107 Bosch</p> <p>PC-8 PC200-8 PC220-8</p> <p>7854-71-1320 0445020150</p>	
<p>CMPK-E301</p>  <p>Overhaul gasket</p> <p>6D95 4D95 6D102 6D107 6D125</p>	<p>CMPK-E302</p>  <p>Piston</p> <p>6D95 4D95 6D102 6D107 6D125</p>	<p>CMPK-E303</p>  <p>Piston Ring</p> <p>6D95 4D95 6D102 6D107 6D125</p>	<p>CMPK-E304</p>  <p>bearing</p> <p>6D95 4D95 6D102 6D107 6D125</p>
<p>CMPK-E305</p>  <p>main bearing</p> <p>6D95 4D95 6D102 6D107 6D125</p>	<p>CMPK-E305</p>  <p>Cylinder head gasket</p> <p>6D95 4D95 6D102 6D107 6D125</p>	<p>CMPK-E307</p>  <p>liner kit</p> <p>6D95 4D95 6D102 6D107 6D125</p>	

## KOMATSU EXCAVATOR PARTS---Alternator, Turbo charger

CMPK-E401		CMPK-E402			
					
Alternator	Alternator				
PC200-3	PC200-5 PC200-6 PC200-7 PC200-8				
RKD25A04					
CMPK-E501		CMPK-E502		CMPK-E503	
					
Turbocharger	6D102 Turbocharger	6D125E Turbocharger			
Komatsu 6D102 turbocharger	PC-7 PC200-7 PC220-7 PC230-7 PC270-7	PC400-8 PC450-8 PC550-8			
6735-81-8031	3598036 6738-81-8192 6738-81-8190 6738-81-8191	6506-21-5020			

## KOMATSU EXCAVATOR PARTS----sensor, switch, relay

CMPK-F001	CMPK-F002	CMPK-F003	CMPK-F004
			
Pressure sensor/ Switch	Pressure sensor/ Switch	Pressure sensor/ Switch	Pressure sensor
PC200-5 PC210-5 PC220-5	PC-8 PC200-8 PC300-8 PC55MR-3	PC-8 PC300-8 PC350-8 PC400-8 PC450-8	6D114 6D107
20Y-06-15190	20Y-06-21710	206-06-61130	6754-72-1210
CMPK-F005	CMPK-F006	CMPK-F007	CMPK-F008
			
OIL PRESSURE SENSOR	OIL PRESSURE SENSOR	OIL PRESSURE SENSOR	sensor
4D102 PC60-7 PC200-6 PC210-6 PC228US-1	PC100-5 PC120-5 PC130-5 PC200-5 PC220-5	PC100-6 PC200-6 PC300-6	
6732-81-3140 08073-10505	7861-92-1540	7861-92-1610	7861-93-1651
CMPK-F009	CMPK-F010	CMPK-F011	CMPK-F012
			
Pressure sensor	Pressure sensor	Sensor	Oil temperature sensor
PC130-8 PC138US-8 PC200-8 PC300-8 PC400-8	PC130-8 PC138US-8 PC200-8 PC300-8 PC400-8	PC400-7 PC450-7 PW160-7	
7861-93-1812	7861-93-1840	208-06-71130	7861-92-3320
CMPK-F013	CMPK-F014	CMPK-F015	CMPK-F016
			
Water temp sensor			Revolution speed sensor
PC200-6 6D102 4D102			
7861-92-3380	7861-93-3320	7861-93-3380	7861-92-2310
CMPK-F017	CMPK-F018	CMPK-F019	CMPK-F020
			
Revolution speed sensor	Revolution speed sensor	Ignition key	Ignition key
		PC200-1 PC200-2 PC300-3 PC200-5	PC200-7
7861-92-2340	7861-93-2310	08086-10000	08086-20000

### KOMATSU EXCAVATOR PARTS----sensor, switch, relay

CMPK-F021	CMPK-F022	CMPK-F023	CMPK-F024
			
sensor	throttle motor fitting sensor throttle positioner		
PC750-7	PC200-7	PC450-7	PC450-7
6217-81-9240	7861-93-4131	ND029600-0570	ND29600-0580
CMPK-F025	CMPK-F026	CMPK-F027	CMPK-F028
			
PC400-8PC450-8	Relay	motor starter relay	starter relay
WA200-6 PC300-8	Relay	PC200-6	PC-7
ND949979-1300	569-06-61960	600-815-2170	600-815-2170 600-815-8940 600-815-8941
CMPK-F029	CMPK-F030	CMPK-F031	CMPK-F032
			
relay	EXCAVATOR BATTERY RELAY 24V	24V battery Relay	Relay
PC200-8 PC200LC-8 PC220-8 PC220LC-8			
600-815-8941	08088-10000	08088-30000	SD1599-0010010



### KOMATSU EXCAVATOR PARTS----valve(solenoid valve)

CMPK-G101	CMPK-G102	CMPK-G103	CMPK-G104
			
Solenoid Valve 20Y-60-32120	Solenoid Coil 20Y-60-11713	Solenoid Coil PC120-6 PC60-7 203-60-62171 203-60-62161	Solenoid Coil PC200-6 6D102
CMPK-G105	CMPK-G106	CMPK-G107	CMPK-G108
			
Solenoid Valve wa320-3 714-10-16951	Solenoid Valve PC200-5 20Y-60-11672	Solenoid Valve PC200-6 6D95 20Y-60-22121 20Y-60-22123	solenoid valve PC 60-5 pc120-5 pc 60-6-old 203-60-56180
CMPK-G109	CMPK-G110	CMPK-G111	CMPK-G112
			
solenoid valve coil 203-60-56560	Komatsu Rotary Solenoid Valve PC200-6 6D102 206-60-51130	solenoid valve 561-15-47210 17A-15-17271	600-815-9260
CMPK-G113	CMPK-G114	CMPK-G115	CMPK-G116
			
PC200-6 6D102 4D102 702-21-07010	komatsu solenoid valve 702-21-07311	solenoid PC350-8 702-21-07610	Main Pump Pilot Valve PC200-7 PC220-7 PC350-7 702-21-57400 702-21-55901 702-21-57500
CMPK-G117	CMPK-G118	CMPK-G119	CMPK-G120
			
pc200-3 pc200-5 pc200-6 6D95 708-2H-25240 18272 708-23-18272	Vlave Assy 708-2L-06410	Solenoid Valve Komatsu Excavator PC250LC-6L PC200-6 708-2L-25211	solenoid 6732-82-9110 24v

## KOMATSU EXCAVATOR PARTS----valve(solenoid valve, pilot valve)

CMPK-G121	CMPK-G122
	
Solenoid Valve	Solenoid Valve
PC55 PC40	PC200-6 6D102
12V	206-60-51130 206-60-51131 206-60-51132
CMPK-G1201	CMPK-G202
	
Pilot valve Pilot pump	Pilot valve Pilot pump
PC-6 PC200-6 PC100-6 PC120-6 PC300-6 PC400-6C	PC200-5 PC-5 PC220-5
702-16-01180	702-16-01022

## KOMATSU EXCAVATOR PARTS----Relief valve, main relief valve, Valve Assy

CMPK-H001	CMPK-H003	CMPK-H003	CMPK-H004
			
control main valve	Komatsu Main Valve	main relief valve	
PC300-1 PC200-1		PC200-6	
700-92-55000	702-75-01200	702-75-01201	
CMPK-H005	CMPK-H006	CMPK-H007	CMPK-H008
			
	Komatsu Relief Valve	main Valve	main Valve
	PC220-6 PC220LC-6		
708-2L-04523	708-2L-04531 708-2L-04532	Komatsu 708-2L-04713	708-2L-06710
CMPK-H009	CMPK-H010	CMPK-H011	CMPK-H012
			
main relief valve	Relief Valve	Hydraulic Main Relief Valve	Main Relief Valve
PC120-5	PC150-5 PC180LC-5K 4D102	PC300-5 PC200-5	PC120-6 PC130-6
709-70-51202 709-70-51203	709-80-5290	709-90-52201	723-30-50101
CMPK-H013	CMPK-H014	CMPK-H015	CMPK-H016
			
	main valve ass'y	main relief valve ass'y	
723-30-56100	PC120-6 PC100-6 PC128UU-1	PC120-6 PC130-6	PC200-6 PC200LC-6
	723-30-60101	723-30-50101 723-30-90101	723-40-50100
CMPK-H017	CMPK-H018	CMPK-H019	CMPK-H020
			
PC200-6 PC200LC-6		PC300-8-PC350-8-PC400-8	Main Relief Valve
723-40-50200 (	723-40-60101	723-40-85100	PC200LC-6 PC220LC-6
			723-40-90200

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinocmp-daisy

## KOMATSU EXCAVATOR PARTS----Relief valve, main relief valve, Valve Assy

CMPK-H021	CMPK-H022	CMPK-H023	CMPK-H024
			
relief valve oil suck valve			Service Relief valve
pc200-6			PC60-7
709-90-74302 723-90-61600 723-40-91200 709-70-55200	723-40-51102	723-40-92103 723-40-93600	
CMPK-H025	CMPK-H026	CMPK-H027	CMPK-H028
			
Relief valve	main relief valve	main relief valve	main relief valve
PC200-1	PC200-8	PC40	PC50
	723-46-23101		
CMPK-H029	CMPK-H030	CMPK-H031	CMPK-H032
			
main relief valve	Service relief valve	Service relief valve	Valve Assy
PC60-7	PC200-7 PC200-8	PC200-3	PC200

# KOMATSU EXCAVATOR PARTS----Hydraulic pump rebuild parts

CMPK-1001

ITEM	DESCRIPTION	QUANTITY	REMARK
1	ROLLER BEARING	1	
2-A	DRIVE SHAFT (L/R)	1	
2-B	DRIVE SHAFT (L/REV)	1	(PC200-3)
2-C	DRIVE SHAFT (L/SPLINE)	1	(PC200-3)
3-A	CRADLE (L/R)	1	
3-B	CRADLE (L)	1	(PC200-3)
4	SPACE	2	
5	SOCKET BOLT	4	
6	FIX PLATE	2	
7	CAM ROCKER	1	
8	PISTON SHOE	9	
9	SET PLATE	1	
10	CYLINDER BLOCK	1	
11	COIL SPRING	1	
12	WASHER	2	
13	SNAP RING	1	
14	VALVE PLATE (L/R)	1	
15	THRUST BEARING	2	

HPV35 HPV55 HPV71 HP90 HP160	PC200-3/5 PC300-3 PC300-3/5 PC400-3/5		
Drive shaft, Cradle, Cam roker, Piston Shoe, Set plate, Cylinder block, Vlave plate	Piston Shoe, Snap spring, fix Plate, Coil Sring, Thrust Bearing, etc		

CMPK-1002

ITEM	DESCRIPTION	QUANTITY	REMARK
1	VALVE PLATE (L/R)	1	
2	SPACE-A	1	
3	COIL SPRING	1	
4	SPACE-B	1	
5	CYLINDER BLOCK	1	
6	PIN OF CYLINDER BLOCK	3	
7	BALL GUIDE	1	
8	SET PLATE	1	
9	PISTON SHOE	9	
10-A		1	(HPV95A/PC200-6/7/8)
10-B		1	(HPV95C)
10-C		1	(HPV95A/PC200-7)
10-D	CAM ROCKER	1	(HPV140/PC200-7/8)
10-E		1	(HPV160/PC200-7)
10-F		1	(HPV120/PC200-8)
11-A		1	(HPV95C)
11-B	CRADLE	1	(HPV132A/55)
11-C		1	(HPV95A)
11-D		1	(HPV140)
12	DRIVE SHAFT (L/R)	1	
13	ROLLER BEARING	1	
14	SPACE	1	
15	SNAP RING	1	


















HPV95A HPV95C HPV95H HPV 132 HPV140 HPV165 HPV375	PC200-6 PC200-7 PC200-8 PC400-6/7/8 PC800-8 PC300-6/7/8		
Drive shaft, Cradle, Cam roker, Piston Shoe, Set plate, Cylinder block, Vlave plate	Piston Shoe, Snap spring, fix Plate, Coil Sring, Thrust Bearing, etc		



## KOMATSU EXCAVATOR PARTS----seal kits and other parts

CMPK-J001	CMPK-J002	CMPK-J003	CMPK-J004
			
<p>Boom cylinder seal kits PC200-3/5/6/7/8 PC-3/5/6/7/8</p>	<p>Arm Cylinder seal kits PC200-3/5/6/7/8 PC-3/5/6/7/8</p>	<p>Bucket cylinder seal kits PC200-3/5/6/7/8 PC-3/5/6/7/8</p>	<p>Control valve seal kits PC200-3/5/6/7/8 PC-3/5/6/7/8</p>
CMPK-J005	CMPK-J006	CMPK-J007	CMPK-J008
			
<p>Pilot valve seal kits PC200-3/5/6/7/8 PC-3/5/6/7/8</p>	<p>Main Pump seal kits PC200-3/5/6/7/8 PC-3/5/6/7/8</p>	<p>Center joint seal kits PC200-3/5/6/7/8 PC-3/5/6/7/8</p>	<p>swing motor seal kits PC200-3/5/6/7/8 PC-3/5/6/7/8</p>
CMPK-J008	CMPK-J009		
			
<p>Travel motor seal kits PC200-3/5/6/7/8 PC-3/5/6/7/8</p>	<p>Track Adjuster seal kits PC200-3/5/6/7/8 PC-3/5/6/7/8</p>		

## HITACHI EXCAVATOR PARTS---Controller

CMPH-A001	CMPH-A002	CMPH-A003	CMPH-A004
			
Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel
EX100-2	EX100-2	EX100-2 EX120-2 EX200-2 EX220-2 EX100-3 EX120-3 EX200-3 EX200LC-3	EX100-2 EX120-2 EX200-2 EX220-2 EX100-3 EX120-3 EX200-3 EX220-3
9104905	9116366	9128976	9104918
CMPH-A005	CMPH-A006	CMPH-A007	CMPH-A008
			
Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller
EX300-2 EX320-2 EX340-2	EX100-2	EX100-2 EX120-2 EX200-2 EX220-2 EX100-3 EX120-3 EX200-3 EX200LC-3	EX100-3
9104918	9104910	9131577	9133701
CMPH-A009	CMPH-A010	CMPH-A011	CMPH-A012
			
Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller
EX100-3 EX100M-3	EX120-3	EX120-3	EX120-2
9133700	9131576	9131578	9104907
CMPH-A013	CMPH-A014	CMPH-A015	CMPH-A016
			
Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller
EX120-2	EX120-2	EX200-2 EX200LC-2	EX200-2 EX200LC-2
9116368	9131579	9104908	9116941
CMPH-A017	CMPH-A018	CMPH-A019	CMPH-A020
			
Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller
EX200-2 EX200LC-2	EX200-2 EX200LC-2	EX220-2	EX220-3 EX220LC-3
9125533	9104912	9104909 9117636 9125534 9104913	9133703

# HITACHI EXCAVATOR PARTS---Controller

CMPH-A021	CMPH-A022	CMPH-A023	CMPH-A024
			
Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel
EX220-3 EX220LC-3	EX300-2 EX300LC-2 EX320-2 EX340-2	EX300-3 EX320-3 EX340-3 EX300LC-3	EX300-3 EX300LC-3 EX320-3 EX340-3
9133702	9123938	9136787	9136786
CMPH-A025	CMPH-A026	CMPH-A027	CMPH-A028
			
Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel
EX300-3 EX300LC-3	EX300-3 EX300LC-3 EX400-3 EX400-3C EX400LC-3 EX400LC-3C EX300-3C	EX400-3 EX400-3C EX400LC-3 EX400H-3 EX400LC-3C EX450H-3C EX400LCH-3	EX400-3 EX400-3C EX400LC-3 EX400H-3 EX400LC-3
9153489	9153488	9142477	9133566
CMPH-A029	CMPH-A030	CMPH-A031	CMPH-A032
			
Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller
EX400-3 EX400LC-3 EX400H-3 EX400-3C EX400LC-3C EX450-3 EX450-3C	EX400-3 EX400LC-3 EX400H-3 EX400LCH-3 EX450-3 EX450LCH-3	EX550-3 EX550LC-3 EX600H-3 EX550 EX550L EX600H EX600LCH EX600LCH-	EX550-3 EX550LC-3 EX600H-3 EX550 EX550LC EX600H EX600LCH
9143297	9133567	9137152	9137151
CMPH-A033	CMPH-A034	CMPH-A035	CMPH-A036
			
Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi Excavator Controller, Control Panel, Computer Board
EX100WD-3	EX400-5 EX400LC-5 EX450LC-5 EX450H-5 EX450LCH-5	EX400-5 EX400LC-5 EX450LC-5 EX450H-5 EX450LCH-5	Zaxis ZX110-1 ZX120-1
9135614	9162392	9158859	9226740
CMPH-A037	CMPH-A038	CMPH-A039	CMPH-A040
			
Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board
Zaxis ZX100-1 ZX130-1	Zaxis ZX200/230/230LC/240/250/250LC-1	Zaxis ZX200-1 ZX200LC-1 ZX230-1	Zaxis ZX240-1
9226743	9226752	9226748	4445494

# HITACHI EXCAVATOR PARTS---Controller

CMPH-A041	CMPH-A042	CMPH-A043	CMPH-A044
Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU	Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board
Zaxis ZX250-1 ZX270-1 ZX270LC-1 ZX280LC-1	Zaxis ZX270-1 ZX270LC-1 ZX280LC-1 ZX280L-1	Zaxis ZX330-1 ZX330LC-1 ZX370-1 ZX350LC-1	Zaxis ZX450-1 ZX450LC-1 ZX450H-1
X9226754 9226754 0241117000	4428087	9226755 4428088	4428516 9227386
CMPH-A045	CMPH-A046	CMPH-A047	CMPH-A048
Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU	Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU	Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU
Zaxis ZX200-3 ZX240-3	Zaxis ZX220/230/270/330-1, ZX110/120/130/135US/200/240/270/330-3	ZX200-3 ZX200LC-3 ZX210-3 ZX240-3 ZX250-3	Zaxis ZX240-3 ZX270-3
9292115	9292116 9263792	9292112	9281270
CMPH-A049	CMPH-A050	CMPH-A051	CMPH-A052
Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU	Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU, Engine Controller	Hitachi Excavator Control Panel, Controller, Computer Board CPU, Engine Controller
ZX330-3 ZX330LC-3 ZX320LC-3 ZXS350LC-3	ZX225US-3 ZX225USLC-3	ZAXIS200 ZAXIS450 ZAXIS450LC ZAXIS600 ZAXIS160LC	ZAXIS160LC ZAXIS240 ZAXIS250 ZAXIS450 ZAXIS450LC
9260333	9263795	9194416	9212078
CMPH-A053	CMPH-A054	CMPH-A055	CMPH-A056
Hitachi Excavator Control Panel, Controller, Computer Board CPU, Engine Controller	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU
ZAXIS160LC ZAXIS200 ZAXIS230LC ZAXIS330 ZAXIS330LC ZAXIS370	ZX200/240/330/270/450-/240LC/250LC-3 ZX120/130W/160W/180W/210	EX100-3 EX200-3 EX200LC-3 EX200H-3 EX300-3 EX300LC-3	EX200-2 EX200LC-2 EX100-2 EX300-2 EX300LC-2 EX200-3
9239568	4631129 X4631129 025F41000 0500	4325825 4688258	4248572
CMPH-A057	CMPH-A058	CMPH-A059	CMPH-A060
Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU
EX60-5	EX200LC-5 EX200-5 EX210H-5 EX210LCH-5	EX120-5 EX130H-5	EX120-5
7376700	4372490 9164280	4369340	9164280 9148017

EMAIL: [service@sinoamp.com](mailto:service@sinoamp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596







Skype: Mou Mark(CMP) sinoamp-daisy

## HITACHI EXCAVATOR PARTS---Controller

CMPH-A061	CMPH-A062	CMPH-A063	CMPH-A064
			
Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU
EX200-5	EX120-5 EX200-5	EX120-5 EX135USR	Zaxis ZX210-3 ZX200-3
9164280	9148016	9164279	4686916
CMPH-A065	CMPH-A066	CMPH-A067	
			
Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU	
Zaxis ZX270-3 ZX280-6	Zaxis ZX240-3	Zaxis ZX240-3	
8980806670	4686919	4635318	























## HITACHI EXCAVATOR PARTS---A/C Controller

CMPH-B001	CMPH-B002	CMPH-B003	CMPH-B004
			
Hitachi Excavator Air Conditioning Control Panel, A/C Controller Zaxis ZX75US-1/3 ZX135US-1/3 ZX225US-1/3 ZX135US-1/3	Hitachi Excavator Air Conditioning Control Panel, A/C Controller Zaxis ZX200-3 ZX240-3 ZX270-3	Hitachi Excavator Air Conditioning Control Panel, A/C Controller ZX160LC ZX120 ZX130	Hitachi Excavator Air Conditioning Control Panel, A/C Controller ZX450 ZX450LC EX1200-ZAXIS600 ZX600LC ZX800
4450315 4713662 4692239 4713980 4426048	4692240	4431080 146430-8272 237040-0090	4439093
CMPH-B005	CMPH-B006		
			
Hitachi Excavator Air Conditioning Control Panel, A/C Controller ZX200-3 ZX240-3 ZX330-3 ZX270-3 ZX450-3 ZX240LC-3 ZX250LC-3	Hitachi Kobelco Motor Control Mold, Accelerator Module EX200-2/3 SK200-6		
4631128	SS2B003		



## HITACHI EXCAVATOR PARTS---Monitor

CMPH-C001	CMPH-C002	CMPH-C003	CMPH-C004
			
Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen	Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen	Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen	Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen
ZX160LC/200/230LC/240/330/330LC/370/135US	Zaxis ZX200 ZX120 ZX240 ZX130 ZX135US ZX225US	Zaxis ZX200 ZX230LC ZXS330 ZX330LC ZXS370 ZX230 ZX350	Zaxis ZX-3
4488903 4483034	4450853	4646113	4652262 4631127 4653775 4684075
CMPH-C005	CMPH-C006	CMPH-C007	
			
Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen, Instrument Panel	Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen, Instrument Panel	Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen, Instrument Panel	
EX100/120/200/220/300/400/550/600H-2/3	EX120-5 EX220-5 EX220LC-5 EX270-5 EX270LC-5 EX300-5 EX330LC-5	EX60-5 EX60LC-5 EX80-5	
4273796	4411757 4370905	4362249	

# HITACHI EXCAVATOR PARTS---Motor

CMPH-D001	CMPH-D002	CMPH-D003	CMPH-D004
			
Hitachi Excavator Throttle Motor, Stepping Motor	Hitachi Excavator Throttle Motor, Stepping Motor	Hitachi Excavator Blower Motor	Hitachi Excavator Blower Motor
EX200-5-6 EX200-5 EX300-5 ZAX200-6 ZAX120/220/230/240/330-5	EX200-2 EX200-3 EX300-2 EX300-3 EX100-1 EX100-2 EX100-3	EX200-2 EX200-3	EX200-5 EX230LC-5
4360509 4614911	4257163 4188762 9094106 4709168		
CMPH-D005	CMPH-D006	CMPH-D007	CMPH-D008
			
Hitachi Excavator Blower Motor	Hitachi Excavator Blower Motor	Hitachi Excavator Blower Motor	Hitachi Excavator Blower Motor
ZX120-3 ZX330-3	ZAX200-3 ZX240-3	ZX460	ZX60 ZX70
			502725-1730 Y-SSMZ113-12
CMPH-D009	CMPH-D010	CMPH-D011	CMPH-D012
			
Hitachi Excavator Blower Motor	Hitachi Excavator Wiper Motor	Hitachi Excavator Wiper Motor	Hitachi Excavator Throttle Knob
ZX70LC ZX80 ZX135US ZX225US ZX70 ZX75US ZX85	ZAX200-3	ZX870-3	EX120-5 EX150LC-5 EX160LC-5 EX220-5 EX220LC-5 EX270-5 EX270LC-5
4475716		4709168	4341545
CMPH-D013	CMPH-D014	CMPH-D015	CMPH-D016
			
Hitachi Excavator Throttle Cable	Hitachi Excavator Throttle Cable	Hitachi Excavator Throttle Cable	Hitachi Excavator Throttle Cable
ZX200 ZX230LC ZX225US ZX230 ZX240LCH	EX120-2 EX100-2 EX100-3	ZX230LC ZX230 ZX240LCH ZX250 ZX250LC ZX270	EX1200-5 EX1200-5C EX1200-5D EX300-2 EX1200-6
4426564	4259859	4437891	4440505
CMPH-D017	CMPH-D018	CMPH-D019	CMPH-D020
			
Hitachi Excavator Throttle Cable	Hitachi Excavator Throttle Cable	Hitachi Excavator Accelerate Cable	Hitachi Excavator Throttle Cable
EX90 SK60-5	EX120-3 EX300-5	EX200-3	EX60


## HITACHI EXCAVATOR PARTS---Motor

CMPH-D021	CMPH-D022
	
<p>Throttle Wiring Harness Governor Cable</p>	<p>Hitachi Excavator Throttle Cable</p>
<p>ZX450 ZX450LC ZX450H ZX600 ZX600LC ZX650H ZX800 ZX330LC</p>	<p>ZX135</p>
<p>4614911</p>	

# HITACHI EXCAVATOR PARTS---Solenoid Valve

CMPH-E001	CMPH-E002	CMPH-E003	CMPH-E004
Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY	Hitachi Valve	Hitachi Excavator Solenoid Valve
EX150-5 EX100-5 EX120-5 EX200-5 EX230-5	ZX200-3 ZX230-6	EX120-5 EX100-3 EX150LC-5 EX160LC-5 EX200-3 EX200LC-3	EX-5 EX135USR EX225USR
0671301	9218235	4255055	9745876 4367899
CMPH-E005	CMPH-E006	CMPH-E007	CMPH-E008
Hitachi Excavator Solenoid Valve	Hitachi Excavator High Speed Solenoid Valve, High Velocity Solenoid	Hitachi Excavator Solenoid Valve	Hitachi Excavator Solenoid Valve
Zaxis ZX450	EX100-2/3/5 EX120-2/3/5 EX200-2/3/5	ZX200-3 ZX210-3 EX400-3 EX400LC-3 EX400-3C EX400-5 EX400LC-5	ZX200 ZX230LC ZX230 ZX250 ZX250LC ZX350-3 ZX330-3
4469585	9147260 9120191 9120292 9098250	4368974	9218234
CMPH-E009	CMPH-E010	CMPH-E011	CMPH-E012
Hitachi Excavator Solenoid Valve	Hitachi Excavator Solenoid Valve	Hitachi Excavator Solenoid Valve	Hitachi Excavator Solenoid Valve
ZX60LC ZXS200 ZX230LC ZX330 ZX330LC ZX370 ZX120 ZX-3	EX100-3 EX200-3 EX200LC-3 EX200-2 EX200LC-2 EX100-2 EX220-3	EX100-3 EX200-3 EX200LC-3 EX200-2 EX200LC-2 EX100-2 EX220-3	EX100-3 EX200-3 EX200LC-3 EX200-2 EX200LC-2 EX100-2 EX220-3
4455991 9239590	4288336 9218359	4288337 9218367	4288336
CMPH-E013	CMPH-E014	CMPH-E015	CMPH-E016
Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY
Zaxis ZX-3	Zaxis ZX-3	EX200-5 EX330LC-5	EX220-5 EX300-5 EX300LC-5 EX350-5 EX370-5 EX345USR EX385USR
9254306 9312027	4400442 9218269 9311350	4330224 4330226 4396760	9218255 4396760 AT250108
CMPH-E017	CMPH-E018	CMPH-E019	
Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY	
EX200-2 EX200LC-2	EX200-5	ZX330 ZX330LC ZX370 ZX350LC ZX350LCN ZX350LCH ZX350K	
4254647 9218370 4299959 AT158394 AT154742	9218312 9218382	9195243	

## HITACHI EXCAVATOR PARTS---Conversion Kit

CMPH-F001	CMPH-F002	CMPH-F003	CMPH-F004
			
Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit
EX200-2	EX120-2	EX220-2	
CMPH-F005	CMPH-F006	CMPH-F007	CMPH-F008
			
Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit
EX200-3	EX220-3	EX100-3	EX120-3

# HITACHI EXCAVATOR PARTS---Wiring Harness

CMPH-H001	CMPH-H002	CMPH-H003	CMPH-H004
			
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
Zaxis ZX240-3 ZX270-3 ZX240LC-3 ZXS250LC-3 ZX250LCN-3 ZXS270LC-3	Zaxis ZX450 ZX450LC ZX450H ZX450LCH; ZX460LCH	EX225US EX1120-5 EX200-5	EX220-5
4658146	ZX450 ZX450LC ZX450H ZX450LCH; ZX460LCH	0002207 0001932	0002018
CMPH-H005	CMPH-H006	CMPH-H007	CMPH-H008
			
Hitachi Excavator Wiring Harness(External)	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
Zaxis ZX200 ZX200LC ZX210H ZX210LCH ZX210K ZX250 ZX240	ZX330-3 ZX330LC-3 ZX350-3 ZX350H-3 ZX350LCH-3	Zaxis ZX200 ZX230 ZX240 ZX250 ZX270 ZX280 ZX230LC ZX250LC	Zaxis ZX200 ZX230 ZX240 ZX250 ZX270 ZX280 ZX230LC ZX250LC
0004773 0003323	0005471	0003816	1027579
CMPH-H009	CMPH-H010	CMPH-H011	CMPH-H012
			
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
ZX200-3 ZX200LC-3 ZX210H-3 ZX210LCH-3 ZX210K-3 ZX240-3	ZX240-3 ZX330-3 ZX270-3 ZX240LC-3 ZX250LC-3 ZX250LCN-3	ZX200-1	ZX120-3 ZX270-3 ZX280-3 ZX200-3 ZX270LC-3 ZX280LC-3
0005473 0005472	0005458	4449447 4449447H	0006003
CMPH-H013	CMPH-H014	CMPH-H015	CMPH-H016
			
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
Zaxis ZX330 ZXS330LC ZX350H ZXS370 ZX350LC ZX350LCN	Zaxis ZX110 ZX120	Zaxis ZX160LC ZX200 ZXS230LC ZX120 ZX230 ZX240H ZX210 ZX250 ZX270	EX120-5 EX150LC-5 EX160LC-5 EX100- 5 EX200LC-5 EX130H-5 EX110-5
0004307	0004770	0003322	0002023
CMPH-H017	CMPH-H018	CMPH-H019	CMPH-H020
			
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
EX100-3 EX200-3 EX200LC-3 EX200H-3 EX120-3 EX200LCH-3	ZX450 ZXS450LC ZX450H ZX450LCH ZX460LCH	EX200-2 EX200LC-2 EX100-2 EX120-2	EX100-2 EX120-2
0001835 0001836	4447726	0001044	0001049



# HITACHI EXCAVATOR PARTS---Wiring Harness

CMPH-H021	CMPH-H022	CMPH-H023	CMPH-H024
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
EX100-3 EX100M-3 EX120-3	EX200-2 EX200LC-2	EX220-2	EX220-2
0001847	4296868	0001065	0001066 4296408
CMPH-H025	CMPH-H026	CMPH-H027	CMPH-H028
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Hydraulic Pump Wiring Harness
EX300-2 EX300LC-2 EX300H-2 EX300LCH-2	EX300-3 EX300LC-3 EX300H-3 EX300LCH-3	EX400-3 EX400LC-3 EX400H-3 EX400-3C EX400LC-3C EX450H-3C EX450LCH-	EX120-2
0001534 0001535	0001660 0001661	0001302 0001303	0671301
CMPH-H029	CMPH-H030	CMPH-H031	CMPH-H032
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
EX400-3 EX400LC-3 EX400-3C EX400LC-3C EX400-5 EX400LC-5	EX200LC-5 EX200-5 EX210H-5 EX210LCH-5 EX210-5	EX400-5 EX400LC-5 EX450LC-5 EX450-5 EX450LCH-5	EX400-5 EX400LC-5 EX450LC-5 EX450-5 EX450LCH-5
4295913	0003779	0002676 0003303 0003385	0002694 0003435
CMPH-H033	CMPH-H034	CMPH-H035	CMPH-H036
Hitachi Excavator Hydraulic Pump Wiring Harness	Hitachi Excavator External Wiring Harness	Hitachi Excavator Complete Wiring Harness	Hitachi Excavator Pump Wiring Harness
ZX200-3	EX120-2	EX120-2 EX100-2	EX200-3
0002018			
CMPH-H037			
Hitachi Excavator Hydraulic Pump Wiring Harness			
ZX200-1			

# HITACHI EXCAVATOR PARTS---Relief Valve

CMPH-I001	CMPH-I002	CMPH-I003	CMPH-I004
			
Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve
EX200-3 EX200LC-3 EX200H-3 EX200-2 EX200LC-2 EX220-3 EX220LC-3	ZX200 EX200LC-5 ZX225US ZX225USLC ZX200LC EX200-5 ZX200-3	EX220-5 EX220LC-5 EX270-5 EX270LC-5 EX280-5 EX200LC-5 EX230LC-5	EX120-2
4289602 4289406	4372038	4372034	
CMPH-I005	CMPH-I006	CMPH-I007	CMPH-I008
			
Hitachi Excavator Main Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Relief Valve	Hitachi Excavator Main Pressure Relief Valve
EX200-5	EX300-3 EX300LC-3 EX300-3C EX310H-3C EX300-2 EX300LC-2 EX300H-2	EX200-1	EX200-2 EX200-3 EX200LC-3 EX220-5 EX220LC-5 EX270-5 EX270LC-5 EX300-
	4324535		9134147
CMPH-I009	CMPH-I010	CMPH-I010	CMPH-I012
			
Hitachi Excavator Service Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Relief Valve	Hitachi Excavator Main Pressure Relief Valve
EX120-5 EX150LC-5 EX160LC-5 EX100-5 EX100-5E ZX120 ZX120-E ZX130H	EX300-3 EX200-3 EX220-5 EX220LC-5 EX270-5 EX270LC-5 XXS200 ZX230LC	ZX200	ZX350-3 EX330-3 EX300-5 EX330LC-5 EX370-5 ZX330 ZX370 EX285USR
4372683	4372039		0719308 0719117
CMPH-I0013	CMPH-I014	CMPH-I015	CMPH-I016
			
Hitachi Excavator Main Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve
EX300-5 EX300LC-5 EX330LC-5 EX350H-5 EX370-5 ZX330 ZX330LC	EX200 EX200LC	ZX190W-3	EX200-2 EX300-5 EX300LC-5 EX330LC-5 EX200-5 EX370-5 ZX330 XXS330LC
0719010	4242176 4228354	9200504	0719116
CMPH-I017			
			
Hitachi Excavator Main Relief Valve			
ZX330 ZX330LC XXS350H ZX370 ZX350LC ZX350LCN			
0816204			




# HITACHI EXCAVATOR PARTS---Sensor,Switch


CMPH-J001	CMPH-J002	CMPH-J003	CMPH-J004
Throttle Locator , throttle position sensor , Fitting Sensor, Accelerator locator	Throttle Locator , throttle position sensor , Fitting Sensor, Accelerator locator	Hitachi Excavator DP Sensor	Hitachi Excavator DP Sensor
EX200-5 ZX200-6 ZAX210/220/230/240/330	EX200-1 EX200-2 EX100-3 EX200-3 EX200LC-3 EX200H-3 EX300-3	EX120-2 EX200-2 EX120-3 EX200-3 EX200-5 EX220-5 EX300-2 EX300-3	EX120-2 EX120-3 EX200-2 EX200-3
4614912	4257164	4339559 9101532 9102068	590332
CMPH-J005	CMPH-J006	CMPH-J007	CMPH-J008
Hitachi Angle Sensor Angular sensor	Hitachi Angle Sensor Angular sensor	Hitachi Angle Sensor Angular sensor	Oil Pressure Switch,Oil Pressure Sensor ,Hitachi Hydraulic Pressure Sensor
EX120-2 EX120-3 EX200-2 EX200-3 ZX450 ZX450LC ZX600 ZX800	EX120-2 EX120-3 EX200-2 EX200-3 ZX400-3 ZX400LC-3 ZX200LC-3	EX120-2 EX120-3 EX200-2 EX200-3	EX200-1 EX200-2 EX200-3 EX200-5
4444902	9102385 9101533	4716888	1-82410160-1 1-82410160-0 1-82410044-0
CMPH-J009	CMPH-J010	CMPH-J011	CMPH-J012
Oil Pressure Switch,Oil Pressure Sensor ,Hitachi Hydraulic Pressure Sensor	Oil Pressure Switch,Oil Pressure Sensor ,Hitachi Hydraulic Pressure Sensor	Oil Pressure Switch,Oil Pressure Sensor ,Hitachi Hydraulic Pressure Sensor	Hitachi Excavator RPM Revolution Speed Sensor
EX200-2 EX200-3 EX300-3	EX120-5 EX100-3 EXE150LC-5 EX200-3 EX220-5 EX200LC-3 EX220LC-5	EX200-5	EX200-1 EX200-2 EX200-3 EX200-5 EX100-3 EX220-5 EX270-5
4259333	4259787	6732-81-3140 08073-10505	4265372
CMPH-J013	CMPH-J014	CMPH-J015	CMPH-J016
Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Excavator Water Temperature Sensor Alarm
EX120-5 EX400-5 EX200-2/3/5 EX300-2/3/5 ZX330 ZX450	EX200-2 EX200-3 EX200-5 EX120-5 EX100-3 EX220-5 EX220LC-5	ZX200 ZX450 ZX1600 ZX800 ZX70LC ZX80 ZX160LC	EX100-3 EX200-3 EX200LC-3 EX400-3 EX400LC-3
4371318	4257129	4436537	4250260 179700-0050
CMPH-J017	CMPH-J018	CMPH-J019	CMPH-J020
Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Crankshaft sensor
EX200-2 EX200-5 EX200-3	ZX200-1	EX200-5 EX300-5	ZX240-3 ZX330-3 ZX270-3 ZX450-3 ZX850-3 ZX250LC-3
1-83161019-1	1-83161033-0	8-97125601-1	4657944 8-98014831-0

# HITACHI EXCAVATOR PARTS---Sensor, Switch

CMPH-J021	CMPH-J022	CMPH-J023	CMPH-J024
			
Hitachi Excavator Pressure Switch EX200-3 EX200-2 EX200-5 EX120-2 EX120-3 EX120-5EX400-3	Hitachi High-Pressure Common Rail Sensor ZX330-3	Hitachi Pressure Sensor(distributor) ZX200-3 ZX230-3 ZX450-3 ZX450 ZX600 ZX800 EX1200-5 EX1900-5	Hitachi Pressure Sensor(large pump) /Switch ZX450 ZX600 ZX800 ZX160 ZX200 ZX120-3 EX200-2/3/5 EX300-2/3/5
4254563	10L05840	4436535	4436536
CMPH-J025	CMPH-J026	CMPH-J027	CMPH-J028
			
Hitachi Pressure Switch(Distributor) EX60-5 EX100-5 EX120-5 EX200-5 EX220-5 EX270-5 EX150LC-5	Hitachi Excavator Pressure Sensor EX200-2 EX200LC-2 EX100-2	Hitachi Excavator Pressure Sensor EX200-2/3/5 EX300-2/3/5 ZX450 ZX600 ZX80 ZX210 ZX270	Hitachi Excavator Pressure Switch EX120-5 EX270-5 EX220LC-5 EX300-5 EX200LC-5 EX200-5 EX100-5
4353686	4339754 4248773	4436271 4355012	
CMPH-J029	CMPH-J030	CMPH-J031	CMPH-J032
			
Hitachi Excavator Pressure Sensor(distributor)Pressure Switch EX200-2 EX200-3 EX120-5 EX200-5 EX220-5 EX270-5 EX100-5	Hitachi Excavator Pressure Sensor EX200LC-2 EX100-2 EX200-2 EX200-3 EX120-5 EX200-5 EX100-5 EX270-5	Hitachi Excavator Pressure Sensor EX200-5 EX120-5 EX220-5 EX270-5 EX100-5 EX150LC-5 EX220LC-5	Switch 4483285 and Dial Knob 4482656 ZX200 ZX135US ZX225US
20PS586-19F82	4333040	4380677 20PS586-23	4483285
CMPH-J033	CMPH-J034	CMPH-J035	CMPH-J036
			
Hitachi Excavator Ignition Switch EX200-2 EX200-3 EX200-5 EX300-3 EX3500-3 EX5500-3 EX100-2 EX300-2	Hitachi Excavator Ignition Switch EX200-1	Hitachi Excavator Ignition Switch ZX200LC ZX250 ZX350 ZX240F-3 ZX290F-3	Hitachi Excavator Ignition Switch EX100-3 EX200-3 EX300-3 EX200 EX200-2 EX200LC-3
4250350 4448303		4477373	4164695
CMPH-J037	CMPH-J038		
			
Hitachi Excavator Ignition Switch Zaxis ZX	Hitachi Excavator Ignition Switch EX200-2/3/5		

# HITACHI EXCAVATOR PARTS----Relay

CMPH-K001	CMPH-K002	CMPH-K003	CMPH-K004
			
Hitachi Excavator Starter Relay	Hitachi Excavator Battery Relay	Hitachi Excavator Relay	Hitachi Excavator Relay
EX200-2 EX200-3 EX200-5 EX120-5 EX100-3 EX220-5 EX220LC-5 EX200LC-	EX120-5 EX100-3 EX150LC-5 EX200-3 EX300-3 EX200LC-3 EX300LC-3	EX120-2 EX200-3 EX300-3 EX200-2 EX100-2 EX400 EX1000 UH181 UH501	ZX450 ZX450LC ZX600 ZX600LC ZX800 ZX70LC ZX80 EX1200-5
4251588 4251587 5AT02-261022	4255762 BR-262 08088-30000	4191999 4325797 1-82550192-1	4436534

CMPH-K005

Hitachi Excavator Relay
MR5A016B2

# HITACHI EXCAVATOR PARTS----Pump

CMPH-L001	CMPH-L002	CMPH-L003	CMPH-L004
			
Hitachi Excavator Pilot Pump	Hitachi Excavator Gear Pump	Hitachi Excavator Gear Pump	Hitachi Excavator Gear Pump
EX100-2 EX100M-2 EX120-2 EX200K-2 EX220-2 EX200-2 EX200-3E	EX100-3/5 EX110-5 EX200-3/5 EX220-3/5 EX225 EX230-5 EX270-5 EX280 EX400-	EX200-1 EX220-1 EX270-1 EX300-1/2/3/3C/5 EX330LC-5 EX400-1 EX550-	UH082LC UH261 UH172 UH07-5 UH123 UH10-7 UH23 UH07-7 UH07LC-7 UH083
4255303 9218004	4276918 9218005	4181700 9217993	4035495
CMPH-L005	CMPH-L006	CMPH-L007	CMPH-L008
			
Hitachi Excavator Gear Pump	Hitachi Excavator Oil Pump	Hitachi Excavator Oil Pump	Hitachi Excavator Oil Pump
EX30-2 EX35-2	EX100 EX120	EX200-1 EX200-2	
			8-98009397-1
CMPH-L009	CMPH-L010	CMPH-L011	CMPH-L012
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
4BG1	4BG1T	4HF1	4JB1
CMPH-L013	CMPH-L014	CMPH-L015	CMPH-L016
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
4JG2	4ZC1	4ZD1	4ZE1
CMPH-L017	CMPH-L018	CMPH-L019	CMPH-L020
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
6BD1	6BD1H	EX200-2/3 6D16T	6HE1T
		4210164	

# HITACHI EXCAVATOR PARTS----Pump





CMPH-L021	CMPH-L022	CMPH-L023	CMPH-L024
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
6QA1	6RBIT	C190	C240
CMPH-L025	CMPH-L026	CMPH-L027	CMPH-L028
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
DA220	DA640	EX120-2	EX200-1 6BD1T
CMPH-L029	CMPH-L030	CMPH-L031	CMPH-L032
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
EX200-2 6BD1T	EX200-5 6BG1T	EX300-3 6SD1T	EX300-5 6SD1T
CMPH-L033	CMPH-L034	CMPH-L035	CMPH-L036
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
FSR113 6BF1	EX120-2 EX120-5 4BG1	4HK1	NKR 4JB1T
CMPH-L037	CMPH-L038	CMPH-L039	CMPH-L040
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
TCM C240	UBS 6VD1	EX200-5 6BG1	EX220-5 H07CT
		1-13650017-1	



## HITACHI EXCAVATOR PARTS----Pump

CMPH-L041	CMPH-L042	CMPH-L043	CMPH-L044
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
EX300-2/3 6SD1	ZX330	ZX330 6HK1T	4BD1 4BC2
1-13610944-0	1-13650133-0		
CMPH-L045	CMPH-L046	CMPH-L047	
			
Hitachi Main Hydraulic pump	Hitachi Excavator Regulator Pump	Hitachi Excavator Piston Pump	
EX300 EX300LC EX300H EX300LCH			
9075752	9266177	PVK-2B-505-N-4962F	

## HITACHI EXCAVATOR PARTS----Injector


CMPH-M001	CMPH-M002	CMPH-M003	CMPH-M004
			
<p>Hitachi Excavator Injector</p>	<p>Hitachi Excavator Injector</p>	<p>Hitachi Excavator Injector</p>	<p>Hitachi Excavator Injector</p>
<p>ZX200-3 ZX240-3 ZX330-3 ZX350-3</p>	<p>ZX470-3</p>	<p>ZX350-3</p>	<p>ZX-3</p>
<p>8-98284393-0 095000-0660</p>	<p>8-97603415-7</p>	<p>8-98284393-0</p>	<p>095000-5474</p>

# HITACHI EXCAVATOR PARTS----Seal Kit

CMPH-N001	CMPH-N002	CMPH-N003	CMPH-N004
			
Hitachi Bucket Cylinder Seal Kit	Hitachi Excavator Arm Cylinder Seal Kit	Hitachi Excavator Boom Cylinder Seal Kit	Hitachi Excavator Travel Motor Seal Kit
		EX60-3	EX60-5
CMPH-N005	CMPH-N006	CMPH-N007	CMPH-N008
			
Hitachi Excavator Center Joint seal kits	Hitachi Excavator Main Pump Seal Kit	Hitachi Excavator swing motor Seal Kit	Hitachi Excavator Track Adjuster Seal Kit
CMPH-N009	CMPH-N010		
			
GASKET KIT	Hitachi Excavator Gear Pump Seal Kit		

# HITACHI EXCAVATOR PARTS----Hydraulic Parts

CMPH-Q001



ITEM	DESCRIPTION	QUANTITY	REMARK
1	SERVO PISTON	2	
2	SERVO PISTON PIN	2	
3	HEAD COVER	1	
4	VALVE PLATE (R)	1	
5	SNAP RING	12	
6	BOLT OF VALVE PLATE	4	
7	ROTOR	2	
8	LINK OF VALVE PLATE	4	
9	PIN OF LINK	4	
10	COIL SPRING	2	
11	PISTON	14	
12	FEED BACK LEVER	2	
13	VALVE PLATE (L)	1	
14	CENTER PIN	2	
15	PIN OF CENTER PIN	2	
16	DRIVE SHAFT (R)	1	
17	DRIVE SHAFT (L)	1	
18	LOCK NUT	2	
19-A	PIN OF FEED BACK-A	2	
19-B	PIN OF FEED BACK-B	2	




Hitachi Excavator Hydraulic Pump Spare Parts

HPVO50/102/118/135

EX200-5 EX220-5 ZX200 ZX220 ZX230

CMPH-Q002



ITEM	DESCRIPTION	QUANTITY	REMARK
1	HEAD COVER	1	
2	SERVO PISTON	1	
3	SERVO PISTON PIN	1	
4-A	VALVE PLATE(ES-TYPE)	1	
4-B	VALVE PLATE(DS-TYPE)	1	
5	ROTOR	1	
6	COIL SPRING	1	
7	PISTON	14	
8	CENTER PIN	2	
9	PIN OF CENTER PIN	2	
10	HOLDER OF CENTER PIN	1	DS-TYPE
11	BALL OF CENTER PIN	1	DS-TYPE
12	DRIVE SHAFT(ES-TYPE)	1	
13	DRIVE SHAFT(DS-TYPE)	1	
14	BOLT OF VALVE PLATE	1	
15	LOCK NUT	2	



Hitachi Excavator Hydraulic Pump Spare Parts

HPVO91DS/ES

EX100-2 EX100-3 EX100-5 EX200-2 EX200-3 EX220-2 EX220-3

## HITACHI EXCAVATOR PARTS---Others

CMPH-P001	CMPH-P002	CMPH-P003	CMPH-P004
			
Throttle Motor Gear	Rubber Gear	Fuel tank cap	Hitachi Handle
EX120-5/60EX200-5/6	ZX-5	ZX-5	EX300-5
CMPH-P005	CMPH-P006	CMPH-P007	CMPH-P008
			
Hitachi Excavator Air Conditioning Belt Tensioner	Hitachi Excavator Diode	HITACHI Hydraulic Oil Dipstick	Hitachi Hydraulic Oil Dipstick
8-94399957-0 4346770	EX200-3 EX400-3 EX750-5 EX1100-5 EX200LC-3 EX550-5 4288109		
CMPH-P009	CMPH-P010	CMPH-P011	CMP-K025
			
Hitachi Excavator Fuel Gauge Level	Hitachi Fuel Gauge Level For JOHN DEERE Excavator	Hitachi Excavator Radio	Hitachi Excavator Fuse Panel Box
8033923	EX200-23 EX120-3 6BD1 8033923	ZX250LC-3 YA00010687	ZX-1
CMP-K026	CMP-K027	CMP-K028	CMP-K029
			
Hitachi Excavator Fuse Panel Box	Hitachi Excavator Ring	Hitachi Excavator Radiator	Hitachi Excavator Oil Seal
ZX-3	EX100-3 EX200-3 EX200-2 EX100-2 ZX200 ZX230LC EX200LC-3 4339171	ZX200-3 ZX240-3 ZX330-3 ZX270-3 ZX250-3 4647814	EX100-3 EX200-3 EX220-3 EX220LC-3

## Volvo EXCAVATOR PARTS---Controller





CMPV-A001	CMPV-A002	CMPV-A003	CMPV-A004
Volvo ECU, Controller Control Panel Computer Board 24V	Volvo ECU, Controller Control Panel Computer Board 24V	Volvo ECU, Controller Control Panel Computer Board 24V	Volvo ECU, Controller Control Panel Computer Board 24V
EC160BLC EC160	EC210B EC210BLC EC240B EC270B EC290B EC330B EC360B EC460B	L60E L70E L120	EC360B EC360BLC
60100002 VOE 60100002/P02/P04/P05/P06/P11	60100002 VOE 60100002/P02/P04/P05/P06/P11	60100002/ 3161983/ VOE 20577135	20582958/ VOE 20582958/P06
CMPV-A005	CMPV-A006	CMPV-A007	CMPV-A008
Volvo ECU, Controller Control Panel Computer Board 24V	Volvo ECU, Controller Control Panel Computer Board 24V	Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V	Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V
EC290B EW145B	EC460B EC360B EC330B	EC140B EC140 EC160BLC EC160 EC180B EC180BLC	EC210B EC210BLC EC240B EC240BLC EC270B EC270BLC EC290B EC290BLC
20577135/ VOE 20577135/P02	20577131/ VOE 20577131	60100000 VOE 60100000/P01/P02/P03/P04/P11	60100000 VOE 60100000/P01/P02/P03/P04/P11
CMPV-A009	CMPV-A010	CMPV-A011	CMPV-A012
Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V	Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V	Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V	Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V
EC330B EC330BLC EC360B EC360BLC EC380B EC380BLC EC460B	EC210C EC210CLC EC290C EW180C EC210D	L60F L20E L120E	EC140B EC140 EC140BLC EC160B EC160 EC160BLC EC180B EC180BLC
60100000 VOE 60100000/P01/P02/P03/P04/P11	60100000 VOE 60100000/P01/P02/P03/P04/P11	60100000 VOE 60100000/P01/P02/P03/P04/P11	VOE 14518349/ VOE 14514090
CMPV-A013	CMPV-A014	CMPV-A015	CMPV-A016
Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V	Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V	Volvo ECU Controller Control Panel Computer Board 24V	Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V
EC210 EC210B EC210BLC EC240 EC240B EC240BLC EC290B EC290BLC	EC330B EC330BLC EC330 EC360 EC360B EC360BLC EC380B EC380BLC	EC240B EC290B EC330B EC360B EC460B	EC210B EC240B EC290B EC330B EC360B EC380B EC460B
VOE 14518349/ VOE 14514090	VOE 14518349/ VOE 14514090	14531360/ VOE14531360	14594697/ VOE 14594697
CMPV-A017	CMPV-A018	CMPV-A019	
Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V	Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V	Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V	
EC360D EC380D EC480DL	EC220D EC200D EC350D EC380D EC480D	EC700 EC700B D16E	
14594707/ VOE14594707	14594708/ VOE14594708	20814604/ VOE 20814604	

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinocmp-daisy

## Volvo EXCAVATOR PARTS---Controller

CMPV-A021	CMPV-A022	CMPV-A023	CMPV-A024
			
<p>Volvo Air Conditioner Control Panel Controller, A/C Controller DC: 24V</p>	<p>Volvo Air Conditioner Control Panel Controller, A/C Controller DC: 24V</p>	<p>Volvo 60100000 ECU Controller Plug</p>	<p>Volvo VECU Controller Plug</p>
<p>EC140B EC160B EC180B EC210B EC460B EC360B EC330B EC290B</p>	<p>EC140B EC160B EC180B EC210B EC460B EC360B EC330B EC290B</p>	<p>EC140B EC160B EC180B EC210B EC460B EC360B EC330B EC290B</p>	<p>EC140B EC160B EC180B EC210B EC460B EC360B EC330B EC290B</p>
<p>14590052/ 14541344 VOE14541344 VOE14590052</p>	<p>14631179/ 14520415 VOE14631179/ VOE14520415</p>		







## Volvo EXCAVATOR PARTS---Monitor

CMPV-B001	CMPV-B002	CMPV-B003	CMPV-B004
			
Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V
EC140 EC140BLC EC140B	EC160B EC160BLC EC210B EC210BLC EC240B EC240BLC EC290B EC290BLC	EC360B EC360BLC EC380B EC380BLC EC460B EC460BLC	EW180B
VOE 14390065/P03/P02 VOE 14636301/ VOE 14527149	VOE 14390065/P03/P02 VOE 14636301/ VOE 14527149	VOE 14390065/P03/P02 VOE 14636301/ VOE 14527149	14390065/ VOE 14390065/P03/P02
CMPV-B005	CMPV-B006	CMPV-B007	CMPV-B008
			
Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V
EC160B EC210B EC290B EC330B EC360B EC380B EC460B	EC140B EC160B EC210B EC290B EC330B EC360B EC380B EC460B	EC360C EC240CL EC210D EC220D EC240D EC380D	EC360C EC240CL EC220D EC210D EC240D EC360D EC380D EC480D
1048069137DE/ 1145086420DE	14515555/ 14527158/ 14521370 VOE14527158/VOE14515555/VOE14521370	14585030/ 14609502/ 14640101 VOE14585030/VOE14609502/VOE14640101	14640102/ 14544928/ 14630801/ 14609611
CMPV-B009	CMPV-B010		
			
Volvo Monitor LCD	Volvo Monitor Plug		
EC140B EC160B EC210B EC290B EC330B EC360B EC380B EC460B	EC140B EC160B EC210B EC290B EC330B EC360B EC380B EC460B		

## Volvo EXCAVATOR PARTS---Sensor and Switch

CMPV-C001	CMPV-C002	CMPV-C003	CMPV-C004
			
Volvo Water Temperature Sensor EC240B EC290B EC330B EC360B EC460B EC700B	Volvo Revolution Roarty Speed Sensor EC140B EC160B EC180B EC210B EC240B EC290B	Volvo Oil Pressure Sensor Volvo Track, Wheel Loaders L180E L150E	Volvo Prime Level Sensor EC210BLC
14508670/ VOE 14508670	14505855/ VOE14505855	20706889/ 20374280/ 20478260/ 20700060	VOE21391697/ VOE20840227
CMPV-C005	CMPV-C006	CMPV-C007	CMPV-C008
			
Volvo Warning Level Sensor EC290B EC240B	Volvo Excavator Oil Pressure Sensor EC700B EC460B EC360B EC330B	Volvo Excavator Oil Pressure Sensor Switch EW140B	Volvo Excavator Oil Pressure Sensor EC460B EC360B EC330B
VOE11170064	21302639/ 20898038 20484678/ 20829689/ 21746206	VOE20585158	VOE1077574
CMPV-C009	CMPV-C010	CMPV-C011	CMPV-C012
			
Volvo Excavator Pressure Sensor 110R-000096/ 29003981	Volvo Water Temperature Sensor 16MM EC210B E290B	Volvo Excavator Oil Level Sensor VOE11423761	Volvo Excavator Pressure Sensor EC290 EC330 VOE14529294
CMPR-C013	CMPV-C014	CMPV-C015	CMPV-C016
			
Volvo Water Temperature Sensor EC210B EC140B	Volvo Excavator Oil Level Sensor VOE21391695/ VOE21391697	Volvo Water Temperature Sensor VOE4436537	Volvo Excavator Oil Pressure Sensor VOE 20796744
VOE20513340			
CMPV-C017	CMPV-C018	CMPV-C019	CMPV-C020
			
Volvo Excavator Oil Pressure Sensor VOE 20886108	Volvo Excavator NEW Oil Pan Pressure Sensor Truck D12 D13 EC300D VOE 21634021	Volvo Crankshaft Position Sensor EC210 EC290 VOE20820494	Volvo Crankshaft Speed Sensor EC240 EC290 VOE 20450707










## Volvo EXCAVATOR PARTS----Sensor and Switch

CMPV-C021	CMPV-C022	CMPV-C023	CMPV-C024
			
<p>Volvo Crankshaft Position Sensor</p>	<p>Volvo Crankshaft Position Sensor</p>	<p>Volvo Excavator Ignition Switch</p>	<p>Volvo Excavator Switch</p>
		<p>EC160B EC210 EC290 EC240B EC330B EC360B</p>	
<p>VOE0281002410/ 4890189</p>	<p>VOE20482772</p>	<p>VOE 14826158/ VOE 14529152</p>	<p>VOE14508635</p>

### Volvo EXCAVATOR PARTS---Main valve and Solenoid

CMPV-D001	CMPV-D002	CMPV-D003	CMPV-D004
			
Volvo Excavator Hydraulic Pump Solenoid Valve	Volvo Excavator Solenoid Valve Coil	Volvo Excavator Solenoid Valve Coil 24V	Volvo Excavator Solenoid Valve
EC210B EC290B	EC210B EC160B EC180B EC135B EC140B EC700B	EC210 EC240	EC210B EC140B EC240B EW130
KDRDE5K-20/40C04-109	14527267/ VOE14527267	VOE 14550884	VOE14526664/ 14526664
CMPV-D005	CMPV-D006	CMPV-D007	CMPV-D008
			
Volvo Excavator Main Relief/Control Valve	Volvo Excavator Main Relief/Control Valve	Volvo Excavator Main Relief/Control Valve	Volvo Excavator Main Relief/Control Valve
DH220-5 DH225-7 R225-7 HD820 SH120 EC210 EC240	EC210B EC240B EC210	EC210B EC240B EC210	EC460
	SA8230-21640/ 8230-21640	14518516/ SA8230-27400	
CMPV-D009	CMPV-D010	CMPV-D011	CMPV-D012
			
Volvo Excavator Service Relief/Control Valve	Volvo Excavator Rotary Overflow Valve	Volvo Excavator Rotary Overflow Valve	Volvo Excavator Main Relief/Control Valve
EC460	EC210 EC240	EC290	EC460 EC460LC
CMPV-D013			
			
Volvo Excavator Main Relief/Control Valve			
EC360B			
VOE 14552973			

## Volvo EXCAVATOR PARTS---Wire Harness, Motor Parts

CMPV-E001	CMPV-E002	CMPV-E003	CMPV-E004
			
Volvo Cable Wiring Harness	Volvo Excavator Wiring Harness	Volvo Excavator Wiring Harness	Volvo Excavator Cable Wiring Harness
EC210C L60F L70F L90F EW160C EC235C	EC290	D7E	EC210
22243151/ 22068267	20814758/ 22041209		
CMPV-E005	CMPV-E006	CMPV-E007	CMPV-E008
			
Volvo Excavator Wiring Harness	Volvo Excavator Wiring Harness	Volvo Excavator Wiring Harness	Volvo Wiper Motor
	EC210		EC120B EC240 EC160B EC360B
14631808	VOE20886142	VOE 88850634	VOE14508630
CMPV-E009			
			
Volvo Universal Motor Blower			

## Volvo EXCAVATOR PARTS----Engine parts (Pump, Turbocharger, Injector)

CMPV-F001	CMPV-F002	CMPV-F003	CMPV-F004
			
Volvo Excavator Water Pump	Volvo Excavator Fuel Pump	Volvo Excavator Fuel Pump	Volvo Excavator Fuel Injection Pump
EC240B EC210 EC290B Engine No. D7D	EC140B EC210B	EC210	EC290
VOE20459004/ VOE21404502	VOE20518337/VOE21019945/VOE21620 116 04290596/04294704/04294706	VOE 21584586	
CMPV-F005	CMPV-F006	CMPV-F007	CMPV-F008
			
Volvo Engine Turbo Turbocharger	Volvo Turbo Turbocharger	Volvo Turbo Turbocharger	Volvo BOSCH Fuel Injector
EC210B Engine No.D6D	EC240B EC240BLC EC290B	EC290B D7E	EC210B
	VOE21109241 (DEUTZ 0429 4738)	20873313/ 20459239/ 15096757	VOE 20798683 BOSCH 0445120067
CMPV-F009	CMPV-F010	CMPV-F011	CMPV-F012
			
Volvo Deutz Fuel Injector	Volvo Fuel Injector	Volvo BOSCH Fuel Injector	Volvo Fuel Injector
EC210	D16E EC700BLC	EC210B EC290B D6D	EC210 EC240 EC290 EC330BLC EC330 EC360
04290987/ 04290986	9098404	BOSCH 0445120066	VOE 20440388
CMPV-F013	CMPV-F014		
			
Volvo Injector Roller	Volvo Fuel Injector		
EC140B EC160B EC240B EC290B D7D	D12D		
VOE 11700392	VOE 20847327		

## Volvo EXCAVATOR PARTS----Seal kit

CMPV-G001	CMPV-G002	CMPV-G003	CMPV-G004
			
Volvo Boom Cylinder Seal Kit	Volvo Track Adjuster Seal Kit	Volvo Arm Cylinder Seal Kit	Volvo Boom Cylinder Seal Kit
EC210B	EC210BLC	EC210BLC	EC210BLC
14589129			
CMPV-G005	CMPV-G006	CMPV-G007	CMPV-G008
			
Volvo Bucket Cylinder Seal Kit	Volvo Arm Cylinder Seal Kit	Volvo Boom Cylinder Seal Kit	Volvo Bucket Cylinder Seal Kit
EC210BLC	EC210LC	EC210LC	EC210LC
CMPV-G009	CMPV-G010	CMPV-G011	CMPV-G012
			
Volvo Swing Motor Seal Kit	Volvo Arm Cylinder Seal Kit	Volvo Boom Cylinder Seal Kit	Volvo Bucket Cylinder Seal Kit
EC240B	EC240BLC	EC240BLC	EC240BLC
14556030 14526214			
CMPV-G013	CMPV-G014	CMPV-G015	CMPV-G016
			
Volvo PPC Seal Kit	Volvo Excavator Overhaul Full Gasket Kit	Volvo Control Valve Seal Kit	Volvo Main Pump Seal Kit
EC330B	EC360B Engine D12	EC460LC	EC460LC
			
Volvo Arm Cylinder Seal Kit	Volvo Boom Cylinder Seal Kit	Volvo Bucket Cylinder Seal Kit	GIANT ORING BOX
EC460LC	EC460LC	EC460LC	Volvo Hyundai Doosan



### Volvo EXCAVATOR PARTS---Others

CMPV-H001	CMPV-H002	CMPV-H003	CMPV-H004
			
Volvo Bushing	Volvo Coupling	Volvo Coupling	Volvo EC Fuel Inlet Metering Valve
EC240B EC210B	EC240B EC210B	EC240B EC210B	
VOE14512696	VOE14504230	VOE14531072	0928400670
CMPV-H005	CMPV-H006	CMPV-H007	CMPV-H008
			
Volvo Key Fuel	Volvo Fuel Cap Diesel Fuel Tank	Volvo Water Tank	Volvo Coupling
	EC210B	EC240BLC EC210B	EC210B
	14528922	15047209	41515827
CMPV-H009	CMPV-H010	CMPV-H011	
			
Volvo Fuel Pressure Regulator	Volvo Rotary Knob, Throttle Knob	Volvo Selector Unit Throttle Knob	
EC210BLC EC240B EC290BLC	EC210B		
VOE21103266	VOE 14542152	14659775/ VOE14659775	

## Caterpillar EXCAVATOR PARTS---Controller

CMPC-A001	CMPC-A002	CMPC-A003	CMPC-A004
Caterpillar Controller, CPU, Control panel, Computer Board	Caterpillar Controller, CPU, Control panel, Computer Board	Caterpillar Controller, CPU, Control panel, Computer Board	Caterpillar Controller, CPU, Control panel, Computer Board
E120B E200B	320A 320L E320 322L 322LN 322N	325A 325L 325 LN E330 E325	315 E315A
861-03705 E861-03705A	119-0609/ 106-0138 1190609/ 1060138	102-8012/ 106-0134 1028012/ 1060134	119-9971 1199971
CMPC-A005	CMPC-A006	CMPC-A007	CMPC-A008
Caterpillar Controller, CPU, Control panel, Computer Board	Caterpillar Controller, CPU, Control panel, Computer Board	Caterpillar Controller, CPU, Control panel, Computer Board	Caterpillar Controller, CPU, Control panel, Computer Board
330C 330CL 330CLN	E320B 320B	320B 320B L 320B N 320B S 325B 330B	330B L W330B E330B 312B
240-5313/ 157-3165 2405313/ 1573165	119-0607/ 119-0607X-00 177-7723	164-8261/ 164-8285 151-9293	164-8255/ 157-3207
CMPC-A009	CMPC-A010	CMPC-A011	CMPC-A012
Caterpillar Controller, CPU, Control panel, Computer Board	Caterpillar A/C panel, air conditioner controller	Caterpillar A/C panel, air conditioner controller	Caterpillar Lamp Controller
320D 312D 311D	E320D 320D	E320C 320C	320B 320C 320D
331-7539/ 221-8874 221-8874	293-1136/ 145670-350	157-3210/ 146432-822	155-7042/ 176810-0050
CMPC-A013	CMPC-A014	CMPC-A015	CMPC-A016
Caterpillar excavator controller connector plug wire harness	Caterpillar excavator controller connector plug wire harness	Caterpillar excavator controller connector plug wire harness	Caterpillar Head Lamp and Wiper Motor Controller
E320	E320B		320B 318C 320C 320D
			222-8183/ 111-4800X 70800-KS9011
CMPC-A017	CMPC-A018		
Caterpillar Head Lamp and Wiper Motor Controller	Caterpillar Head Lamp and Wiper Motor Controller		
E320C	311D 312D 320D		
163-6701	227-7575/ 191-6537		

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinocmp-daisy

### Caterpillar EXCAVATOR PARTS----Monitor LCD

CMPC-B001	CMPC-B002	CMPC-B003	CMPC-B004
			
Caterpillar Display Monitor Panel, Cluster Gauge panel	Caterpillar Display Monitor Panel, Cluster Gauge panel	Caterpillar Display Monitor Panel, Cluster Gauge panel	Caterpillar Display Monitor Panel, Cluster Gauge panel
311 312 315 315 L 320A E320A	312B 312B L 315B 325B 320B	E 320C 312C 322C 325C 330C	320D 320D L 320D LRR 320D RR 323D L 323D LN 323D S
7Y-5500	151-9385/ 106-0172 106-0176	157-3198/ 260-2160 177-7700	279-7611/ 227-7698 386-3457
CMPC-B005	CMPC-B006	CMPC-B007	CMPC-B008
			
Caterpillar Display Monitor Panel, Cluster Gauge panel	Caterpillar Display Monitor Panel, Cluster Gauge panel	Caterpillar Monitor LCD	Caterpillar Monitor LCD
320D	312D 315D L 319D 320D 325D 323D	311 312 315 315 L 320A E320A	312B 312B L 315B 325B 320B 330B
260-2193/ 327-7482	319-4353/ 319-4354 450-0714		
CMPC-B009	CMPC-B010	CMPC-B011	
			
Caterpillar Monitor LCD Module	Caterpillar Monitor LCD Module	Caterpillar Monitor Connector Cable	
E 320C 312C 322C 325C 330C	320D	E 320C 312C 330C 322C 325C	

### Caterpillar EXCAVATOR PARTS---Motor Parts

CMPC-C001	CMPC-C002	CMPC-C003	CMPC-C004
Caterpillar Motor Assy, Throttle Governor Motor, Accelerator	Caterpillar Motor Assy, Throttle Governor Motor, Accelerator	Caterpillar Motor Assy, Throttle Governor Motor, Accelerator	Caterpillar Motor Assy, Throttle Governor Motor, Accelerator
E 307A 307 E 307B 307B	E 307B 307B	E311 E313 E314	E320 E320A E320L E330L
111-5497/ 132-7818	102-8007		106-0092/ 7Y-3913 105-0092/ 7Y-5571/ 109-0092
CMPC-C005	CMPC-C006	CMPC-C007	CMPC-C008
Caterpillar Motor Assy, Throttle Governor Motor, Accelerator	Caterpillar Motor Assy, Throttle Governor Motor, Accelerator	Caterpillar Motor Assy, Throttle Governor Motor, Accelerator	Caterpillar Motor Assy, Throttle Governor Motor, Accelerator
E320A E320 E320L E312 E312A	E320 E325B E325L E325 E320 E320A E320L	312B 312BL E312B 320B 320B L	320C 320C L 320D 320D L
7Y-5559/ 4I-5496 7Y-3914/ 247-5227	7Y-5461/ 7Y-5558 106-0100	247-5231/ 247-5229 119-0633/ 120-0002	247-5212/ 247-5214 227-7672/ 227-7372
CMPC-C009	CMPC-C010	CMPC-C011	CMPC-C012
Caterpillar Motor Assy, Throttle Governor Motor, Accelerator	Caterpillar Motor Assy, Throttle Governor Motor, Accelerator	Caterpillar Motor Assy, Throttle Governor Motor, Accelerator	Caterpillar Motor Assy, Throttle Governor Motor, Accelerator
312C 312C L 318C 319C 320C	307C 308C 309C 311C 315C 324C 325C 329C 330C	320B 320B L 322B 325B L 325B 330B	E312B 312B E311B 311BL 322B 325B E330B
157-3177/ 247-5207 247-5211	164-8233/ 185-2481	247-5232/ 132-7778 241-5253	106-0126/ 139-3917 132-7776
CMPC-C013	CMPC-C014	CMPC-C015	CMPC-C016
Caterpillar Motor Assy, Throttle Governor Motor, Accelerator	Caterpillar Excavator Throttle Motor Single Cable	Caterpillar Excavator Throttle Motor Double Cable	Caterpillar Excavator Throttle Motor Single Cable
325BL E325BL E324BL	E320 E320A E320L E330L	E320A E320 E320L E312 E312A	307C 308C 309C 311C 315C 324C 325C 329C 330C
247-5234		157-3160	
CMPC-C017	CMPC-C018	CMPC-C019	CMPC-C020
Caterpillar Excavator Throttle Motor Double Cable	Caterpillar Throttle Drive Panel for Throttle Motor Assembly with 6 Lines	Caterpillar Throttle Drive Panel for Throttle Motor Assembly with 7 Lines	Caterpillar Throttle Drive Panel for Throttle Motor Assembly with 6 Lines
312C 312C L 318C 319C 320C 320C L 320D 320D L	E312B 312B E311B 311BL 320B 325B E330B	E320C 320C	E320

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinocmp-daisy

### Caterpillar EXCAVATOR PARTS---Motor Parts

CMPC-C021	CMPC-C022	CMPC-C023	CMPC-C024
			
Caterpillar Drive Panel Connector Plug Wire Harness 6 Holes	Caterpillar Drive Panel Connector Plug Wire Harness 8 Holes	Caterpillar Throttle Electric Motor, Accelerator	Caterpillar Throttle Knob, Fuel Dial
320B	320C	320 320B 320C 320D 330B	E320B E320C
CMPC-C025	CMPC-C026	CMPC-C027	CMPC-C028
			
Caterpillar Throttle Knob, Fuel Dial	Caterpillar Blower Motor 24V Long	Caterpillar Blower Motor 24V	Caterpillar Blower Motor 24V Long
E320	320 320A	320B	320C
	162500-7191	7I-6603	
CMPC-C029			
			
Caterpillar Blower Motor 24V			
320D 330D			
245-7839			

## Caterpillar EXCAVATOR PARTS---Sensor and switch

CMPC-D001	CMPC-D002	CMPC-D003	CMPC-D004
			
Caterpillar Excavator Throttle Motor Positioner Sensor, Fitting Sensor	Caterpillar Excavator Throttle Motor Positioner Sensor, Fitting Sensor	Caterpillar SENSOR AS-PRESSURE, Pressure Sensor 40MPa	Caterpillar SENSOR AS-PRESSURE, Oil Fuel Pressure Sensor
320B 320C 320D	315B E320B E320C	311D 312D 314D 320D	325D 330C E325D E330C
227-7658	247-5230/ 106-0107	260-2180	161-1705/ 161-1704
CMPC-D005	CMPC-D006	CMPC-D007	CMPC-D008
			
Caterpillar Water Temperature Sensor, Water Temperature Alarm	Caterpillar Water Temperature Sensor, Water Temperature Alarm	Caterpillar Water Temperature Sensor	Caterpillar Water Temperature Sensor
311C 312C 318B 318C E320B E320C	E330B	E200B	E320D 320D
5I-7578/ 34390-00800 297-9314	4I-5394	05204-50300	238-0112
CMPC-D009	CMPC-D010	CMPC-D011	CMPC-D012
			
Caterpillar Water Temperature Sensor	Caterpillar Excavator Water Temperature Sensor	Caterpillar Revolution Speed Sensor	Caterpillar SENSOR GROUP-SPEED, Revolution Speed Sensor
315C 317B 318B 320B E320C	E320C	E320C	317B 318B 320B 320C
135-2336	34390-02200	5I-7579	125-2966
CMPC-D013	CMPC-D014	CMPC-D015	CMPC-D016
			
Caterpillar SENSOR GROUP-SPEED, Revolution Speed Sensor	Caterpillar SENSOR GROUP-SPEED, Revolution Speed Sensor	Caterpillar ENGINE OIL PRESSURE, Engine Oil Pressure Sensor	Caterpillar SENSOR AS-PRESSURE, Hydraulic Pump Pressure Sensor
317B 318B 320B 320C	E330B E330	311C 312C 314C 312B 312B L 315B L 315C 317B L E320B	E320C 320C
196-7973	189-5746	266-6210/ 5I-8005 34390-40200	221-8859/ 106-0178 157-3182
CMPC-D017	CMPC-D018	CMPC-D019	CMPC-D020
			
Caterpillar SWITCH AS-PRESSURE, Pressure Switch Square Plug	Caterpillar SWITCH AS-PRESSURE, Pressure Switch Square Plug	Caterpillar SWITCH AS-PRESSURE, Pressure Switch Round Plug	Caterpillar SWITCH AS-PRESSURE, Pressure Switch Round Plug
312B 312B L 315B L E320B E320C	312B 315B L 317B 318B E320B E320C	E320A E312B E320B E320C	E320 311C 311D 312D 314C 314D
106-0180X02	106-0181	126-2938X03/ 106-0096	106-0180X03/ 309-5768

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinocmp-daisy

### Caterpillar EXCAVATOR PARTS----Sensor and switch

CMPC-D021	CMPC-D022	CMPC-D023	CMPC-D024
			
Caterpillar SWITCH AS-PRESSURE, Pressure Switch Square Plug 307B E330B E330C 345C 345C L 345D 345D L	Caterpillar SWITCH AS-PRESSURE, Pressure Switch Round Plug 307 312 315 317 330L	Caterpillar Oil Pressure Switch 325 BL E330B	Caterpillar SENSOR GROUP-PRESSURE, Oil Pressure Sensor Switch E330C
106-0179X03/ 309-5795	119-9985X01/ 20PS767-7	3E-6455	224-4536
CMPC-D025	CMPC-D026	CMPC-D027	CMPC-D028
			
Caterpillar SWITCH AS-LIQUID LEVEL, Oil Pressure Sensor Switch 320B 320C E320B E320C	Caterpillar SENSOR GROUP-PRESSURE, Oil Pressure Sensor Switch 320B 320C	Caterpillar SENSOR GROUP-PRESSURE, Oil Pressure Sensor Switch 311D 312D 314D 315D 319D	Caterpillar SENSOR GROUP-PRESSURE, GP Sensor
213-0677	216-8684	238-0118	274-6721/ 274-6720
CMPC-D029	CMPC-D030	CMPC-D031	CMPC-D032
			
Caterpillar Excavator Ignition Switch (two plugs)	Caterpillar Excavator Ignition Switch (three plugs)	Caterpillar Excavator Ignition Switch (four plugs)	Caterpillar Excavator Ignition Switch (five plugs)
7N-0718	7N-4160	E320C 9G-7641	E200B 0.00
CMPC-D033			
			
Caterpillar Excavator Ignition Switch (six plugs) 307 307B 307C 308C 311 311C 312 312B			
7Y-3918			



## Caterpillar EXCAVATOR PARTS---Wire harness

CMPC-E001	CMPC-E002	CMPC-E003	CMPC-E004
			
Caterpillar HARNESS AS-CHASSIS, External Outer Wiring Harness	Caterpillar ENGINE HARNESS ASSEMBLY, Engine Wire Harness	Caterpillar HARNESS ASSEMBLY, Engine Wire Harness	Caterpillar HARNESS AS-ENGINE, Engine Wire Harness
E320C	322C 325C	E330C 330C	320D E320D
186-4605HE01	195-7336	230-6279	296-4617
CMPC-E005	CMPC-E006	CMPC-E007	CMPC-E008
			
Caterpillar HARNESS ASSEMBLY, Engine Wire Harness	Caterpillar HARNESS ASSEMBLY, Engine Wire Harness	Caterpillar HARNESS ASSEMBLY-WIRING, Engine Wire Harness	Caterpillar Cylinder Line Wire Harness
324D 325D 326D 327D 328D 329D	330D 336D C9	330D 330D L 336D 336D L	330D 336D
198-2713/ 381-2499	235-8202	323-9140	419-0841
CMPC-E009	CMPC-E010	CMPC-E011	CMPC-E012
			
Caterpillar HARNESS ASSEMBLY, Wire Wiring Harness	Caterpillar Wire Harness ET14 Cable	Caterpillar HARNESS ASSEMBLY, Injector Wiring Harness	Caterpillar HARNESS ASSEMBLY-WIRING, Engine Wiring Harness
345C 345C L 345D 345D L		330D C7	324D C7 C9
219-7461	457-6114	215-3249	222-5917
CMPC-E013			
			
Caterpillar WIRING GROUP-ENGINE, Engine Wiring Harness			
322C 325C 325C L			
190-5038			

## Caterpillar EXCAVATOR PARTS---Main valve

CMPC-F001	CMPC-F002	CMPC-F003	CMPC-F004
			
Caterpillar VALVE GROUP-RELIEF, Main Valve, Main Relief Valve	Caterpillar VALVE GROUP-RELIEF, Main Valve, Main Relief Valve	Caterpillar VALVE GROUP-RELIEF, Main Valve, Main Relief Valve	Caterpillar Control Valve Oil Suck Valve
320 320 L 320N 322 325 330	E320B 312C	E330L	200B E200B
6I-6899/ 107-7033	171-0030		2111B-40184
CMPC-F005	CMPC-F006		
			
Caterpillar Main Valve, Main Relief Valve, Overflow Valve	Caterpillar Main Valve, Main Relief Valve		
E320	E320		

## Caterpillar EXCAVATOR PARTS----Solenoid valve

CMPC-G001	CMPC-G002	CMPC-G003	CMPC-G004
			
Caterpillar VALVE GROUP-SOLENOID, Rotating Rotary Solenoid Valve 12V	Caterpillar VALVE GROUP-SOLENOID, Rotating Rotary Solenoid Valve 12V	Caterpillar VALVE GROUP-SOLENOID, Rotating Rotary Solenoid Valve 12V	Caterpillar VALVE GROUP-SOLENOID, Rotating Rotary Solenoid Valve 12V
320 E320B E320C	320 E320B E320C	320D E320B E320C	320 E320B E320C
121-1491	121-1490	111-9916	116-3526
CMPC-G005	CMPC-G006	CMPC-G007	CMPC-G008
			
Caterpillar VALVE GROUP-SOLENOID, Hydraulic Pump Solenoid Valve 12V E320B E325C E320C E320D E325D E330D	Caterpillar VALVE GROUP-SOLENOID, Oil Pump Solenoid Valve	Caterpillar VALVE AS-SOLENOID, Main Pump Solenoid Valve	Caterpillar Hydraulic Pump Solenoid Valve
111-9916/ KDRDE5K-3140E30	3126 3126B C15 122-5053	330 350 375 139-3990/ 5I-8368	E3230 41-5674
CMPC-G009	CMPC-G010	CMPC-G011	CMPC-G012
			
Caterpillar Hydraulic Pump Solenoid Valve	Caterpillar Fuel Shutdown Solenoid, Stop Solenoid Valve, Shutoff Solenoid	Caterpillar Fuel Shutdown Solenoid, Stop Solenoid Valve, Shutoff Solenoid	Caterpillar Fuel Shutdown Solenoid, Stop Solenoid Valve, Shutoff Solenoid
E200B	330 330 L 330B L 350 24V/12V	E325 24V/12V	24V/12V
086-1879	155-4654/ 155-4653 3E-9785	155-4652/ 8C-3663	155-4651
CMPC-G013	CMPC-G014		
			
Caterpillar Fuel Shutdown Solenoid, Stop Solenoid Valve, Shutoff Solenoid	Caterpillar Fuel Shutdown Solenoid, Stop Solenoid Valve, Shutoff Solenoid		
E330 E330B E330C 24V/12V	24V 12V		
125-5771/ 125-5772 125-5773/ 125-5774	110-6465/ 110-6466 6T-4122/ 6T-4121		

## Caterpillar EXCAVATOR PARTS----Relay

CMPC-H001	CMPC-H002	CMPC-H003	CMPC-H004
			
MITSUBISHI Electric Relay 24V	MITSUBISHI Electric Relay 24V	Caterpillar TIMER AS, Time Relay	Caterpillar RELAY 24V
Kato CAT320C E320C	CAT320C 312C 330C E320C	311B 312B 312B L 320B E320B 325BL	320 320B 320C 320D
ME077148/ R8T30173	ME049233/ R8T30171	111-4870	111-4871X
CMPC-H005	CMPC-H006		
			
Caterpillar RELAY 24V	Caterpillar METER GROUP-SERVICE, Time Relay		
E320C E320D 320C 320D	320D		
161-3128X	285-9075		

### Caterpillar EXCAVATOR PARTS---Injector and turbocharger


CMPC-I001	CMPC-I002	CMPC-I003	CMPC-I004
			
Caterpillar INJECTOR GROUP-FUEL, Injectors ASSY	Caterpillar INJECTOR GROUP-FUEL, Injectors ASSY	Caterpillar FUEL INJECTOR GROUP, Injectors ASSY	Caterpillar FUEL INJECTOR GROUP, Injectors ASSY
CAT 320D C6 C6.4	311D 312D 314D 320D C4.2 C6 C6.4		C402
326-4700	326-4756	127-8216	
CMPC-I005	CMPC-I006	CMPC-I007	CMPC-I008
			
Caterpillar FUEL INJECTOR GROUP, Injectors ASSY	Caterpillar Diesel Engine Fuel Injector	Caterpillar FUEL INJECTOR GROUP, Injectors ASSY	Caterpillar FUEL INJECTOR GROUP, Injectors ASSY
3114 3116	3114 3116 3126	3116 3114	330C 330D C9
127-8207/ 127-8213 127-8218	387-9427/ 235-2888	127-8211/ 127-8228 127-8230/ 127-8222	236-0962/ 254-4339 387-9434
CMPC-I009	CMPC-I010		
			
Caterpillar Injector Sleeve	Caterpillar TURBOCHARGER GROUP,		
C-9	320B 320D		
227-1200	5I-8018/ 287-0049		

### Caterpillar EXCAVATOR PARTS----Seal kits

CMPC-J001	CMPC-J002	CMPC-J003	CMPC-J004
Caterpillar Arm Cylinder Seal Kit	Caterpillar Arm Cylinder Seal Kit	Caterpillar Arm Cylinder Seal Kit	Caterpillar Arm Cylinder Seal Kit
320B	320C	320D	E330B
CMPC-J005	CMPC-J006	CMPC-J007	CMPC-J008
Caterpillar Boom Cylinder Seal Kit	Caterpillar Travel Motor Seal Kit	Caterpillar Swivel Joint Seal Kit	Caterpillar Arm Cylinder Seal Kit
E70B	E70B	E120B	E120B
CMPC-J009	CMPC-J010	CMPC-J011	CMPC-J012
Caterpillar Boom Cylinder Seal Kit	Caterpillar Bucket Cylinder Seal Kit	Caterpillar Main Pump Seal Kit	Caterpillar Track Adjuster Seal Kit
E120B	E120B	E120B	E120B
CMPC-J013	CMPC-J014	CMPC-J015	CMPC-J016
Caterpillar Arm Cylinder Seal Kit	Caterpillar Boom Cylinder Seal Kit	Caterpillar Bucket Cylinder Seal Kit	Caterpillar Control Valve Seal Kit
E312	E312	E312	E312
CMPC-J017	CMPC-J018		
Caterpillar Main Pump Seal Kit	Caterpillar Track Adjuster Seal Kit		
E312	E312		

# Caterpillar EXCAVATOR PARTS----Hydraulic pump rebuild parts


CMPC-K001



SBS80 SBS120 SBS140  
drive shaft, swash plate, tiling pin, shoe plate, piston shoe, set plate, ball guide,

320C 325C E311C 311D E312C 312D  
cylinder block, valve plate, pin of swash plate, pin of shoe plate, coupling

CMPC-K002












CAT12G(PVH98)&14G(PVH131)&16G(PVH131)  
CAT120G(PVE35)&140G(PVE47)  
valve plate, cylinder block, fix plate, set plate, piston shoe, shoe plate

CAT 215 225 235 245  
drive plate(G-type), drive shaft(E-type)



### Kobelco EXCAVATOR PARTS----Monitor

CMPB-A001	CMPB-A002	CMPB-A003	CMPB-A004
			
Kobelco Gauge, Monitor Cluster	Kobelco Gauge, Monitor Cluster	Kobelco Gauge, Monitor Cluster	Kobelco Gauge, Monitor Cluster
SK100 SK100L SK120 SK120-V SK120-5 SK200-5 SK200LC-V SK100-2 SK200-2	SK330-6 SK200-6 SK210-6 SK250-6 SK200 mark VI	SK330-6E SK200-6E SK210-6E SK250-6E	SK200-6E SK230-6ESK250-6E
YN59S00002F2 YN59S00002F3 YN59S00002F4 YN59S00002F5	YN59E00004F1/2/3 YN59E00004F4/5/6 YN59E00002F1/2/3/4/5/6/7/8	YN59S00012F1 YN59S00012F2	YV59S00003F2 YV59S00009F1
CMPK-B005	CMPB-A006	CMPB-A007	CMPB-A008
			
Kobelco Gauge, Monitor Cluster	Monitor LCD, LCD, Kobelco LCD	Monitor LCD, LCD, Kobelco LCD	Monitor LCD, LCD, Kobelco LCD
SK200-8 SK210-8 SK230-8 SK250-8 SK350-8	SK-3 SK200-3 SK100-3 SK120-3	SK-2 SK-5 SK200-2 SK200-5 SK100-2 SK120-5	SK-6 SK-6E SK200-6 SK200-6E
YN59S00021F1 YN59S00021F2 YN59S00021F3			
CMPB-B009			
			
Monitor LCD, LCD, Kobelco LCD			
SK-2 SK-5 SK200-2 SK200-5 SK100-2 SK120-5			

### Kobelco EXCAVATOR PARTS----Controller

CMPB-B001	CMPB-B002	CMPB-B003	CMPB-B004
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
SK100-3 SK120-3 SK300-3 SK220-3 SK60-3	SK100-5 SK120-5 SK200-5 SK220-5	SK120-5 SK200-5 SK120LC-5	SK120-2 SK120-5
2480U371F2 2480U371F1 2480U371F3 2480U371F4	YN22E00013F4 YN22E00013F3 YN22E00013F2 YN22E00013F1	LP22E00004F2 LP22E00004F5	YW22E00007F1 YW22E00007F2 YW22E00007F3 YW22E00007F4
CMPB-B005	CMPB-B006	CMPB-B007	CMPB-B008
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
SK120-5 SK200-5 SK120LC-5	SK120-5 SK120-3	SK120-5 SK200-2 SK200-5 SK200-3	SK120-5 SK200-5 SK200-3
LP22E00006F1 LP22E00006F2 LP22E00006F3 LP22E00006F4	LP22E00020F1	YN22E00015F3 YN22E00015F1 YN22E00015F2	YN22E00020F1 YN22E00020F2 YN22E00020F3
CMPB-B009	CMPB-B010	CMPB-B011	CMPB-B012
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
sk200-3 SK120-3	sk200-3 sk220-3	SK200-6E SK210-6E SK230-6E SK300-6E	SK200-6 SK210-6 SK230-6 SK300-6
YN22E00041F2 YN22E00041F1 YN22E00041F3	YN22E00358F1=2480U332F6 2480U332F1/2/3/4/5/6/7/8/9 2480U332F10/11/12/13/14	YN22E00149F3 YN22E00149F2 YN22E00149F1	YN22E00037F6 YN22E00037F2 YN22E00037F3 YN22E00037F4 YN22E00037F5 YN22E00037F1
CMPB-B013	CMPB-B014	CMPB-B015	CMPB-B016
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
SK200-6 SK210-6 SK230-6 SK300-6	SK250-6	SK200-6 SK210-6 SK210LC-6 SK230-6 SK300-6 SK480-6	SK330-6 SK320-6
lq22e00031F1	LS22E00029F3 LS22E00029F2 LS22E00029F1	YN22E00069F1 YN22E00069F2 YN22E00069F3/4 YN22E00069F5/6	LC22E00009F6 LC22E00009F5 LC22E00009F4/3 LC22E00009F2/1
CMPB-B017	CMPB-B018	CMPB-B019	CMPB-B020
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
SK-6 SK250-6	SK330-6	SK-6	SK230-6E
LQ22E00024F1 LQ22E00024F2 LQ22E00024F3 LQ22E00024F4 LQ22E00024F5/6 LQ22E00024F7/8	LC22E00044F1 LC22E00044F2 LC22E00044F3 LC22E00044F4 LC22E00044F5 LC22E00044F6/7	YN22E00087F3 YN22E00087F2 YN22E00087F1	YN22E00123F1 YN22E00123F2 YN22E00123F3 YN22E00123F4 YN22E00123F5

EMAIL: [service@sinoamp.com](mailto:service@sinoamp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmparts.com](mailto:sales@cmparts.com)  
 Whatsapp: +8615328181468 +8613242057399 +8613434784596  
 Skype: Mou Mark(CMP) sinoamp-daisy



### Kobelco EXCAVATOR PARTS---Controller

CMPB-B021	CMPB-B022	CMPB-B023	CMPB-B024
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	
sk290-6e sk200-6e	sk210-6e sk200-6e	SK230-6E	SK250-6E
LB22E00007F1	YN22E00146F2=YN22E00146F1	YM22E00007F1	LQ22E00065F1
CMPB-B025	CMPB-B026	CMPB-B027	CMPB-B028
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU
SK200-8 SK210-8 SK250-8 SK330-8 SK350lc-8 sk250lc-8 sk260lc-8 sk210lc-8	SK200-8 SK250-8 SK330-8	SK200-8 SK210-8 SK240-8 SK250-8 SK290-8 SK330-8 SK450-8	SK200-8 SK210-8 SK240-8 SK250-8 SK290-8 SK330-8
YT22E00036F4	YN22E00354F3 YN22E00354F3 YN22E00354F5 YN22E00354F6 YN22E00354F7	YN22E00214F1	YN22E00193F1 YN22E00193F2 YN22E00193F3 YN22E00193F4 YN22E00193F5 YN22E00193F6
CMPB-B029	CMPB-B030	CMPB-B031	CMPB-B032
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	
SK200-8 SK210-8 SK240-8 SK250-8 SK290-8 SK330-8	SK200-8 SK210-8 SK240-8 SK250-8 SK290-8 SK330-8	SK330-6E SK350-6E SK450-6	
YN22E00234F1 YN22E00234F2 YN22E00234F3 YN22E00234F4 YN22E00234F5 YN22E00234F6	LQ22E00102F1 LQ22E00102F2 LQ22E00102F3	ME441124	YN02P00042F1 VH89661E0010 275800-4211
CMPB-B033	CMPB-B034	CMPB-B035	CMPB-B036
Controller Control Panel, ECU, CPU	Controller Control Panel, ECU, CPU	Kobelco Air Conditioner Control Panel	Kobelco Air Conditioner Control Panel
SK200-6 SK210-6 SK210LC-6 SK230-6 SK300-6 SK480-6	SK330-6E	SK200-6 SK200-6E SK330-6E	SK200-8 SK230-8 SK250-8 SK230-8 SK210-8 SK350-8
LQ22E00018F8 LQ22E00018F7 LQ22E00018F6 LQ22E00018F5 LQ22E00018F4 LQ22E00018F3/2	LC22E00048F1 LC22E00048F2	YN20M01299P1 51589-17530	51586-17813 YN20M01468P2 YN20M01468P1
CMPB-B037			
Module			
SS2B003			

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)  
 Whatsapp: +8615328181468 +8613242057399 +8613434784596  
 Skype: Mou Mark(CMP) sinocmp-daisy






**Kobelco EXCAVATOR PARTS----Solenoid valve**

CMPB-C001	CMPB-C002	CMPB-C003	CMPB-C004
			
Solenoid valve	Solenoid valve	Solenoid valve	Solenoid valve with screw
2436U1453S11	2436U1453S8	2436U1453F1 2436U1453F2 2436U1453F3	White plug 609-74211200
CMPB-C005	CMPB-C006	CMPB-C007	CMPB-C008
			
Pump solenoid valve	Pump solenoid valve	Pump solenoid valve	Pump solenoid valve
SK200-6E SK210-6E SK250-6E SK290-6E YN35V00041F1 KDRDE5K-31/30C50-102	SK200-8 SK210-8 SK250-8 SK260-8 SK350-8 YN35V00048F1 YN35V00048F2 YN35V00048F3 KDRDE5K-31/30C50-122 SKY5P-17-A	SK200-6E SK230-6E SK330LC-6E SK190-6E SK160-6E YB35V00003F1 KDRDE5K-31/3040-111	SK200-6E SK230-6E SK330LC-6E SK190-6E SK160-6E YB35V00005F1 KDRDE5K-31/30C50-107
CMPB-C009	CMPB-C010	CMPB-C011	CMPB-C012
			
Pump solenoid valve	Pump solenoid valve	Pump solenoid valve	Pump solenoid valve
SK200-6E SK230-6E SK330LC-6E SK190-6E SK160-6E YB35V00006F1 KWE5K-31/G24YA50	SK200-6 SK290-6 SK250-6 SK330-6 YN35V00018F1 YN35V00018F2 KDRDE5K-31/30C40-111	sk120-5 sk200-5 sk200-6 sk200-6e YN35V00019F1 KDRDE5K-31/30C40-101	SK-6/SK-6E SK200-3/ SK230-6/SK320-6 sk210-6E SK330-6E SK200-5 YN35V00020F1 KWE5K-31/G24DA40 KWE5K-31/G24D40
CMPB-C013	CMPB-C014	CMPB-C015	CMPB-C016
			
Pump solenoid valve	Pump solenoid valve	Pump solenoid valve	Pump solenoid valve
sk200-3 sk200-5 sk200-6 sk200-6e YN35V00021F1 KWE5K-31/G24YA40 KWE5K-31/G24Y40	SK200-8 SK210-8 SK250-8 SK260-8 SK350-8 YN35V00049F1 KDRDE5K-31/40C50-213	SK200-8 SK210-8 SK250-8 SK260-8 SK350-8 YN35V00050F1 KWE5K-31/G24DB50	SK200-8 SK210-8 SK250-8 SK260-8 SK350-8 YN35V00052F1 YN35V00052F2 KDRDE5K-31/30C50-123
CMPB-C017	CMPB-C018	CMPB-C019	CMPB-C020
			
Pump solenoid valve	Pump solenoid valve	Pump solenoid valve	Pump solenoid valve
SK200-6E/SK210-6E/SK230-6E/SL250-6E YT35V00013F1 YT35V00013F1 KWE5K-31/G24DA50	SK200-2 SK200-3 SK200-5 YN35V00004F1 KDRDE5K-20/30C12A-111	SK200-2 SK200-3 SK200-5 sk120-5 YN35V00004F2 KDRDE5K-20/30C12A-101	SK200-2 SK200-3 SK200-5 sk120-5 YN35V00005F1 KWE5K-20/G24D12A

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmparts.com](mailto:sales@cmparts.com)  
 Whatsapp: +8615328181468 +8613242057399 +8613434784596  
 Skype: Mou Mark(CMP) sinocmp-daisy



### Kobelco EXCAVATOR PARTS----Monitor

CMPB-C021	CMPB-C022	CMPB-C023	CMPB-C024
			
<p>Pump solenoid valve</p>	<p>Pump solenoid valve</p>	<p>solenoid valve Assy</p>	<p>SK-6 Solenoid valve plug</p>
<p>SK200-2 SK200-3 SK200-5 sk120-5</p>	<p>SK200-8 SK210-8 SK250-8 SK260-8 SK350-8</p>		
<p>YN35V00005F2 KWE5K-20/G24Y12A</p>	<p>YN35V00051F1 KWE5K-31/G24YB50</p>		
CMPB-C025			
			
<p>SK-8 solenoid plug</p>			

**Kobelco EXCAVATOR PARTS----sensor**

<p>CMPB-d001</p>	<p>CMPB-D002</p>	<p>CMPB-D003</p>	<p>CMPB-D004</p>
			
<p>kobelco Excavator Revolution Sensor,RMP sensor</p>	<p>kobelco Excavator Revolution Sensor,RMP sensor</p>	<p>Kobelco pressure sensor (3MPa)</p>	<p>Pressure: 3MPa</p>
<p>sk200-3 sk200-5 sk120-3 sk120-5</p>	<p>SK200-6 SK200-6E Engine: 6D34T</p>	<p>SK200-5</p>	
<p>VAMC845235 MC845235</p>	<p>VAMC849577 MC849577</p>	<p>YN52S00028P1=LC52S00013F1</p>	<p>YN52S00003P1</p>
<p>CMPB-D005</p>	<p>CMPB-D006</p>	<p>CMPB-D007</p>	<p>CMPB-D008</p>
			
<p>Pressure sensor: 3MPa</p>	<p>Pressure: 3MPa</p>	<p>Pressure: 3MPa</p>	<p>Pressure: 3MPa</p>
<p>sk170-8 sk210-8 sk200-8 sk250-8 SK350-8</p>	<p>SK190-6E SK200-6E SK160-6E SK210-6E SK250-6E SK290-6E</p>	<p>sk200</p>	
<p>LC52S00019P1</p>	<p>YX52S00010P1</p>	<p>LC52S00001P1 LC52S00001P3 LC52S00001P2</p>	<p>LS52S00019P2 LS52S00019P3</p>
<p>CMPB-D009</p>	<p>CMPB-D010</p>	<p>CMPB-D011</p>	<p>CMPB-D012</p>
			
<p>Pressure sensor: 3MPa</p>	<p>Pressure sensor: 3MPa</p>	<p>Pressure sensor: 3MPa</p>	<p>High Pressure sensor 50MPa</p>
<p>LC52S00013F1 YT13EO1082P1</p>	<p>SK100 SK120-5 SK200-5</p>	<p>YW52S00002P2 YW52S00002P3</p>	<p>LS52S00027P1 LS52S00027P2 LS52S00027P3 LS52S00027P4</p>
<p>CMPB-D013</p>	<p>CMPB-D014</p>	<p>CMPB-D015</p>	<p>CMPB-D016</p>
			
<p>High Pressure sensor 50MPa</p>	<p>High Pressure sensor 50MPa</p>	<p>High Pressure sensor 50MPa</p>	<p>High Pressure sensor 50MPa</p>
<p>SK-6E</p>	<p>SK-6E</p>	<p>LC52S00013F2</p>	<p>SK-8 SK170-8 SK200-8 sk210-8 sk350-8</p>
<p>LC52S00012P1</p>	<p>YY52S00033F1 YY52S00033F2 YY52S00033F3</p>	<p>YN52S00048P1</p>	
<p>CMPB-D017</p>	<p>CMPB-D018</p>	<p>CMPB-D019</p>	<p>CMPB-D020</p>
			
<p>High Pressure sensor 50MPa</p>	<p>High Pressure sensor 50MPa</p>	<p>Pressure: 4.9MPa Type: Negative pressure sensor</p>	<p>Pressure: 4.9MPa Type: Negative pressure sensor</p>
<p>sk120-5 sk200-5 sk200-6 sk200-6e sk200-8</p>	<p>LC52S00027P1</p>	<p>SK200-6 SK250-6 SK290-6 SK330-6</p>	<p>SK480-6E SK210-6 SK330-6E</p>
<p>LS52S00015P1</p>	<p>YN52S00016P1</p>	<p>YN52S00016P2</p>	<p>YN52S00016P3</p>

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)  
 Whatsapp: +8615328181468 +8613242057399 +8613434784596  
 Skype: Mou Mark(CMP) sinocmp-daisy



**Kobelco EXCAVATOR PARTS----sensor**

CMPB-D021	CMPB-D022	CMPB-D023	CMPB-D024
			
Pressure: 4.9MPa Type: Negative pressure sensor	Pressure sensor	Pressure sensor	Pressure sensor: 3MPa
SK200-6 SK210-6 SK230-6 SK250-6	SK135SRLC SK200SR SK250	SK135SRLC SK200SR SK250	SK200-3 SK200-5 SK200-6
LC52S00016P2 LC52S00016P3	LC52S00002P1 LC52S00002P2 LC52S00002P3 =LS52S00015P1	YY5200033F2 YY5200033F1	LC52S00019P1
CMPB-D025	CMPB-D026	CMPB-D027	CMPB-D028
			
LOW pressure switch	Kobelco Water Temperature Alarm Sensor (Double Pins)	kobelco Excavator Water Temperature Sensor Single Pin	kobelco Excavator Water Temperature Sensor
SK330LC-6E	SK200-6 6D31 6D34	SK200-6 6D31 6D34	sk200-6e
YX52S00012F1 YX52S00012F2 YX52S00012F3 YX52S00012F4 YX52S00012F1=YX52S00005P1	ME049265	ME039860	YT52S00001P1
CMPB-D029	CMPB-D030	CMPB-D031	CMPB-D032
			
Oil Pressure Sensor	Ignition key	Ignition key	Convert plug
SK200-3 SK200-5 SK200-6 SK200-6E	SK-1/2/3/5/6/6E	SK-8	sk-6 to sk-6E, SK200-6 to SK200-6E
VAME840219 ME840219	YN50S00026F1 YN50S00026F2 YN50S00026F3 YN50S00029F1 YN50S00002P1		
CMPB-D033			
			
Convert plug			
SK200-8 to sk200-6			



**Kobelco EXCAVATOR PARTS----relief valve, main valve**

CMPB-E001	CMPB-E002	CMPB-E003	CMPB-E004
			
verglow relief valve	overglow relief valve	Kobelco Main Relief Valve	Kobelco Main Relief Valve
SK120-5 SK200-5 SK200-6 SK230-6 SK200-6E SK230-6E SK250-6E	SK290-6E SK330-6E SK350-6E SK140LC-8	SK250-5 SK250-6	SK220-3 SK300-6 SK330LC-6 SK115DZ SK300-IV K912LC
YN22V00002F1 YN22V00002F2 YN22V00002F3	YN22V00002F4 YN22V00002F5 YN22V00002F6	2436R683F4 2436R683F3	2436R837F2 2436R837F1 2436R837F4 2436R837F3
CMPK-E005	CMPB-E006	CMPB-E007	
			
Kobelco Main Relief Valve	Kobelco Main Relief Valve	Kobelco Main Relief Valve	
SK200-6E SK230-6E SK250-6E SK330-6E SK250-8 SK460-8 SK480LC-8 R210-5	SK100-5 SK110-5	SK200-1 SK200-4	
YN22V00001F8 YN22V00001F3 YN22V00001F4 YN22V00001F5 YN22V00001F1/2 YN22V00001F6/7			

**Kobelco EXCAVATOR PARTS----Wire harness**

CMPB-F001	CMPB-F002	CMPB-F003	CMPB-F004
			
Hydraulic pump wire harness	Kobelco Wiring harness	Kobelco wiring harness	Kobelco engine wire harness
SK450-8 SK250-8	SK200-3	engine 6D34 Mitsubishi SK210-6E	sk210-8 sk200-8
		YN16E01021P1	LQ16E01015P1 YN13E01444P2 LQ16E00010F1
CMPK-F005	CMPB-F006	CMPB-F007	
			
Kobelco engine wire harness	Kobelco engine wire harness	Kobelco engine wire harness	
SK200-3	sk200-6E	sk200-6	

**Kobelco EXCAVATOR PARTS----Others**

<p>CMPB-G001</p>	<p>CMPB-G002</p>	<p>CMPB-G003</p>	<p>CMPB-G004</p>
 <p>Kobelco Excavator Console, Control Plate Switch Assy Panel</p> <p>SK200-3 SK100-3</p> <p>YN50E00001P5 YN17M00008F5 YN50E00001F1</p>	 <p>Kobelco Excavator Console, Control Plate Switch Assy Panel</p> <p>sk120-5 sk200-5</p> <p>YN17M00008F5 YN50E00001F3</p>	 <p>Kobelco Relay Assembly , Kobelco Fuse Assy</p> <p>SK200-8 SK230-8 SK250-8 SK230-8 SK210-8 SK350-8</p> <p>YY24E00008F2 YN24E00016F2 YN24E00016F1 YN24E00019F1 YN73E01024P2 YN73E01023P2</p>	 <p>kobelco Locking Key, Kobelco Excavator Lock Switch</p> <p>SK60-5 SK200-6 SK230-6</p> <p>YN50S01001P2</p>
<p>CMPB-G005</p>	<p>CMPB-G006</p>	<p>CMPB-G007</p>	<p>CMPB-G008</p>
 <p>kobelco Locking Key, Kobelco Excavator Lock Switch</p> <p>SK60-5</p> <p>YN50801001P2</p>	 <p>battery relay assembly</p> <p>2479R1470F1</p>	 <p>Battery Relay</p> <p>77279310 2479R1470F1 YT24S00001F1</p>	 <p>Relay</p> <p>VAME077148 ME077148 R8T30173</p>
<p>CMPB-G009</p>	<p>CMPB-G010</p>	<p>CMPB-G011</p>	<p>CMPB-G012</p>
 <p>Relay</p> <p>YN24S00008F1</p>	 <p>Relay</p> <p>YN24S00012P1</p>	 <p>water pump</p> <p>6D16T</p>	 <p>Turbocharger</p> <p>SK200-6E SK210-6E</p> <p>49185-01030</p>
<p>CMPB-G013</p>	<p>CMPB-G014</p>	<p>CMPB-G015</p>	<p>CMPB-G016</p>
 <p>kobelco regulator</p> <p>LC10C01002F2</p>	 <p>Pilot pump</p> <p>SK100-3-5 SK200-5 SK200-3</p>	 <p>Hour Meter</p>	 <p>electric motor clutch</p> <p>SK200-2 SK-2</p>
<p>CMPB-G017</p>	<p>CMPB-G018</p>	<p>CMPB-G019</p>	
 <p>throttle knob</p> <p>sk120-6 sk200-6</p> <p>YN52S00032P1</p>	 <p>throttle knob</p> <p>SK200-6 SK200-6E</p> <p>YN52S00009P1</p>	 <p>Injector</p> <p>sk200-8 sk210-8</p> <p>97095000-6353</p>	

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmparts.com](mailto:sales@cmparts.com)  
 Whatsapp: +8615328181468 +8613242057399 +8613434784596  
 Skype: Mou Mark(CMP) sinocmp-daisy

## Doosan Daewoo EXCAVATOR PARTS---Controller

CMPD-A001	CMPD-A002	CMPD-A003	CMPD-A004
			
Doosan Daewoo Controller, e-EPOS Controller SOLAR 230LC-V SOLAR 225LC-V SOLAR 225LC-V SOLAR 220LC-6	Doosan Daewoo Controller, e-EPOS Controller SOLAR 220LC-V	Doosan Daewoo Controller, e-EPOS Controller S225NLC-V	Doosan Daewoo Controller, e-EPOS Controller SOLAR 300LC-7A SOLAR 300LC-V
543-00055A/ 543-00055	2543-1035/ 2543-1035A	543-00089/ 543-00089A	543-00053C/ 543-00053A 543-00053B/ 543-00053
CMPD-A005	CMPD-A006	CMPD-A007	CMPD-A008
			
Doosan Daewoo Controller, e-EPOS Controller DX340LC	Doosan Daewoo Controller, e-EPOS Controller DX210W DX210	Doosan Daewoo Controller, EPOS-3 SOLAR 220LC-III S220LC-V	Doosan Daewoo Controller, Engine Throttle Controller SOLAR 340LC-7 SOLAR 340LC-V SOLAR 400LC-V SOLAR 230LC-V
K1007727A/ K1007727B K1007727/ 0819-0624-236	K1011284A/ K1011284B	2543-1025/ 2543-1025X	2543-1036/ 543-00074
CMPD-A009			
			
Doosan Daewoo PANEL AIRCON CONTROL, A/C Controller S220-V S220LC-V SOLAR 340LC-7 DH220-5 DH150-7 SOLAR 230LC-V, etc			
543-00049/ 543-00049A			

## Doosan Daewoo EXCAVATOR PARTS---Monitor and LCD

CMPD-B001	CMPD-B002	CMPD-B003	CMPD-B004
			
Doosan Daewoo PANEL, LCD GAUGE, Monitor Display	Doosan Daewoo PANEL, LCD GAUGE, Monitor Display	Doosan Daewoo PANEL, LCD GAUGE, Monitor Display	Doosan Daewoo PANEL, LCD GAUGE, Monitor Display
DH200-5 DH220-V DH290LC-5 DH130-V S220LC-V SOLAR 250LC-V, etc	DH225-7 DH300-7 DH220-7 OLAR 340LC-V SOLAR 155LC-V SOLAR	DX300LC DX520LC DX480LC DX340LC DX420LC DX255LC	DX140LC DX180LC DX255LC DX160LC
2539-1068/ 2539-1068A	539-00048/ 539-00048A/B/C/E/G	539-00076/ 539-00076A/B/C/E/G	539-00076G/ K1030180
CMPD-B005	CMPD-B006	CMPD-B007	CMPD-B008
			
Doosan Daewoo PANEL, LCD GAUGE, Monitor Display	Doosan Daewoo PANEL, LCD GAUGE, Monitor Display	Doosan Daewoo PANEL, LCD GAUGE, Monitor Display	Doosan Daewoo PANEL, LCD GAUGE, Monitor Display
DH-9 DX340	DX300 DX340LC	DX85R-3	DX140LC
300426-00164B/ 300426-00174 300425-00174	300426-00010B/ 300426-00202	300426-00134	300426-00007
CMPD-B009	CMPD-B010	CMPD-B011	
			
Doosan Daewoo LCD Screen	Doosan Daewoo LCD Screen	Doosan Daewoo LCD Screen	Doosan Daewoo Monitor Plug Wire Harness
DH225-7	DH-5 DH200-5	DH-7 DH200-7	DH225-7

## Doosan Daewoo EXCAVATOR PARTS---Motor Parts and Relay

CMPD-C001	CMPD-C002	CMPD-C003	CMPD-C004
			
Doosan Daewoo Engine Control Throttle Motor	Doosan Daewoo Engine Control Throttle Motor	Doosan Daewoo MOTOR E/G STOP, Engine Stop Motor	Doosan Daewoo Throttle Motor
DH220-5 SL220-V SOLAR 250LC-V SOLAR 290LC-V SOLAR 400LC-V	DH220-5 DH258-5 DH300-5 DH225-7 DH258-7 DH300-7, etc	DH220-5 DH225-7 S220LC-V	HD820R
2523-9014/ 2523-9015	523-00006	2523-9016	709-4500006
CMPD-C005	CMPD-C006	CMPD-C007	
			
Doosan Daewoo Blower Motor	Doosan Daewoo CONVERTER, DC-DC, Wiper Relay	Doosan Daewoo Controller, Starter Relay	
DH225/DH150/DH200/DH215/DH220/DH300-5 DH200/DH215/DH220-7	DH225-7 SOLAR 250LC-V	DH200-5 DH220-V DH220LC-V	
	2531-1003/ 2537-9008	2543-9015	

## Doosan Daewoo EXCAVATOR PARTS----Sensor and Switch





CMPD-D001	CMPD-D002	CMPD-D003	CMPD-D004
			
Doosan Daewoo Engine Speed Sensor	Doosan Daewoo Pressure Sensor	Doosan Daewoo Pressure Sensor 50Mpa	Doosan Daewoo Water Temperature Sensor
DH220-5 SOLAR 300LC-V SOLAR 130LC-V SOLAR 330LC-V, etc	DH220-5	SOLAR 140W-V SOLAR 330LC-V SOLAR 400LC-V	DH220-5 SOLAR 330-III SOLAR 280LC-III
2547-1015	8422627-500K	2547-9045/ 8Z12568-500k	2547-9038
CMPD-D005	CMPD-D006		
			
Doosan Daewoo Pressure Sensor Switch	Doosan Daewoo Ignition Switch		
DH220-6 SOLAR 330LC-V SOLAR 500LC-V DX210W, etc	DH220-5 DH220-7		
2549-9112			



## Doosan Daewoo EXCAVATOR PARTS---Main Valve and Solenoid

CMPD-E001	CMPD-E002	CMPD-E003	CMPD-E004
			
Doosan Daewoo Valve ASSY, Main Relief Control Valve	Daewoo Doosan Main Relief Control Valve	Daewoo Doosan Main Relief Control Valve	Daewoo Doosan Main Relief Control Valve
DH220-5 DH220-7 DH200-5 DH200-7 DH225-7	DH55 DH60-7	S220LC-V S220LC-5	DH55 DH60
2420-1225A			
CMPD-E005	CMPD-E006	CMPD-E007	CMPD-E008
			
Daewoo Doosan Main Relief Control Valve	Daewoo Doosan Main Relief Control Valve	Daewoo Doosan Main Relief Control Valve	Daewoo Doosan Main Relief Control Valve
DH55	DH80-7	DX55	DH220-5 DH220-6
CMPD-E009	CMPD-E010	CMPD-E011	CMPD-E012
			
Daewoo Doosan Main Relief Control Valve	Daewoo Doosan Solenoid Valve Magnetic Switch	Daewoo Doosan Solenoid Valve Coil	Daewoo Doosan Solenoid Valve Coil 24V
DH220-5	DH-5 DH-7	DH220-5	DH300
	301411-00030		

## Doosan Daewoo EXCAVATOR PARTS----Pump, Turbocharger, Condenser

CMPD-F001	CMPD-F002	CMPD-F003	CMPD-F004
			
<p>Daewoo Doosan DENSU Giga Condenser 24V</p>	<p>Daewoo Doosan Air Conditioner Pump</p>	<p>Daewoo Doosan Water Pump</p>	<p>Daewoo Doosan Turbo Turbocharger</p>
	<p>DH220-5</p>	<p>DH220-5</p>	<p>DL400</p>
<p>263500-0833/ 263500-0831 263500-0832/ 263500-0834</p>			<p>8609809.00</p>

## Doosan Daewoo EXCAVATOR PARTS---Wire harness

CMPD-G001	CMPD-G002	CMPD-G003	CMPD-G004
			
Daewoo Doosan Cabin Internal Wiring Harness	Daewoo Doosan Electrical Box Wiring Harness	Daewoo Doosan Switch Box Wiring Harness	Daewoo Doosan Monitor Connector Cable
DH200-7 DH225-7 DH300-7	DH200-7 DH225-7 DH300-7	DH200-7 DH225-7 DH300-7	DH200-7 DH225-7 DH300-7
530-00208E	530-00207B	530-00209	530-00231A
CMPD-G005	CMPD-G006	CMPD-G007	CMPD-G008
			
Daewoo Doosan Engine Wiring Harness	Daewoo Doosan Engine Wiring Harness	Daewoo Doosan Engine Wiring Harness	Daewoo Doosan Engine Wiring Harness
DH225-7	DH150-7	DH220-7	DH215-7
530Y00190B	530Y00475	530-00327A	
CMPD-G009	CMPD-G010	CMPD-G011	CMPD-G012
			
Daewoo Doosan Engine Wiring Harness	Daewoo Doosan Cabin Wiring Harness	Daewoo Doosan Cabin Wiring Harness	Daewoo Doosan Engine Wiring Harness
DH-9	DH60-7	DH220-5 DH300-5	DH300-5
310207-01123	530-00380B	2530-1604C	2530-1631B
CMPD-G013	CMPD-G014	CMPD-G015	
			
Daewoo Doosan Engine Wiring Harness	Daewoo Doosan External Wiring Harness	Daewoo Doosan Main Wiring Harness	
DH300-7	DH290LC DH300LC	DH-5	
530-00211A	530-001630J/ 2530-1630HG	2530-1607L/A/E/G/H	

## Doosan Daewoo EXCAVATOR PARTS----Seal Kit

CMPD-H001	CMPD-H002	CMPD-H003	CMPD-H004
			
Daewoo Doosan Arm Cylinder Seal Kit	Daewoo Doosan Boom Cylinder Seal Kit	Daewoo Doosan Bucket Cylinder Seal Kit	Daewoo Doosan Arm Cylinder Seal Kit
S220LC-3	S220LC-3	S220LC-3	S220LC-5
CMPD-H005	CMPD-H006	CMPD-H007	CMPD-H008
			
Daewoo Doosan Boom Cylinder Seal Kit	Daewoo Doosan Bucket Cylinder Seal Kit	Daewoo Doosan Swing Cylinder Seal Kit	Daewoo Doosan Bucket Cylinder Seal Kit
S220LC-5	S220LC-5	S220LC-5	SL220LC-5
CMPD-H009			
			
Daewoo Doosan Arm Cylinder Seal Kit			
DH290-5			

### Doosan Daewoo EXCAVATOR PARTS---Others

CMPD-I001	CMPD-I002	CMPD-I003	CMPD-I004
			
Daewoo Doosan Fuse Box	Daewoo Doosan Fuse Box	Daewoo Doosan Matiz	Daewoo Doosan Chain Nozzle
DH60-7 SOLAR 75-V	DH215-5 SOLAR 230LC-V SOLAR 300LC-V		DH55
K1001468	2510-1010		
CMPD-I005	CMPD-I006	CMPD-I007	CMPD-I008
			
Daewoo Doosan Chain Nozzle	Daewoo Doosan Chain Nozzle	Daewoo Doosan Cylinder Bed	Daewoo Doosan Special Square Lamp
DH220	B21204	DH220-3	DH220-5 R200
CMPD-I009	CMPD-I010	CMPC-G011	CMPC-G012
			
Daewoo Doosan Bullet 10CM/12CM	Daewoo Doosan Timer	Daewoo Doosan Hour Meter	Daewoo Doosan Fuel Tank Float
DH220-5	DH220-5		
CMPC-G013			
			
Daewoo Doosan Throttle knob			

## SUMITOMO EXCAVATOR PARTS---Controller




CMPS-A001	CMPS-A002	CMPS-A003	CMPS-A004
			
Sumitomo Excavator Controller Computer Board ECU	Sumitomo Excavator Controller Computer Board ECU	Sumitomo Excavator Controller Computer Board ECU	Sumitomo Excavator Controller Computer Board ECU
SH120-1 SH120-2 SH120 SH120LC A1 A2	SH210-1 SH210-2 SH210A1 A2	SH300-1 SH300-2 SH300A1 SH300A2	SH200
KHR1785	KHR1794	KHR1784 KHR1788	KHR1790
CMPS-A005	CMPS-A006	CMPS-A007	CMPS-A008
			
Sumitomo Excavator Main Controller Computer Board VECU	Sumitomo Excavator Main Controller Computer Board VECU	Sumitomo Excavator Main Controller Computer Board VECU	Sumitomo Excavator Main Controller Computer Board VECU
SH120-3 SH200-3 SH210-3 SH300-3 A3	SH120-3 SH200-3 SH210-3 SH300-3 A3		
KHR2680 KRH1571 407915-4690	KHR1335 407915-3310 407915-0930	KNH0895 KNH10010 407915-5510 407915-2970	KHR10023 KRH1436 407915-2600
CMPS-A009	CMPS-A010	CMPS-A011	CMPS-A012
			
Sumitomo Excavator Main Controller Computer Board VECU	Sumitomo Excavator Main Controller Computer Board VECU	Sumitomo Excavator Main Controller Computer Board VECU	Sumitomo Excavator Main Controller Computer Board VECU
SH120-3 SH200-3 SH210-3 SH300-3 A3	SH120-5 SH120A5	SH210-5 SH350-5	SH280-5
KRH10750 KRH10660 407915-5810 407915-5640	KHR1782	KHR10031 07G0R0446 KHR10025	KHR10031
CMPS-A013	CMPS-A014	CMPS-A015	CMPS-A016
			
Sumitomo Excavator Main Controller Computer Board VECU	Sumitomo Excavator Main Controller Computer Board VECU	Sumitomo Excavator Main Controller Computer Board VECU	Sumitomo Excavator Main Controller Computer Board VECU
SH210-5 SH350-5	SH210-3	SH350	SH350
KHR10029(A) 9CG0L257	KRH1335	KHR1783	KHR1783
CMPS-A017	CMPS-A018	CMPS-A019	CMPS-A020
			
Sumitomo Excavator Engine Controller	Sumitomo Motor Driver Controller Panel	Sumitomo Excavator Wiper Motor Controller	Sumitomo Excavator Controller
SH210-5	A1 A2 SH280-2 SH280-1 SH300-1 SK300-2 SH120 SH120-1 SH120-2 SH160	SH350-5 SH200-3	SH220
8-98126057-0 KSH18223	KHR1347	KRH10750 176810-0070	KHR3314

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596





Skype: Mou Mark(CMP) sinocmp-daisy

## SUMITOMO EXCAVATOR PARTS---Controller







CMPS-A021	CMPS-A022	CMPS-A023
		
Sumitomo Air Conditioner Control Panel	Sumitomo Motor Driver Controller Panel	Sumitomo Excavator Controller Wire Harness Connector
SH210 SH200 SH210-5	SH350A1	
KHR12512 51586-17742	KHR1885	



## SUMITOMO EXCAVATOR PARTS----Monitor

CMPS-B001	CMPS-B002	CMPS-B003	CMPS-B004
			
<p>Sumitomo Excavator Monitor Display Panel Gauge Panel</p>	<p>Sumitomo Excavator Monitor Display Panel Gauge Panel</p>	<p>Sumitomo Excavator Monitor Display Panel Gauge Panel</p>	<p>Sumitomo Excavator Monitor LCD</p>
<p>Sumitomo A1 A2</p>	<p>Sumitomo A5</p>	<p>Sumitomo A3</p>	<p>Sumitomo A1 A2</p>
<p>KHR2125</p>			

## SUMITOMO EXCAVATOR PARTS---Motor

CMPS-C001	CMPS-C002	CMPS-C003	CMPS-C004
			
Sumitomo Excavator Throttle Motor 9 lines/cable	Sumitomo Excavator Throttle Motor 9 lines/cable	Sumitomo Excavator Throttle Motor 12 lines/cables	Sumitomo Excavator Throttle Motor 9 lines/cable
SH200-A1 SH200-A2 SH120-A1 SH120-A2	SH100-A1 SH100-A2 SH280-3	SH200-A1 SH200-A2 SH120-A1 SH120-A2 SH100-A1 SH100-	SH280-3
KHR1713	KHR1346	KHR1290 KHR1346	1713-30020
CMPS-C005	CMPS-C006		
			
Sumitomo Excavator Wiper Motor	Sumitomo Excavator Accelerator		
	Sumitomo A1 A2		

### SUMITOMO EXCAVATOR PARTS----Sensor and Switch

CMP5-D001	CMP5-D002	CMP5-D0013	CMP5-D004
			
Sumitomo Excavator Revolution Speed Sensor	Sumitomo Excavator Water Temperature Sensor	Sumitomo Excavator Water Temperature Sensor(2pins, 3pins)	Sumitomo Excavator Low Pressure Sensor Negative Pressure Sensor
SH120-A1 SH120-A2 SH120-A3 SH120A1 SH120A2	SH120-3 SH200-3 SH210-3 SH240-3 SH250-3	Sumitomo A3	Sumitomo A1 A2 A3
KRH0964 1-81510513-0	KHR1017 1-82410170-1		KHR10290 KM15-P02 KM16-P02
CMP5-D005	CMP5-D006	CMP5-D007	CMP5-D008
			
Sumitomo Excavator High Pressure Sensor	Sumitomo Excavator Low Pressure Sensor Negative Pressure Sensor	Sumitomo Excavator High Pressure Sensor	Sumitomo Excavator Pressure Sensor
Sumitomo A1 A2 A3	SH200-3 SK350-3	CX210 CX240 SH210LC-5 SH330LC-5 SH300-A3 SH220-3 SH200	Sumitomo A1 A2
KM16-P03	KHR2915	KHR2914	KHR10800
CMP5-D009	CMP5-D010	CMP5-D011	CMP5-D012
			
Sumitomo Excavator Pressure Sensor	Sumitomo Excavator Oil Pressure Sensor	Sumitomo Excavator Pressure Sensor	Sumitomo Excavator Tank Float Oil Level Sensor
KHR24020			
CMP5-D013	CMP5-D014	CMP5-D015	CMP5-D016
			
Sumitomo Excavator Crankshaft Position Sensor	Sumitomo Excavator Ignition Switch	Sumitomo Excavator Ignition Switch	Sumitomo Excavator Low Pressure Sensor Plug
	Sumitomo A1 A2 A3	Sumitomo A1 A2 A3	SH200A1A2A3







## SUMITOMO EXCAVATOR PARTS---Main Valve

CMPS-E001	CMPS-E002	CMPS-E003	CMPS-E004
			
Sumitomo Excavator Main Relief Valve	Sumitomo Excavator Main Relief Valve	Sumitomo Excavator Main Relief Valve	Sumitomo Excavator Main Relief Valve
HD800 HD900 SH200A1A2	HD700-7	E200B SH280	HD700
CMPS-E005	CMPS-E006	CMPS-E007	CMPS-E008
			
Sumitomo Excavator Main Relief Valve	Sumitomo Excavator Main Relief Valve	Sumitomo Excavator Main Relief Valve	Sumitomo Excavator Main Relief Valve
HD700-7	HD820	SH280	CMPS-F001 SH120A1
CMPS-E009	CMPS-E010		
			
Sumitomo Excavator Main Relief Valve	Sumitomo Excavator Main Relief Valve		
SH280-2/3	SH200A3		

## SUMITOMO EXCAVATOR PARTS----Solenoid Valve

CMPS-F001	CMPS-F002	CMPS-F003	CMPS-F004
			
Sumitomo Excavator Solenoid valve	Sumitomo Excavator Hydraulic Pump Solenoid Valve	Sumitomo Excavator Solenoid Coil	Sumitomo Excavator Stop Solenoid Valve
SH200A2 SH215UA2	SH200-2	SH200-A1 SH200-A2	
KHJ1364		LNC0205	A036-3175
CMPS-F005	CMPS-F006	CMPS-F007	CMPS-F008
			
Sumitomo Excavator Solenoid valve	Sumitomo Excavator Proportional Solenoid Valve	Sumitomo Excavator Solenoid Valve	Sumitomo Excavator Solenoid valve Connector
SH200 A3		SH350-3 SH350A3	
		LL001140	
CMPS-F009			
			
Sumitomo Excavator Solenoid valve Connector			

## SUMITOMO EXCAVATOR PARTS----Others

CMPS-G001	CMPS-G002	CMPS-G003	CMPS-G004
			
Sumitomo Excavator Wiring Harness	Sumitomo Excavator Wiring Harness	Sumitomo Excavator Electric Pump	Sumitomo Excavator Relay
SH240-5	SH240-5		
KRH10740	KRR12930		
CMPS-G005	CMPS-G006		
			
Sumitomo Excavator Hand Control Lever	Sumitomo Excavator Bullet		

## Hyundai EXCAVATOR PARTS---Controller

CMPR-A001	CMPR-A002	CMPR-A003	CMPR-A004
			
Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box
Robex R130LC-1(E) R130-5	R130-5 R210LC-7H R220LC-7H R210-7	R130LC-3	Robex R250LC-3
21E6-20600 (DC)	21N6-20021/ 21N6-20020	21E6-32110	21EN-32110
CMPR-A005	CMPR-A006	CMPR-A007	CMPR-A008
			
Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box
Robex R210LC-3(E) R210-3	Robex R180LC-3 (E)	R130W-3	Robex R210LC-3(E) R210-3
21EM-32131/ 21EM-32133 (DC)	21EL-32143 (DC)	21EA-32112	21EM-32150
CMPR-A009	CMPR-A010	CMPR-A011	CMPR-A012
			
Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box
Robex R220LC-3	Robex R250LC-3	Robex R80-7	R210-7
21EM-30111	21EN-32110	21N1-32101	21N1-32101
CMPR-A013	CMPR-A014	CMPR-A015	CMPR-A016
			
Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box
Robex R180LC-7	Robex R110-7 RX110LC-7 R335-7	R290-7	Robex R3000LC-7
21N5-32100	21N3-32300/ 21N7-32600 21N9-32600	21N8-32102	21N8-32206
CMPR-A017	CMPR-A018	CMPR-A019	CMPR-A020
			
Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box
Robex R290NLC-7 R290-7 RX305-7	Robex R110LC-7	Robex R305LC-7	Robex R290LC-7
21N8-32300/ 21N8-32600	21N3-32102/ 21N8-32401	21N8-32402	21N8-32500

EMAIL: [service@sino cmp.com](mailto:service@sino cmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sino cmp-daisy



## Hyundai EXCAVATOR PARTS---Controller

CMPR-A021	CMPR-A022	CMPR-A023	CMPR-A024
Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box
Robex R210-7 R210LC-7E	Robex RX215-7	Robex RX215-7	Robex RX215-7
21N6-33100/01	21N6-32502	21N6-32504	21N6-32503
CMPR-A025	CMPR-A026	CMPR-A027	CMPR-A028
Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box
Robex R200W-7	Robex RX215-7C	R210LC-7 Robex210LC-7E R225-7	Robex RX215-7C
21N6-32410	21N6-43101	21N6-42101/ 21N6-42102	21N6-43100
CMPR-A029	CMPR-A030	CMPR-A031	CMPR-A032
Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box
Robex RX225-7 R225LC-7	RX220LC-7 R305-7 R335-7 210-7 225-7 265-7	R140W-7	R500LC-7A
21N6-44100	21N6-44101	21N4-32300	21NB-33001
CMPR-A033	CMPR-A034	CMPR-A035	CMPR-A036
Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU MCU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box
ROBEX	R290LC-7E R290LC-7	R210LC-9	R210LC-3E
21EA-31150	21N8-32302	21Q6-32105/ 21Q6-32102	21EM-32132
CMPR-A037	CMPR-A038	CMPR-A039	CMPR-A040
Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai CPU ECU Controller, Control Panel, Computer Box
R140-9	R220LC-9S/ R300LC-9	RX385LC-9(T2)	R330LC-9S
21Q4-32811	21Q6-32180	21QA-32300	21Q9-32180

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinocmp-daisy

## Hyundai EXCAVATOR PARTS---Controller

CMPR-A041	CMPR-A042	CMPR-A043	CMPR-A044
			
Hyundai CPU ECU Controller, Control Panel, Computer Box	Hyundai Air Conditioner Control Panel A/C Controller 24V	Hyundai Air Conditioner Control Panel A/C Controller 24V	Hyundai Wiper Motor Controller
R260LC-9S	R210-7 R 210LC-7 R225-7 R250LC-7 R290LC-7 RX215-7	R220-9S R210-9 R140LC-9 R160LC-9 R180LC-9 R210LC-9	R110-7 R110-7A R140LC-7 R140LC-7A R140LC-9 R145CR-9 R160LC-7
21Q7-32110	11N6-90031	11Q6-90310	21N6-01272/ 21N6-01270







## Hyundai EXCAVATOR PARTS---Monitor

CMPR-B001	CMPR-B002	CMPR-B003	CMPR-B004
			
Hyundai Cluster Assy Monitor Display Panel	Hyundai Cluster Assy Monitor Display Panel	Hyundai Cluster Assy Monitor Display Panel	Hyundai Cluster Assy Monitor Display Panel
Robex160-3 R160LC-3 R220-3 R200-3	Robex R220-5 R130-5 R160LC-3	R140LC-7 R160LC-7 R180LC-7 R210LC-7 R-7	Robex R220-9S R210-9 R220-9 R520LC-9 R-9
21E6-00200/ 21E6-00201 21M6-53100	21EN-00200/ 21EN-00200-AS	21E8-30013/ 21N8-30015/ 21N8-30016 21N8-30013/ 21N6-30010/ 21N8-36001	21Q6-30104/ 21Q6-30103 21Q6-30400/ 21Q6-33400

## Hyundai EXCAVATOR PARTS---Motor parts

CMPR-C001	CMPR-C002	CMPR-C003	CMPR-C004
			
Hyundai Accel Actuator/ Stepping Motor/ Throttle Motor/ Governor Motor	Hyundai Accel Actuator/ Stepping Motor/ Throttle Motor/ Governor Motor	Hyundai Accel Actuator/ Stepping Motor/ Throttle Motor/ Governor Motor	Hyundai Accel Actuator/ Stepping Motor/ Throttle Motor/ Governor Motor
R110-7 R215-7 R210LC-7H R220LC-7H R225-7	R130-5 R220-5 R215-7 R215-9 R220-7	R220-5 R225-5 short cable	R220-7 R225-7 R130-5 R220-5 R320LC-7
21EN-32260	11E9-62010	21EN-32220	21EN-32200
CMPR-C005	CMPR-C006	CMPR-C007	CMPR-C008
			
Hyundai Accel Actuator/ Stepping Motor/ Throttle Motor/ Governor Motor	Hyundai Accel Actuator/ Stepping Motor/ Throttle Motor/ Governor Motor	Hyundai Accel Actuator/ Stepping Motor/ Throttle Motor/ Governor Motor	Hyundai Accel Actuator/ Stepping Motor/ Throttle Motor/ Governor Motor
R210-7 R215-7 R220-7 R225-7	R300LC-9S R330LC-9S R380LC-9S	R140W-7 R140LC-7 R210LC-7H	R290LC-7H R150-7 R80-7
21EN-32300	21EN-32360/ 21EN-32380	21EN-22260	21EN-32240
CMPR-C009	CMPR-C010	CMPR-C011	CMPR-C012
			
Hyundai Accel Actuator/ Stepping Motor/ Throttle Motor/ Governor Motor	Hyundai Accel Actuator/ Stepping Motor/ Throttle Motor/ Governor Motor	Hyundai Square Short Line 2.3M Throttle Cable	Hyundai Square Long Line 3.3M Throttle Cable
R225-9 R275-9	R210LC-3	R215-7	R215-7
21EN-32340	11E9-60010		
CMPR-C013			
			
Hyundai T Square Short Line 2.3M Throttle Cable	Hyundai Blower Motor, MOTOR ASSY		
R225-9	R210LC-7 R200-7		

## Hyundai EXCAVATOR PARTS---Main Valve and Solenoid

CMPR-D001	CMPR-D002	CMPR-D003	CMPR-D004
			
Hyundai Excavator Main Control Valve , Relief Valve	Hyundai Excavator Main Control Valve , Relief Valve	Hyundai Excavator Solenoid Valve Coil Round	Hyundai Excavator Solenoid Valve Coil Square
R130	R450-3	R210-5	R210-5
CMPR-D005	CMPR-D006		
			
Hyundai Excavator Solenoid Valve	Hyundai Excavator Solenoid Valve Coil 24V		
R215-7	R215-7		
KDRDE5K-20 40C07-109 SKX5P-17-208			





## Hyundai EXCAVATOR PARTS---Sensor and Switch

CMPR-E001	CMPR-E002	CMPR-E003	CMPR-E004
			
Hyundai Excavator Ignition Switch	Hyundai Excavator Ignition Switch	Hyundai Excavator Throttle Knob Touch Switch	Hyundai Excavator Pressure Sensor
R150-7 R210-7 R215-7 R220-7	R220-5 R220-7	R140LC-7 R160LC-7 R180LC-7 R210LC-7	R225-7
	21N4-10400/ 21N4-10430	21N8-20505/ 21N8-20506	31Q4-40800/ 31Q4-40600
CMPR-E005	CMPR-E006		
			
Hyundai Excavator Pressure Sensor	Hyundai Excavator Pressure Sensor		
R140W-9			
31Q4-40820/ 31Q4-40610	31Q4-40830/ 31Q4-40620		

## Hyundai EXCAVATOR PARTS---Seal Kit










CMPR-F001	CMPR-F002	CMPR-F003	CMPR-F004
			
Hyundai Arm Cylinder Seal Kit	Hyundai Arm Cylinder Seal Kit	Hyundai Boom Cylinder Seal Kit	Hyundai Control Valve Seal Kit
R210LC-7	R210-3 R210LC-3 (E)	R210-3 R210LC-3 (E)	R210LC-7
CMPR-F005	CMPR-F006	CMPR-F007	CMPR-F008
			
Hyundai Swing Motor Seal Kit	Hyundai Arm Cylinder Seal Kit	Hyundai Boom Cylinder Seal Kit	Daewoo Doosan Bucket Cylinder Seal Kit
R210-7 R215-7	R250LC-3 R250-3	R250LC-3 R250-3	R250LC-3 R250-3
CMPR-F009			
			
Hyundai Swing Motor Seal Kit	Hyundai Arm Cylinder Seal Kit	Hyundai Boom Cylinder Seal Kit	
R250LC-3 R250-3	R290LC-7	R290LC-7	

## Hyundai EXCAVATOR PARTS---Others

CMPR-G001	CMPR-G002	CMPR-G003	CMPR-G004
			
<p>Hyundai Hydraulic Oil Gauge Ruler</p>	<p>Hyundai Diesel Tank Cap</p>	<p>Hyundai Fuel Filler Pump</p>	<p>Hyundai Joystick Pusher</p>
<p>R140-7 R110-7 R140LC-9 R145CR-9</p>	<p>E215-7 R150-9 R215-9</p>	<p>R110-7 R140LC-7 R140LC-7A R160LC-7</p>	<p>R210-7</p>
<p>E131-0473</p>	<p>31Q4-02130</p>	<p>21N6-20311</p>	



## KATO EXCAVATOR PARTS---Controller

CMPT-A001	CMPT-A002	CMPT-A003	CMPT-A004
			
Kato Excavator VECU Controller, Control Panel, Computer Board	Kato Excavator VECU Controller, Control Panel, Computer Board	Kato Excavator VECU Controller, Control Panel, Computer Board	Kato Excavator Controller, Main CPU, Small
HD820-2 HD820-II	HD820-3 HD820-III	HD820-2 HD820-3	HD820-3
1001-14967	709-62000010	1004-00332	709-98400001
CMPT-A005	CMPT-A006	CMPT-A007	CMPT-A008
			
Kato Excavator Controller, Control Panel, Computer Board	Kato Excavator Controller, Control Panel, Computer Board	Air Conditioner Controller, Control Panel	Kato Excavator Controller Connector
HD450-7	HD450-5		HD820
CMPT-A009			
			
Kato Excavator Controller Connector			
HD820			

## KATO EXCAVATOR PARTS---Monitor

CMPT-B001		CMPT-B002		CMPT-B003		CMPT-B004	
							
Kato Excavator Monitor LCD, Display Panel, Gauge Panel		Kato Excavator Monitor LCD, Display Panel, Gauge Panel		Kato Excavator Monitor LCD, Display Panel, Gauge Panel		Kato Excavator Monitor LCD, Display Panel, Gauge Panel	
HD820-2 HD820-II		HD820-3 HD820-III		HD450-5		HD510-II HD510-III HD1430 HD2045 HD1023	
1108-00380		709-61601101		002-14967		002-14967	
CMPT-B005		CMPT-B006		CMPT-B007		CMPT-B008	
							
Kato Excavator Monitor LCD, Display Panel, Gauge Panel		Kato Excavator Monitor LCD, Display Panel, Gauge Panel		Kato Excavator Monitor LCD, Display Panel, Gauge Panel		Kato Excavator Monitor LCD	
HD820-2 HD820 HD820-3 HD820-II HD512 HD512-II HD512-III		HD820-3 HD1430-3		HD820-5 HD1023-5		HD820	
CMPT-B009		CMPT-B010					
							
Kato Excavator Monitor LCD		Kato Excavator Monitor Sticker		Kato Excavator Monitor Connector			
HD820-3		HD820-3 HD820-3 HD1430-3		HD820 820-1 820-2 820-3			

## KATO EXCAVATOR PARTS---Valve

CMPT-C001	CMPT-C002	CMPT-C003	CMPT-C004
			
Kato Excavator Main Relief Control Valve	Kato Excavator Suction Valve	Kato Excavator Main Relief Control Valve	Kato Excavator Main Relief Control Valve
HD800 HD900 HD1250-5 HD1250-7 SH200A1A2	DH220-5 DH225-7 R225-7 HD820 HD820-2 HD820-3 SH120 SH220-5 EC210/240		HD700 R200-5
CMPT-C005	CMPT-C006	CMPT-C007	CMPT-C008
			
Kato Excavator Main Relief Control Valve	Kato Excavator Main Relief Control Valve	Kato Excavator Main Relief Control Valve	Kato Excavator Main Relief Control Valve
HD700-5 HD700-7 HD800	HD700-7	HD400 HD450 HD500 -5 -7	HD700-5 HD700-7
	669-1365-1003		
CMPT-C009	CMPT-C010	CMPT-C011	CMPT-C012
			
Kato Excavator Main Relief Control Valve	Kato Excavator Main Relief Control Valve	Kato Excavator Main Relief Control Valve	Kato Excavator Main Relief Control Valve
EX200-5 EX60 ZX200 SH200A3 SH280-2 SH280-3 R225-7 CASE360 HD820 HD512	HD512 HD820 SH350/120-1/2	HD450	HD250 250-7
4372038.00			
CMPT-C013	CMPT-C014	CMPT-C015	
			
Kato Excavator Fuel Flameout Solenoid Valve	Kato Excavator Solenoid Valve	Kato Excavator Solenoid Valve	
HD800 HD900 HD250 HD450	HD820		
053400-1461	KWE5K-20_G24D05	KWE5K-20_G24Y05	

## KATO EXCAVATOR PARTS---Motor parts

CMPT-D001	CMPT-D002	CMPT-D003	CMPT-D004
			
Kato Excavator Throttle Motor	Kato Excavator Throttle Knob	Kato Excavator Throttle Motor	Kato Excavator Starting Motor
HD820		HD700-5/7	
709-4500006			
CMPT-D005	CMPT-D006	CMPT-D007	
			
Kato Excavator Throttle Motor Cable	Kato Excavator Throttle Motor Cable	Kato Excavator Blower Motor	
HD820	DH220-5		








## KATO EXCAVATOR PARTS---Switch, Sensor, replay

CMPT-E001	CMPT-E002	CMPT-E003	CMPT-E004
			
Kato Excavator Ignition Switch	Kato Excavator Relay	Kato Excavator Relay	Kato Excavator Relay
HD700-5 HD700-7 HD800		HD700	
	R8T30173		ME049233
CMPT-E005	CMPT-E006	CMPT-E007	
			
Kato Excavator Relay	Kato Hydraulic Pump High Pressure Sensor	Kato Excavator Pressure Sensor	
	HD820	HD820	
ME077148	889-30539002		

## KATO EXCAVATOR PARTS----Seal Kit

CMPT-F001	CMPT-F002	CMPT-F003	CMPT-F004
			
Kato Excavator Control Valve Seal Kit	Kato Excavator Pilot Valve Seal Kit	Kato Excavator Arm Cylinder Seal Kit	Kato Excavator Travel Motor Seal Kit
hd550se	hd550se	HD900-5/7	
CMPT-F005	CMPT-F006	CMPT-F007	CMPT-F008
			
Kato Excavator Center Joint Seal Kit.	Kato Excavator Hydraulic Pump Seal Kits.	Kato Excavator Main Pump Seal Kits	Kato Excavator Arm Cylinder Seal Kit
CMPT-F009	CMPT-F010	CMPT-F011	
			
Kato Excavator Boom Cylinder Seal Kit	Kato Excavator Bucket Cylinder Seal Kit	Kato Excavator Swing Motor Seal Kit	

### KATO EXCAVATOR PARTS---Others

CMPT-G001	CMPT-G002	CMPT-G003	CMPT-G004
			
Kato Excavator Wiring Harness	Kato Excavator Start Switch Harness	Kato Excavator Wiring Harness	Kato Excavator Fuse Box
DH220-5		DH220-V 300-V	DH820
530-00231A		2530-1602B	
CMPT-G005	CMPT-G006	CMPT-G007	CMPT-G008
			
Kato Excavator hydraulic level gauge	Kato Excavator hydraulic level gauge		Kato Excavator Bullet
HD450-5 HD450-7 HD550-7 HD700-5 HD700-7 HD800-5 HD800-7	HD450-5 HD450-7 HD550-7 HD700-5 HD700-7 HD800-5 HD800-7	HD820	

## OTHER EXCAVATOR PARTS---Controller,Monitor

CMPO-A001	CMPO-A002	CMPO-A003	CMPO-A004
			
CASE Excavator Controller, Main ECM, Engine ECM, Control panel	Zoomlon Excavator Controller	CASE Excavator Controller	Zoomlon Excavator Controller
CASE210		Case 9033	C130H-1
KHR10036	E3002024-20 E3002023-20 18238094 18241070	SMCU-5 KHR1794	EPC 2023 2024
CMPO-A005	CMPO-A006	CMPO-A007	CMPO-A008
			
Zoomlon Excavator Controller	Link Belt Controller	Link Belt Controller	Zoomlon Excavator Controller
C130H-1	Linkbelt 350 x2	LINKBELT 210x 2 240X2	C130
SFQ24T0512-25W	8-98126068-2	8-98126057-0	
CMPO-A008	CMPO-A010	CMPO-A011	CMPO-A012
			
CASE Excavator Controller	SANY Excavator Monitor	Zoomlon Excavator Monitor	CASE Excavator Monitor
CX210	215C	DS150 C130H-1	CASE210B
KHR3314	12848576	PEC-WY-03TA-200 PEC-WY-03TB-200	KHR10028



## OTHER BRAND EXCAVATOR PARTS----Solenoid Valve

CMPO-B001	CMPO-B002	CMPO-B003	CMPO-B004
			
Excavator Solenoid Valve	Excavator Stop Solenoid Valve	Excavator Stop Solenoid Valve	Excavator Shut Off Solenoid Valve Kubota
1G772-60014	0428-7583 0428-7116 0410-2390	1751-24E7U1B1A	17208-60016 17454-60010
CMPO-B005	CMPO-B006	CMPO-B007	CMPO-B008
			
Excavator Stop Solenoid Valve	Excavator Solenoid Valve	Excavator Solenoid Valve	Excavator Solenoid Valve
052600-4531 16851-60014	6689034 12V	solenoid 0E52318 12V	SOLENOID 0410 3812 12V
CMPO-B009	CMPO-B010	CMPO-B011	CMPO-B012
			
Excavator Solenoid Valve	Excavator Solenoid Valve	Excavator Solenoid Valve	Excavator Solenoid Valve
SOLENOID 1751-12E2U1B1S1 12V	SOLENOID 2848A279 24V	SOLENOID 6681512 24V	Solenoid 1503ES-12S5SUC11S 41-6383
CMPO-B013	CMPO-B014	CMPO-B015	CMPO-B016
			
Excavator Solenoid Valve	Excavator Solenoid Valve	Excavator Solenoid Valve	Excavator Solenoid Valve
SOLENOID 1751ES-12A3UC12B1S 12V	SOLENOID 6689034 12V	053400-7100	SA-3799-12
CMPO-B017	CMPO-B018	CMPO-B019	CMPO-B020
			
Excavator Solenoid Valve	Excavator Solenoid Valve	Excavator Solenoid Valve	Excavator Solenoid Valve
SA-4026-24 12v	1G772-60012 12V	Solenoid Valve A036-3175 SA-3725-12	Solenoid Valve B4002-1115030 VDC24


**OTHER BRAND EXCAVATOR PARTS----Sensor**

CMPO-D001	CMPO-D002	CMPO-D003	CMPO-D004
			
Denso Excavator Pressure Sensor	Denso Excavator Common Rail Pressure Sensor	ISUZU Excavator Sensor	Excavator Pressure Sensor
4HK1 6HK1			
8-98119790-0	499000-6131	8-97170327-0	281002937
CMPO-D005	CMPO-D006		
			
Excavator Pressure Sensor	Excavator Position Sensor		
1110010028	4327230		

**OTHER BRAND EXCAVATOR PARTS---OTHER**

CMPO-E001	CMPO-E002	CMPO-E003	CMPO-E004
			
NTN	NSK		Piston Shoe
4T-T7FC065STPX3		P128234	04574 H3V180DT
CMPO-E005	CMPO-E006	CMPO-E007	CMPO-E008
			
JCB Excavator Ignition Switch	JCB Excavator Ignition Switch	Glow Plug Timer Relay	Timer Relay
JCB200 JCB220	JCB200 JCB220	HC0108	HC0119
9 Lines	10 Lines	128300-77920	129211-77920
CMPO-E009	CMPO-E010	CMPO-E011	CMPO-E012
			
Sany Excavator Accelerator Throttle Motor	Excavator Throttle Cable	Excavator Throttle Cable	Excavator Throttle Cable
AC22000 AC2-2000 01249	D20	D20	D65-12
		65 inches	
CMPO-E013	CMPO-E014	CMPO-E015	CMPO-E016
			
Excavator Main Relief Valve	Excavator Hydraulic Control Valve	Excavator Common Rail Metering Valve	Yanmar Excavator Glow Relay
XCMG 40	液压控制阀 Denso Fuel Pressure Control Valve 095420-0260	0928400670 valve	119650-77911 11965077977
徐工 主溢流阀			
CMPO-E017	CMPO-E018	CMPO-E019	CMPO-E020
			
Excavator Valve Gear	Excavator Three-hole Puncher	Excavator Oil Pump Small Wheel	Denso Excavator Overhaul Kit
8-98238245-2			094040-0081

## Diagnostic Tool

CMPP-A001	CMPP-A002	CMPP-A003	CMPP-A004
			
Adapter Diagnostic Tool for Cummins Diesel Engine	Volvo Vocom Diagnostic Tool 88890300 Communication interface	Hitachi Excavator Diagnostic Tool DR.ZX Palm TE2	EMPS3 Heavy
Inline 6 Data Link	(PTT) 1.12 / VCADS Pro 2.40		ISUZUexcavator Diagnostic tool
3165033.00	88890300.00	Version V3.10	
CMPP-A005	CMPP-A006	CMPP-A007	CMPP-A008
			
Hino-Bowie diagnostic V3.16	CAT ET 3 iii Communication Adapter	pressure test kit, Pressue gauge( silver)	pressure test kit, Pressue gauge
Kobelco SK-8 excavator machine and other Hino engine machine	Mos of CAT machines	All kinds of excavator	
	317-7485		