

MULTI-SURFACE
**CERAMIC
CLEARCOAT**
PURE AIR COATING

You will need:

Mop/mop bucket

Laundered flat looped microfiber mop

Red and green pads

2 gallon pump-up sprayer

SIMIX Multi-Surface Cleaner & Degreaser

SIMIX Multi-Surface Ceramic Clearcoat

Distilled or RO water

Clean, Restore and Coat LVT and LVP Flooring

INSTRUCTIONS

It is imperative that the floor is completely stripped.

Step 1: If any coating is present strip floor of all dirt, grime and or old coatings.

Step 2: Now rinse floor well with 1 small scoop of **SIMIX Multi-Surface Peroxide Cleaner & Degreaser** to 1 gallon of warm water. Let floor dry.

Apply SIMIX Multi-Surface Ceramic Clearcoat

Step 1: Mix **SIMIX Multi-Surface Ceramic Clearcoat** 4 parts water with 1 part coating in pump-up sprayer. (use distilled or RO water)

Step 2: Apply coating and spread using a laundered flat looped microfiber mop. Apply thin coats. Do not allow coating to puddle. Each coat will take 5 to 10 minutes to dry.

Step 3: Apply 4 coats. After 4th coat is dry wait 30 minutes before replacing all the items back on the floor. Can add 4–6 total coats for added protection.

