

		2 1				
el	Cikkszám	IFS megnevezés EN	Db			
	AKU1830	Filter house for floating 50 sqf filters	2			
	AKU1893	On-Off tap house 33 transparent V2	1	F		
	AKU1892	Air Regulator - house led lighted V2	2	F		
	AKU2101	Fountain laminar V2	6			
	ABE0505	Suction 2" chrome thick with seal V2	4			
	ACM0874	Speaker 3" (2 way)	4			
	AKU2157	Adapter for swim theter V2	1			
	AJ00254	Jet house with sealing 3"	18			
	AJ00253	Jet house 2" with sealing V4 1/3	6			
	AKU1720	Suction 48	2			
	AJ00169	Jet - 20 SB - Ozone 90°	1	E		
	AKU2218	Led housing with seal	18			
	AKU2219	Nut for ledhouse	18			
	ACM0912	Control Panel - IN.K1000 V2	1			
	AJ00259	Nozzle housing nut self-aligning 2" V4 2/3	6			
	AJ00256	Washer for washer housing 2 "V4 3/3	6			
	ACM0080	Spa Pump 3 HP - One Speed	1			
	ACM0834	Circulation pump PCF100 1100 W without prefilter	1	D		
	ACM0888	UV-C Stainless steel house set	1			
	ACM0755	Control box In.YE-3	1			
	ABE0417	Turbine housing	1			
	ACM0857	Control box for tubrine	1			
	ACM0904	IN.STREAM-2 with quick connector	1			
	ACM0849	Subwoofer 288W	1			
	ACM0901	Wifi receiver in.touch 2 Gecko EU&UK	1	С		
	ACM0881	In.Grid external heater controller and 4 ways connector	1			
	ACM0932					
	ACM0867	UV-C control electronics	1	<u> </u>		
	ACM0932	Led 4 prow v2	1			
	ACM0802	Led control box	1			
	ACM0874	Speaker 3" (2 way)	2			
				1		

Product family: SwimLine							
úszómedence			rojection 🕀 🗁	Wellis Wellis Magyarország Zrt.			
s: 230 V - 25A - 50Hz / Opt.El. needs: 400V - 3x16A - 50Hz							
Control box: Gecko IN.YE-3 + IN.K1000							
ner Sándor Pr. No: P-00182 Fe. No:		Number: WU00036			D		
dor - 2020. 05. 14. 14:03:17			M 1:20	page	1/3		

В

Installation instruction

Residual-Current Device (RCD) having a rated operating residual-current not exceeding 30 mA is must

The stated dimensions are for reference only. The actual dimension may be different from the specified

L: Drain diameter: 50 mm

E: 3 m cable is required for the electrical connection through the spa skirt.

Cable length/cross section

- Minimum requirement: cable length is maximum 10 m, 3x4 mm2 core flex cable is necessary (230V) In this case the massage motors and the heating won't work
- For full operation: cable length is maximum 10 m, 5x4 mm2 core flex cable is necessary (400V) In this case the massage motors and the heating work at the same

Attention

The hot tube will be installed only if the electrical contractor makes declaration of the installation of Residual-Current Device and proper fuses

Initial installation

The installation or making any repair are allowed only for properly skilled person. Disconnecting device has to be installed when the spa is directly connected to the electricity networks.

1. Site preparation

D

С

a. Indoor / Basement installation

If you place your spa indoors, be aware of some special requirements: Water may accumulate around the spa, so the flooring mate-rial must have a proper runoff to avoid accumulation of water. When building a new room for the spa, constructing a floor drain is required, or damages may occur due to overflow, overfilling, or technical failure. Our company does not take responsibility for any damage in absence of floor drainage.Humidity will naturally increase in the room where the spa is located and the evaporated water condenses. For this reason ensure that the area has proper ventilation. We recommend installing a dehumidifier in the room.

b. Outdoor and patio installation

A solid horizontal foundation is necessary for installation of the spa. We advise using a reinforced concrete foundation at least 10-15cm thick. Ensure that your deck or foundation will support your spa. You must know the maximal load capacity of the foundation. Consult a qualified building contractor or structural engineer. To find out the weight of your spa, its contents and occupants please refer to the spa specification chart. This weight must not exceed the structure's rated capacity per square meter, otherwise serious structural damages could result. If you install the spa outdoors, we recommend a reinforced hori-zontal concrete pad at least 10-15cm thick.

Install floor drains around your spa to lead water away even in heavy rain. When constructing the water drain it is advised to form a 10-15cm deep sloping ditch around the spa which directs wat to the canal or a drainage with enough capacity.

Warning: Do not expose the spa to direct sunlight (not even empty) without proper coverage. The insulated spa cover preserves the water temperature and provides protection from sunlight a may damage the surface of the spa and the spa equipment. Acrylic rapidly absorbs heat from sun rays, thus reaches a very high surface temperature which may damage the spa. In case of seal structures, prevent the sun rays from reaching the spa directly through the glass as the temperature may get too high.

c. In-Ground / Sunken Spa

In case of sinking the spa into the ground you must make sufficient space for walking around the spa. For completion of maintenance works a minimum of 60cm wide inspection pit must be built. The inspection pit's bottom must be under the bearing pont of the spa so that water can flow into the pit in case of water leakage. A floor drain or sump pump should be used at the bottom of the spa so that water can flow into the pit in case of sinking the spa only the portion below the spa's acrylic edge can be sunk. The air of the inspection pit steams up. To prevent unpleasant odors proper ventilation must be provided (e.g the ground are borne by the user. If the aforemen-tioned conditions are not present, setting up the spa may fail.

2. Electrical connection

All the above stated electrical preparation must be ensured by the costumer. Every product has own connection drawing. Use only copper wires. Change the fuses always with the same type. The device has to be connected to the equipotential grid.

						Sheet name: INF	O(2)(2)		
						File name: FJ_W	U00036_ENG_	Danube-201	9_Tubina_
						Dimension SPA:	2350x4530x1	470 mm	Min.El. nds:
			1	1 person ~75 kg		Weight of the SPA	: kg		
			V	Water disp.:	225 kg	Rim height:	150 mm	Approved by	: Losteine
			Ν	Minimum water:	5913 liter	Created: 2020. 05	. 15.	Drawer: lost	einer.sando
8	7	6	5			4	File path · · · · > C:IWELLIS_PDMIUj_Dokumen	tum rendezésiFJ_WM_100\	



úszómedence

dor - 2020. 05. 14. 14:03:17

ner Sándor

at the same time.	
ne time.	E
	D
ter to the drain. Water from the drain must be directed and rain. When exposed to sunshine for a longer period it led design, if the spa was placed between glass	с
t around the spa. he pit to ensure continual water drainage. g. installing ventilators). The costs of pulling the spa out of	В
Product family: SwimLine	
Projection 🕀 🕞 🛛 🕅	

s: 230 V - 25A - 50Hz / Opt.El. needs: 400V - 3x16A - 50Hz

Pr. No: P

Fe. No:


Control box: Gecko IN.YE-3 + IN.K1000

A3 M 1:17

Number: WU00036

D

page 2 / 3



	2				1			
nube body]							
			Ą					F
			•					
Sm	00	thed gra		hed				
011	<u>00</u>	ined gro		DEG				E
r pebble b	ed]						
								D
							_	
								С
)	,							
								В
	Pro	oduct family:	Swim	Line				
a úczómodora				ojection 🕀 🖯	≯	We	lis	
a_úszómedence ds: 230 V - 25A -		lz / Opt.El. ne	eds:	400V - 3x	16A -	Wellis Magyar	or ozay Zrt.	
Control box: Gecko IN.YE-3 + IN.K1000								
iner Sándor	14	Fe. No:		ber: WU	0003		D	
ndor - 2020. 05.	14.	14:03:17	A3	M 1:17		page	3/3	