


Parts Needed

- Dishwasher Panel Hook
- (Screw) ST3.5*25 x2 (Dishwasher Panel Hook)
- Installation Bracket #2 x2
- (Screw) ST4*14 x10 (Bracket Screws)
- (Screw) ST3.5*45 x4 (Dishwasher Panel)
- (Screw) ST3.5*9 x2

DW7714-18 -- Panel & Kickplate Cutout Dimensions



Front Panel View




17 ⁹/₁₆ in.

5 ³/₈ in.

Front Kickplate View

Back Panel View



2 ⁹/₁₆ in.

2 ¹¹/₁₆ in.

Back Kickplate View


Parts Needed

- Dishwasher Panel Hook
- (Screw) ST3.5*25 x2 (Dishwasher Panel Hook)
- Installation Bracket #2 x2
- (Screw) ST4*14 x10 (Bracket Screws)
- (Screw) ST3.5*9 x2
- (Screw) ST3.5*45 x4 (Dishwasher Panel)


DW7713-24 -- Panel & Kickplate Cutout Dimensions




Front Panel View



Front Kickplate View



Back Panel View



Back Kickplate View

