



ATTACHING YOUR INNER TENT



1 UNPACK YOUR INNER TENT + POSITION IT FLAT AT THE REAR END OF YOUR TENT.



2 LOCATE ONE OF THE WEBBING STRAPS ON THE INNER TENT + HOOK IT ON TO THE MATCHING RING ATTACHED TO THE GROUND SHEET.



3 LOOP + TOGGLE AT THE TOP OF THE WALL.



4 CONTINUE THIS AROUND THE TENT UNTIL ALL TOGGLES + ALL HOOKS ARE SECURELY FASTENED.



5 MAKE SURE THE WINDOWS LINE UP AS SHOWN.



6 THE INNER TENT SHOULD NOW LOOK AS SHOWN HERE.



7 TO CONNECT THE INNER TENT TO THE CENTRE POLE, LOOSEN THE ADJUSTMENT ON THE WEBBING + HOOK ON TO THE LOOP ON THE CENTRE POLE, WHICH SHOULD BE 3/4 UP THE POLE.



8 THE INNER TENT HAS BOTH A MOSQUITO + PRIVACY DOOR WHICH CAN BE ZIPPED OPEN OR CLOSED INDEPENDENTLY.



9 DOUBLE COMPARTMENT INNER TENTS HAVE TWO SLEEPING SECTIONS + CAN BE UNZIPPED TO MAKE ONE LARGE SECTION.



10 USE YOUR NEW SEGREGATED SPACE TO ACCOMMODATE A PRIVATE SLEEPING AREA, TO STORE BELONGINGS OR TO HOST IN THE COMMUNAL SPACE.

