



INSTALLATION GUIDE

DUAL TRUMPET AIR HORN MODEL V618K


► INSTALLATION GUIDE

TRUMPET INSTALLATION:

1. Locate the desired area you wish to mount horn. (**NOTE:** horn should be mounted facing sideways, backwards, or downwards (not facing forward), to protect from any debris, water entering the trumpets).
2. Line up the 2 mounting holes on the horn to desired installation location and drill 2 holes. Fasten horn to surface with 2 bolts (not provided), with trumpets facing down.

ELECTRIC CONNECTIONS

1. Connect BLACK wire **NEGATIVE** (-) to ground (make sure the surface is free of paint or rust).
2. Connect RED wire **POSITIVE** (+) to 12 volt Power.
3. Install the horn button (switch, not included), spliced in the ground wire.



WARRANTY

All "Viking Horns" products carry a warranty of six month, when properly installed and used under normal conditions, and to be free from defects in workmanship and materials from the date of the original purchaser of the product. Warranty does not cover abuse, operation in a manner inconsistent with the product's design, neglect, abnormal use, or damage resulting from exposure to the elements, any modifications or faulty installation. "Viking Horns" will fully inspect your item and if the defect is considered under warranty, we will have the option to repair, or replace the product free of charge to the original purchaser. "Viking Horns" will not be held liable for any installation charges, loss or damage of any kind incurred in the replacement or repair of any warranted product. Any return shipping charges will be paid by the end user.