


QUICK START GUIDE




WHAT'S INCLUDED?

Monitor



Protective Tank & RCE



USB Cables & Charger



Measuring Tape



Monitor Clip




Protective Cases



1. CREATE A COACH ACCOUNT

Visit cloud.rapsodo.com and create a coach account. This will be your username and password to login to both the **Rapsodo Cloud** and the **Diamond App**.



2. DOWNLOAD THE DIAMOND APP

Go to the Apple Store and search **Rapsodo Diamond**.


App Requirements:

- Latest iOS version
- iPad Air 2 or newer



3. SETUP THE MONITOR AND RAPSODO COMPUTING ENGINE (RCE)


Using the provided measuring tape, place the front edge of the device **14'** from the **FRONT** of home plate.



4. PAIR THE RCE AND THE DIAMOND APP

Turn on the RCE and the Monitor and connect to **Rapsodo Wi-Fi** in device settings.

! When connected to the Rapsodo Wi-Fi the iPad will say **"No Internet Connection"**.




5. CALIBRATION

Connect the RCE by tapping the **'Play'** tab and then tapping **'Refresh'**. To Calibrate, tap the **'Monitor' icon** on the bottom right of the app then tap **'Recalibrate'**.

The **red line** in the azimuth view should go directly **down the middle** of home plate.


! Angles should be as close to **90** degrees and **20** degrees as possible.




6. DISPLAYS



- **Red**
Not ready
- **Green**
Data ready, monitor ready
- **Blue**
Processing data
(wait for green light to hit again)




- **Green**
Successfully Connected to RCE though USB
- **Red**
Not connected to RCE, Waiting for USB Sync
- **Amber**
Charging (switched off)
- **Gray**
Off



- ● ● RCE and monitor connected.
- ● ● RCE and monitor connected to application, needs calibrated or on 'Pause Mode'.
- ● ● Ready to record data.
- ● ● Data processing.
- ● ● RCE switched off and charging.
- ● ● Warning for low battery, please recharge monitor.
- ● ● RCE turned on, not connected to app and monitor.
- ● ● RCE turned on, connected to app but not the monitor.

7. MAINTENANCE

The monitor and the RCE must be charged separately. The monitor is charged using the provided right angle Micro USB Cable and the RCE is charged with the provided USB-C cable.




USB Cables



Charger

For additional resources visit the
Rapsodo Learning Centers



BASEBALL



SOFTBALL

support@rapsodo.com
844.772.7763