

USER MANUAL

Chef-Mate Kitchen Scale

MODEL KS 33











www.healthsense.in









Manual Instruction For KS 33

The scale is intended for household use only.

ADVICE TO THE USER

This product is a sensitive electronic instrument and it may be affected by radio transmitting devices being used in close proximity(such as mobile phones, radios, radio model controllers and some microwave ovens).

If the appliance exhibits symptoms such as errors or erroneous data,try moving the product away from the source of interference or switching off that source of interference while you are using this product.

Your new scale is easy to use

It is very important to read this manual carefully.

WARNING!

- You new scale does not require any specific maintenance.
 Handle your scale with care, as it is a precision instrument, i.e. never expose it to extreme temperatures, moisture, winds, dust and direct sunlight. Do not drop the scale or knock it.
- Keep your scale away from sources of heat.
 Clean your scale with a damp cloth,never use abrasives or solvents.
- · Do not overload the scale.
- Do not open the scale. In the event of opening or tampering the guarantee becomes invalid.
- · Refer to authorized service centers for maintenance.
- See that no liquids penetrate inside the scale. This appliance is not watertight. Do not store or use the scale in a damp room with humidity above 85%. Make sure that the scale does not come into contact with water or other liquids as this may cause corrosion and jeopardize the precision of the scale.
- Keep the appliance out of the reach of children

BATTERY INSTALLATION/REPLACEMENT

The scale operates with replaceable AAA batteries

- Insert into the battery compartment located at the bottom of the scale 2xAAA battery with the correct polarity.

 When the batteries are discharged the display will show either "LO".Remove
- the batteries if the scale is not to be use for a long period of time

OPERATING INSTRUCTIONS:

- When the scale is on, it will display with blue led backlight.
 Place the scale on a flat, solid surface.
 Press the [O TARE] button located on the front panel, the display shows "0"
- Weigh.
- The scale will switch off automatically after 120 seconds.

TARE FUNCTION

The tare function allows you to set the scale to zero at any moment and to weigh different ingredients without removing those already weighed. To do so set the scale to the "0g" position at any moment when weighing different ingredients.

- Press the [O TARE] button located on the front panel under the displaythe display shows"0"
- 2. Weigh the first ingredient.
- Press the [\oplus TARE] button again to zero the display. (Now,if you press ON button again, the scale will switch off.)
- 4. Weigh the second ingredient.
- 5. Press the [UNIT] button to switch unit g/ml/lb/oz

OVERLOAD

The message "EEEE" indicates an overload.

SPECIFICATIONS

- 2*AAA battery Weighing Capacity:5000g LCD display with backlight Units: g/ml/lb/oz Increment 1g

WARRANTY & SUPPORT

Entitle yourself for the 1 year HealthSense warranty by registering your purchase and easily reach us to submit your product related issues & queries, when you follow these hassle free ways.





- * For detailed warranty terms please visit the link : www.healthsense.in/warranty-term
- * For additional support : Mail us at support@healthsense.in or Call us on : $080 \cdot 41262836$