

Nanny Panel Playpen Assembly Guide








www.tikktokk.com



When assembling, place playpen on a hard surface such as tiled or wood floors, not carpet, and push firmly downwards until you hear the panels click into place. Ensure both surfaces of the panels are touching and flat.



When setting up, ensure the logo is facing outwards, as installing panels logo side inwards, can cause damage and breakage to pins.





WARNING

This is not a safety device DO NOT LEAVE CHILDREN UNATTENDED DO NOT use as a barrier for stairways, stoves or heaters Incorrect installation may result in instability & weakness Keep plastic bags away from children



PRODUCT NOTICE

The finish deteriorates if over exposed to the elements Colours, especially red deteriorate or alter in strong sunlight Be sure to check all Safety Notices on the side of the

carton

EXPORTER TikkTokk HONG KONG Room 50 45F Premier Centre, No.20 Cheung Shun Street, Cheung Sha Wan, Kowloon,Hong Kong

NPPP01 / NPPP81

CONSUMER ASSISTANCE HOTLINE: +61 (0) 2 9980 6633 SKYPE: tikktokk.mb EMALI: info@itikktokk.com WEB: www.tikktokk.com ADDRES: Unit 3, 280 New Line Rd, Durdi, NSW, 2158, Australia

www.tikktokk.com

2

IMPORTER

TikkTokk Australia

Unit 3, 280 New Line Rd Dural, NSW, 2158

Australia