





USER GUIDE

HOW TO USE

• DEVICE POWER ON/OFF

Press and hold the  or  button for 3 seconds to turn on your device to standby mode. The indicator light will light up once turned on. Press and hold the buttons for 3 seconds to turn off each function.

• VAGINAL VIBRATOR MODES

Press  button repeatedly to cycle through 10 patterns of vibrating modes. Press and hold for 3 seconds to stop.

• CLITORIS PULSATING MODES

Press  button repeatedly to cycle through 10 patterns of pulsating modes. Press and hold for 3 seconds to stop.

• BOTTOM VIBRATOR MODES

Press  button repeatedly to cycle through 10 patterns of bottom vibrator modes. Press and hold for 3 seconds to stop.


Each function can operate independently or all three functions can operate together.



ACCESS

Strapless Strap-on with a 6" Realistic Vibrating Dildo, Bulbous Vibrating Insertable Tip & Intense Pulsating Vibrator

Ignite passion with your partner with Bodywand's strapless strap-on vibrator, designed for boundless pleasure. With a vibrating insertable egg that stimulates the wearer and a lifelike shaft for exhilarating partnered experiences, it's the ultimate toy for couples.



HOW TO USE

• CHARGING THE DEVICE

Connect your device using the included USB Magnetic charger.

The device will not function while charging, unplug the charger before using the device.

Flashing LED Light: Item is charging

Solid LED Light: Item is fully charged

It takes approx 100 minutes of charge for up to 40 minutes of use.

CLEANING, STORAGE & SAFETY

Always clean and dry your device thoroughly before and after use. **DO NOT** store wet. We recommend that you use a mild cleanser that is suitable for use with silicone items.

DO NOT clean with a soft, damp cloth. Clean the device with a soft, damp cloth. clean with an alcohol or chemical-based cleaner. Use water based lubricant as desired.

Not compatible with silicone lubricant.

Avoid leaving your device in direct sunlight and never expose it to extreme heat.

Keep away from water, and never immerse it.

Front

232*114.5*38

WARNING

For adult use only. For external use only.

Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis and/or thrombosis, is at an increased risk of developing blood clots, or who has pins/screws/artificial joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.

Bodywand shall not be liable for incidental or consequential damages resulting from the misuse of this product.

SPECIFICATIONS

FOCUS

Size:

Tamaño: 232mm x 114.5mm x 38mm
Taille:
Größe:

Weight:

Peso: 281g
Poids:
Gewicht:

Material:

Material: ABS + Silicone
Matériau: ABS + Silicone
Material: ABS + Silikon

Battery:

Bateria: 600mAh
Batterie:
Akku:

SPECIFICATIONS

POWER:

3.7V 600mAh USB2.0

SLPASHPROOF:

IPX6

BATTERY LIFE:

100 minutes for up to 40 minutes of use.

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):



The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.

XGEN, LLC

Horsham, PA 19044 All Rights Reserved

www.thebodywand.com

UK Responsible Person:

ArangaRanga UK LTD, 20-22 Wenlock Road, London, N17 GU, UK.

Phone: +44 2037692960,

E-Mail: UKresponsibleperson@arangaranga.com

EU Responsible Person:

ArangaRanga SL, Paseo de la Castellana 194, Madrid, 28046, Spain.

Phone: +34 910054258,

E-Mail: EUresponsibleperson@arangaranga.com

Email us at sales@xgenproducts.com for any unanswered questions

Back