









HOW TO USE

• DEVICE POWER ON/OFF

Hold the (b) button for 3 seconds to turn your device on or off. The device will vibrate immediately once turned on.

VIBRATION MODES

There are 7 adjustable vibration modes.

To adjust the vibration modes, press the button on your device to cycle through each mode.

HOW TO USE

• CHARGING THE DEVICE

Connect your device using the included USB Magnetic charger.

The device will not function while charging, unplug the charger before using the device.

Flashing LED Light: Item is charging Solid LED Light: Item is fully charged.

It takes approx 60 minutes of charge for up to 50 minutes of use.

TRAVEL LOCK

Simultaneously press and hold the (1) and (4) buttons for 3 seconds. Flashing light and vibration will indicate the massager is locked.

To unlock, simultaneously press and hold the 1 and 4 buttons for 3 seconds. Flashing light will indicate the massager is locked.

CLEANING, STORAGE & SAFETY

Always clean and dry your device thoroughly before and after use.

DO NOT store wet. We recommend that you use a mild cleanser that is suitable for use with silicone items.

Clean the device with a soft, damp cloth.

DO NOT clean with an alcohol or chemical-based cleaner.

Use water based lubricant as desired.

Avoid leaving your device in direct sunlight and never expose it to extreme heat.

Keep away from water, and never immerse it.

Not compatible with silicone lubricant.

Front

WARNING

For adult use only. For external use only.

Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis and/or thrombosis, is at an increased risk of developing blood clots, or who has pins/screws/artificial joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.

Bodywand shall not be liable for incidental or consequential damages resulting from the misuse of this product.

SPECIFICATIONS

FOCUS

ABS + Silicone

ABS + Silicona

ABS + Silicone

ABS + Silikon

250mAh

 Size:

 Tamaño:
 39mm x 120mm

 Taille:
 Größe:

Weight:

Peso: 66g
Poids: Gewicht:

Material: Material: Matériaut: Material:

Battery: Batería: Batterie: SPECIFICATIONS

POWER:

3.7V 250mAh USB2.0

WATERPROOF:

IPX5 Splashproof

BATTERY LIFE:

60 minutes for up to 50 minutes of use.

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):



The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.

XGEN, LLC

Horsham, PA 19044 All Rights Reserved

www.thebodywand.com

UK Responsible Person:

ArangaRanga UK LTD, 20-22 Wenlock Road, London, N17 GU, UK. Phone: +44 2037692960,

E-Mail: UKresponsibleperson@arangaranga.com

EU Responsible Person:

ArangaRanga SL, Paseo de la Castellana 194, Madrid, 28046, Spain.
Phone: +34 910054258.

E-Mail: EUresponsibleperson@arangaranga.com

Email us at sales@xgenproducts.com for any unanswered questions

Back