
IMPORTANT SAFETY INSTRUCTIONS: All safety and operating instructions should be carefully read before use.


CAUTION: To reduce the risk of electric shock, do not remove cover or open the device. There are no serviceable parts

Vibration mode

1. Plug the jack of the USB cord in to the socket at the bottom of the massager.



2. Plug the USB end of the cord into the USB port of your computer or another power source. The blue LED will light up under the © button of the massager indicating battery charging.



- 3. The blue light will turn off when the battery is fully charged. It takes appx 6 hours to fully charge (depending on power supply).
- 4. The Bodward MensWard cannot be used while charging.

Vibration mode



- 1. Press button to turn on the massager model.
- 2. Press button to change intensities. Total 8 intensities.

 3. Press button to change the vibration mode. Push once to move to the next mode. In total there are 20 massage modes.

20 Vibration Modes:


Mode 1:	
Mode 2:	
Mode 3:	· · · · · · · · · · · · · · · · · · ·
Mode 4:	······································
Mode 5:	
Mode 6:	
Mode 7:	
Mode 8:	
Mode 9:	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~
Mode 10:	
Mode 11:	

60 mm



BACK

Mode 13: **** Mode 14: **** Mode 17: Mode 18: www.www.www.www Mode 19: **** Mode 20: ₩₩₩



TRAVEL LOCK:

- This Bodywand product features a travel lock for safe and convenient travel.
- Press and hold the W button for 3 seconds. A blue light will indicate the massager is locked on @ button.
- -To unlock, simply repeat by pressing and hold the wbutton for 3 seconds, the blinking blue flashing light will indicate the massager is unlocked.
- · Charging the MensWand will also automatically disengage the travel lock.

WARNING: For adult use only. For external use only. Remove all scarves, neckties, necklaces, and jewelry before using this massager.

IMPORTANT: Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis and/or thrombosis, is at an increase risk of developing blood clots, or who has pins/screws/artifical joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.

CARE AND MAINTENANCE

Clean the massager with a soft, damp cloth. DO NOT clean with an alcohol or chemical-based cleaner.

STORAGE:

Store at 20 $^{\circ}$ - 25 $^{\circ}$ Store at cool dry place.

SPECIFICATIONS:

- Power 3.7V/ 1800MAH USB 2.0
- Battery Life: Up to 5 hours use depending
- on speed and massage platform choosen. - Splash proof for cleaning the wand only, can not play under water.

DISCLAIMER:

BODYWAND SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE MISUSE OF THIS PRODUCT.



Generation Products™ Horsham, PA 19044 All Rights Reserved