

Maze64 User Manual

Function	Key combination	Operation	Explanation
Light Control (The 1st and 2nd layer support light effect switching, the other layers only light up the valid key value's switch led)	Fn+Up	Short Press	Increase brightness of the keyboard(10%-20% -----100% interval 10%)10 levels in total.All switch light effects support brightness control; When the limit value is reached, the "Up"indicator will flash 5 times.
	Fn+Down	Short Press	Reduce brightness of the keyboard(100%-90%-80%----- interval 10%)10 levels in total.All switch light effects support brightness control; When the limit value is reached, the "Down" indicator will flash 5 times.
	Fn+Left	Short Press	Slowed downs the speed of the lighting effect, 5 levels in total; speed of the minimum value of the "Left" key flashing indication (flashing 5 times); it is not adjustable in the state without dynamic light effect, the indicator is equal to the minimum state when adjusting.
	Fn+Right	Short Press	Speed up the speed of the lighting effect, 5 levels in total;the "Right" key light flashes when the speed is at its maximum value (flashing 5 times); it is not adjustable in the state without dynamic light effect, and the light is equal to the maximum state when adjusting.
	Fn+	Short Press	turn off/on all the lights of the key
	Fn+] }	Short Press	switch lighting effects
	Fn+P	Short Press	light effect color summing
	Fn+,:	Short Press	light effect color phase minus
	Fn+ { [Short Press	increase the saturation of switch light effect.
	Fn+''	Short Press	reduce the saturation of switch light effect.
Fn combination	Fn+Esc	Short Press	`
	Fn+Shift+Esc	Short Press	~
	Fn+1	Short Press	F1
	Fn+2	Short Press	F2
	Fn+3	Short Press	F3
	Fn+4	Short Press	F4
	Fn+5	Short Press	F5
	Fn+6	Short Press	F6
	Fn+7	Short Press	F7
	Fn+8	Short Press	F8
	Fn+9	Short Press	F9
	Fn+0	Short Press	F10
	Fn+_	Short Press	F11
	Fn+=+	Short Press	F12
	Fn+U	Short Press	PrintScreen
	Fn+I	Short Press	Scroll Lock
	Fn+O	Short Press	Pause/Break
	Fn+J	Short Press	INS
	Fn+K	Short Press	Home
	Fn+L	Short Press	Page Up
Fn+M	Short Press	Delete	
Fn+,<	Short Press	End	
Fn+,>	Short Press	Page Down	
Fn+A	Short Press	Media play/pause	
Fn+S	Short Press	Previous song	
Fn+D	Short Press	Next song	
Fn+F	Short Press	Mute	
Fn+G	Short Press	V-	
Fn+H	Short Press	V+	
Numpad (Third Layer)	7	Short Press	7
	8	Short Press	8
	9	Short Press	9
	0	Short Press	/
	U	Short Press	4
	I	Short Press	5
	O	Short Press	6
	P	Short Press	*
	J	Short Press	1
	K	Short Press	2
	L	Short Press	3
	::	Short Press	-
	M	Short Press	0
	.>	Short Press	.
/?	Short Press	+	
Layer Switch (When switching, the current layer's num key will keep flashing for 5s, backlight will turn off and turn on again after 5s. While the 3rd-5th layers, backlight effect will be off, only valid key's switch leds will be on. Fn combination operation is valid for all layers.)	Fn+Shift+1	Short Press	switch to the first layer (Windows layout layer)
	Fn+Shift+2	Short Press	switch to the second layer (MAC OS layout layer): all control states and the first layer, the difference with the first layer is the key layout
	Fn+Shift+3	Short Press	switch to the third layer
	Fn+Shift+4	Short Press	switch to the fourth layer
	Fn+Shift+5	Short Press	switch to the fifth layer
Win Key Control (Fn combination operation is valid for all layers)	Fn+LWin	Short Press	Toggles the LWin function key lock/unlock cyclically. When the function of LWin key is locked, the Lwin switch light is always on; when the LWin key is unlocked, the Lwin switch light is off
Fn Lock (Fn combination operation is valid for all layers)	Fn	Short Press	FN double click, equivalent to lock FN long press, Fn key switch light on, click FN key to exit lock mode; Fn key switch light does not follow the light effect mode
Restore factory settings	space+Backspace	Press	Plug in USB cable,restore factory settings
DFU Upgrade	space+B	press	Press space+B and plug in USB enter DFU firmware upgrade mode
	Fn+Shift+R	Long press 3s	Enter DFU firmware upgrade mode in Wired mode
Reset	Fn+Shift+R	Short Press	manually reset the keyboard
6-key rollover/ N-key rollover switch	space+N	Press and plug in USB	6-key rollover by default. How to switch to n-key rollover: press and hold space+N, and plug in computer; The same action again to switch back.
Swap LCtrl/Caps keys	space+LCtrl	Press and plug in USB	press space+LCtrl and plug in the computer and exchange the LCtrl/Caps key position with each other
Control key	Space+Caps	Press and plug in USB	press space+Caps and plug into the computer,change the Caps key to Control key or back to Caps key
Swap LeftAlt/ Lgui	Space+LAlt	Press and plug in USB	press Space+LAlt and plug in the computer, swap the function of LeftAlt and Lgui keys
Swap ReftAlt/Rgui	Space+Ralt	Press and plug in USB	press Space+RAlt and plug in the computer, swap the function of ReftAlt and Rgui keys
Disable Lgui	Space+Lgui	Press and plug in USB	Press Space+Lgui and plug in the computer, disable/enable Lgui key function
Swap Grave/ Escape(MAC)	Space+Grave	Press and plug in USB	Press Space+Grave and plug in the computer,swap function of Grave and Escape(MAC) keys
Swap Backspace/"\	Space+\	Press and plug in USB	Press Space+\ and plug in the computer, swap function of Backspace and \