


MOPALL

N30 TOUCHLESS TRASH CAN



PRODUCT PARAMETERS:

MODEL: JBS-LJT-N30-JWT

INPUT POWER: TYPE-C 5.0V, 1A

BATTERY MODEL: 18650 1200MAH LITHIUM BATTERY

CHARGING TIME: ABOUT 5 HOURS

PRODUCT SIZE: 279*162*318MM

CAPACITY: 3.5 GALLON

INSTRUCTIONS USE

1. When the battery is low, the green indicator light flashes slowly, use the Type-c charging cable to charge, the red indicator light is on when charging, and the fully charged indicator light is off;
2. Turn the power switch to "-" to turn on the power, and the green indicator light flashes quickly; turn the power switch to "o" to turn the power off;
3. Turn up the middle cover, put the garbage bag (40*45mm) on the inner barrel, and stick the drawstring on in the positioning slot;
4. Put down the middle cover, the air suction starts to work automatically, and stops after 7 seconds, and the garbage bag is attached to the wall of the inner barrel;
5. If the sensing area is blocked (distance <30CM, sensing angle <20°), the lid will automatically open; after 5 seconds without obstruction in the sensing area, the lid will automatically close.

NOTICE TIP

1. If not in use for a long time, please turn off the power;
2. Do not run out of power, please charge regularly to avoid battery loss;
3. Please do not block the sensing area for a long time;
4. It is prohibited to disassemble, repair and modify this product without authorization;
5. It is forbidden to wash the fuselage.