

## 1 Joule Solar System






- Speedrite 1000 Unigizer® (Universal Electric Fence Energizer)
- 10 watt solar panel
- Solar panel regulator
- Solid steel, powder-coated frame with battery box
- 1 joule output provides power & portability
- Fully assembled
- 12 volt deep-cycle battery required (SOLD SEPARATELY)



Tru-Test, Inc. 800-874-8494 www.tru-test.com www.speedrite.com



## **Connecting the Battery**



- 1. Make sure the charger/energizer is in the OFF position.
- 2. Locate the gray wire connected to the solar panel.
- 3. At the end of the gray wire, you should see a red wire and black wire.
- 4. Connect the eyelit of the RED wire to the POSITIVE (RED) battery terminal.
- 5. Connect the eyelit of the BLACK wire to the NEGATIVE (BLACK) battery terminal.
- 6. Locate the red and black battery clips from the charger/energizer.
- 7. Connect the RED clip to the POSITIVE (RED) battery terminal.
- 8. Connect the BLACK clip to the NEGATIVE (BLACK) battery terminal.
- 9. Turn ON the charger/energizer.