MEMPHIS WI-FI SET UP GUIDE

ON YOUR GRILL CONTROLLER:

- 1) A Wi-Fi connection can be set up in minutes on your Memphis Wood Fire Grill. First power the grill ON by pressing the top left button \circ on the controller, then from the home screen press the "MENU" button, then the "DOWN ARROW", then the "WIFI" button.
- 2) The "WIFI" screen on your grill contains everything needed to connect your grill to a Wi-Fi network. First, you will notice that Wi-Fi is OFF, this is enabled as default for users not wishing to use **Wi-Fi**. To turn Wi-Fi ON, simply press the button "TURN ON WIFI".
- 3) Next, press and release the "SETUP" button and the grill will start searching for all nearby Wi-Fi networks. Once the status field displays "CONNECTING" the grill is ready to be connected to your network via any Wi-Fi compatible device.

BACK TURN 2



ON YOUR PHONE OR TABLET: (UNDER WIFI SETTINGS)

4) Simply go to available Wi-Fi networks on your phone or tablet and select the network "Memphis Grill XX:XX" NOTE: The XX:XX characters will match the last 4 digits shown on the grill controller next to MAC.

5) Once selected, the grills network will automatically bring you to a page where you will connect your grill to your Wi-Fi network. Search for all networks in range by hitting "Search", all networks in range are displayed. Click on the network desired and it will auto populate the "SSID" field with your selection. Enter your networks password if you have one. If the network does not

require a password, leave the password field blank.

NOTE: Some devices will not bring up the page shown automatically. Once your device is connected to the grill's network, you can visit www.wificonfig.com to manually bring up the provisioning page

- 4) Click "CONNECT" and the page will automatically close.
- 5) The Wi-Fi setup is now complete. The status field in the grills Wi-Fi menu should now read "WIFI CONNECTED". The time period from hitting "CONNECT" to "WIFI CONNECTED" can take up to 3 minutes based on connection strength.





ON YOUR PHONE OR TABLET: (IN THE MEMPHIS GRILLS APP)

- 8) Download our app "MEMPHIS GRILLS" from the IOS App Store or Google Play Store.
- 9) Enter a valid email into the "CUSTOMER ID" field and create a password that you will use to login to the app. After logging in, you will receive an email requiring you to confirm your email address before continuing.
- 10) Once the confirmation link is followed from your email, return to the app.
- 11) Once confirmed, login to the app again and you will be able to add your grill. Enter the exact MAC Address and Name shown on the grill controller

Example: MAC: F8:F0:05:F4:A8:12 NAME: MEMPHIS

NOTE: THERE ARE ONLY NUMERICAL O'S IN THE MAC ADDRESS, NO ALPHABETICAL O'S. NICKNAME IS NOT CASE SENSATIVE. INCLUDE COLONS IN THE MAC ADDRESS AS SHOWN.


Add Grill

Enter Grill MAC Address and a Grill
Nickname

F8:F0:05:F4:A8:12
memphis

Cancel

OK



SETUP IS NOW COMPLETE!