


HANGERS

CRUCIFIX HANGING BAR INSTALLATION GUIDE




STEP 1

Instruction:

Measure the distance of the rear shelf bearer between the two fitted side walls.


Divide this measurement in half.



STEP 2

Instruction:

Measure out from the shelf bearer to 250mm mark a small line for reference.



STEP 3

Instruction:

Fix hanging bar cup in place




STEP 4

Instruction:

Measure from the hanging bar cup to the floor.

Minus 8mm from this measurement to allow for hanging bar cups.

Cut Hanging bar to size




STEP 5

Instruction:

Secure hanging bar cup to floor.

Insert hanging bar into the hanging bar cups.





STEP 6

Instruction:

Secure hanging bar cup 80mm below the underside of shelf to the hanging bar.

Repeat on other side.




STEP 7

Instruction:

Measure the distance between the two hanging bar cups.

Cut hanging bar to suit and install.


Repeat for the other side.



STEP 8

Instruction:

Place hanging bar into hanging bar cups.



STEP 9

Interior is complete.

