

BULLET FOR RINGS



GETTING STARTED

- Before first use, wash your device with soap and water.
- 2. Lubricate your device (if needed) with a water-based, silicone-compatible lubricant.
- Charge your device for approximately 2 hours.
 The USB charging cable can be plugged into any USB port or USB/AC adapter (not included).
 Both the remote and bullet use the same USB cable to charge.

Charging = LED light floshing Charged = LED light solid

4. Turn on your device by pressing the (1) power function button.

CHARGING

Connect the charging plug to the charging part of the device.



- 2. Flashing light on the product indicates that the device is charging.
- 3. Solid light indicates that the device is fully charged.



 The bullet vibrator requires approximately 2 hours to fully charge.

CONTROLS

1. Press the bullet (1) button for 3 seconds to turn the bullet device to standby mode (10) button is flashing).



- Press the bullet (1) button to change between the 10 vibration patterns.
- Press and hold the bullet (1) button for 3 seconds to turn off the bullet device.

CARE

- Always clean your device thoroughly before and
 after each use.
- We recommend using a premium water-based lubricant when needed. Silicone-based lubricants are not recommended. Never use hand cream or massage oils as lubricants for your intimate areas.
- To properly clean your vibrating bullet device, use a suitable toy cleaner.
- 4. Avoid leaving your device in direct sunlight, and never expose it to extreme heat.
- This device is designed to be waterproof according to IPX7 compliance, and can be submerged underwater by up to 1 meter for 30 minutes.

SPECIFICATIONS

Materials:	ABS Plastic
Dimension:	Bullet A: 1.8 cm x 8.7 cm Bullet B: 2 cm x 7.6 cm Bullet C: 1.8 cm x 6 cm
Charging time:	Approxiately 120 mins
Use time:	Bullet device: up to 45 mins
Bullet device battery:	180MaH
Vibration mode:	10



www.zolocup.com