NEEDLEPUNCH CARPET INSTALLATION GUIDE



For best results, read through all the instructions first before you start.

EQUIPMENT NEEDED

- Needlepunch Carpet
- Glue
- Trowel (4mm V-notch)
- Knife
- Straight edge
- Tape measure.

INSTRUCTIONS

- 1. Prepare the area. Sweep & vacuum the garage to start with a clean surface. Any oil stains may react with the glue, so do a deep clean on thee areas.
- 2. Unroll carpet and lay out flat. You may need to let it acclimatise so it isn't so rippled and easier to work with.
- 3. Measure the garage floor area. The carpet rolls are 2m wide. Position the rolls in place on the floor, making sure they overlap by 50mm.
- 4. Roll up carpet to expose half the floor for gluing.
- 5. Spread glue evenly using the trowel provided (insure spread evenly for best result). Wait the recommended wait time for glue to become tacky. Every glue has a slightly different timing, so consult the glue manufacturer to find the appropriate timing. Typically, it is 5-20mins. We recommend not glueing the 100mm running down the joining edge of the carpet.
- 6. Unroll the carpet back onto the glued area and press the carpet down to the ground. Ensure all areas of the carpet are pressed down and have adhered (no air bubbles). Leave it for 30min.
- 7. While you wait, you can continue with steps 4-5 on the other areas of the carpet.
- 8. After 30mins, re-press the carpet down to the surface to ensure its stuck fast.
- 9. Double cut on the 50mm overlap join using a straight edge and knife. A double cut means cutting through both (overlapping) pieces of carpet to ensure a seamless join. Pull the offcuts off both pieces of carpet to make the perfect join.
- 10. Pull back the flaps and glue in between the joins. Press the carpet down.
- 11. Trim the carpet to fit around the outside walls and garage door edges.
- 12. After 30 min of leaving the glued carpet, press it again to get rid of any air bubbles/ ripples.







