


F I I I®

THE ART OF AUDIO



F I I I T1Lite
TRUE WIRELESS EARBUDS

USER MANUAL

Important Safety Instructions

Please read the following safety instructions carefully before using this product. Please make sure to include these safety instructions with the product when delivered to a third party.

Health and safety

- Do not use the product in case it is apparently damaged;
- Do not use the product at a high volume level for an extended period of time;
- Do not use the product while driving or being engaged in activities that require full concentration;
- Keep the product, its packaging and accessories out of the reach of children and pets to avoid choking hazard;
- Keep the product away from medical devices that may be affected by magnetic field, such as an implanted cardiac pacemaker.

Product care

- Keep this product dry and at room temperature, avoid long time exposure to high temperature or humidity environments;
- Use accessories only provided by FIIL;
- Excessive signal level may cause damaging overload;
- Clean the product only with dry and soft cloth.

Battery warning!

The product uses lithium polymer battery. Improper usage may lead to the risk of fire or burn. Please use the charger only supplied by qualified manufacturer (recommended output: voltage 5V, current ~500mA) or charge the product via PC USB port.

Specification and disclaimer

- The product is designed for portable devices and high-fidelity systems;
- Any usage other than those specified in the user manual is deemed as misuse;
- Please note that FIIL will accept no responsibility for any loss incurred by misuse.
- FIIL T1 Lite is designed &made by Jiangxi Feier Technology Co., Ltd.

Scan QR code to download and use fiil + APP

- This products support fiil + APP to config headset settings.




Scan to download fiil+




Scan to visit iOS APP store

- 'FIIL' is a registered trademark® of Jiangxi Feier Technology Co., Ltd.


Packaging Content



Earbuds X2
(L/R)



Charging Case X1



Eartips X4
L/M/S/XS




**Type C Charging
Cable X1**




User Manual X1

Main User Interfaces

● Earbud




- 1 Touch control
- 2 LED indicator




- 3 Call microphone
- 4 Eartip

● Charging Case




- 6 Charging case
- 7L Left earbud
- 7R Right earbud



- 8 Charge indicator
- 9 Type-C connector

Get started

Please follow below steps to activate and start to use



● STEP1

If charging case's LED does not light on after opening the charging case at first, please connect USB cable to charge for more than 10min.

● STEP2

Slightly rotate earbuds after put in ears to make it stable, and pay attention to the microphone position towards the mouth for the best call performance.

Bluetooth Pairing


● Bluetooth Pairing

For first usage of brand new FIIL T1 Lite, please refer to page 5 “Get Started”, the earbud status indicator will continue to blink blue once entered pairing mode.

For a paired FIIL T1 Lite , please delete its pairing history in the device list or when the earbuds are turned off, press and hold any one of earbuds until the LED indicator blinks blue.

● Search Connection


Enter setup menu of audio source devices, select “search device” in “Bluetooth” then select “FIIL T1 Lite” in the device list to connect.



Touch Control


●Power On

Take earbuds out of charging case, they will automatically power on and reconnect cell phone, or you can press and hold earbuds for 2 seconds to force power on, you will hear opening music and notice blue LED light on .




●Power Off

Put earbuds into charging case , they will automatically power off, or you can press and hold earbuds until white LED on.



●Answer/End Call


When incoming call, tap any earbuds to answer call.



Touch Control


●Reject Call

When incoming call, please press and hold 2 seconds to reject a call.



●Play /Pause


Tap 2 times to play or pause music .



●Voice Assistant

Hold 2 sec. to activate voice assistant , like Siri etc.


Note: please enable this function via fiil+ APP



Touch Control

●Volume Up/Volume Down


Tap left earbud to Vol+, tap 3 times to Vol-.



Note: enable full control mode in fiil+ APP.

●Next /Prev. Track

Tap Right earbud to play next track, tap 3 times to play Pre. track.



Note: enable full control mode in fiil+ APP.

Production Parameters

Item	Specification
Earbud Weight	~ 4g/each
Charging Case Weight	~ 29g
User Mode	Bluetooth True Wireless
Bluetooth	V5.2 · Support protocols : HSP,HFP,A2DP,AVRCP BT range : 10m. Pairing code: 0000. Both iOS and Android devices are supported.
Audio Specification	Support Code : AAC,SBC; Speaker Specification : Diameter 6.1mm Frequency range: 15Hz-22kHz
Power and Battery	Rechargeable lithium-polymer battery ; music time: up to 7 Hrs (mediums level) on a single charge; Bluetooth standby time: up to 5 days; charging time: ~50 minutes. Support total 32 Hrs battery time with charging case.
Operation environment	Operating temperature : 0°C~ 50°C; Storage temperature: -30°C ~70°C; IEC60529 IPX7 Certified (earbuds).
Voice reminder	English
Certification	BQB,Bluetooth 5.2, SRRC,RoHS,REACH,IPX7

Trouble Shooting

Problem	What to do
Earbuds don't turn on	<ul style="list-style-type: none">• Power on the earbuds• Charge the battery
Earbuds don't pair with Bluetooth device	<ul style="list-style-type: none">• On your Bluetooth device;<ul style="list-style-type: none">- Turn the Bluetooth feature on and then off- Delete you FIIL T1 Lite earbuds from Bluetooth list on your device. Pair again.• Move your Bluetooth device closer to the earbuds and away from any interference or obstructions.• Pair a different Bluetooth device
No sound	<ul style="list-style-type: none">• Power on the earbuds and charge the battery• Increase the volume on your earbuds and Bluetooth device.• Press the power/ Bluetooth button to hear the connected device. Make sure you are using the correct device.• Move your Bluetooth device closer to earbuds and away from any interference or obstructions• Use a different music source.• Pair a different Bluetooth device.• If two Bluetooth devices are connected, pause the first device and play the other device.

Trouble Shooting

Problem	What to do
Poor sound quality	<ul style="list-style-type: none">• Use a different music source.• Pair a different Bluetooth device.• Disconnect the second device• Move the Bluetooth device closer to the earbuds, and away from any interference or obstructions.• Clear any debris or wax buildup from the earbuds and earbud nozzles.
Earbuds don't charge	<ul style="list-style-type: none">• Open the USB connector and securely connect the small end of the USB cable to the USB connector. Make sure the connector on the cable is correctly aligned with the connector on the earbuds.• Secure both ends of the USB cable.• If your earbuds have been exposed to high or low temperatures, let the earbuds return to room temperature and then try charging again.

