HOW TO USE YOUR NEW FLIP BIN!



TO USE

Our flip bins are shipped fully assembled so just add a bin liner and you're good to go!
Lift bin lid and place the liner in. Use metal holders to secure the liner in place, then replace the lid.

TO EMPTY

When you're ready to empty, we have two ways to remove the bin liner:

- 1. Remove bin lid, tie the bin liner together and then pull the liner out the top.
- 2. If bin liner is very full, tie the bag together and lift the body of the bin off the base to remove the bag.

TO CLEAN

When there's inevitably a mysterious sticky, smelly juice in the bottom of the bin there's an easy way to clean it out!

Lift the body of the bin again and remove the bin base, this can be easily washed and replaced.





