





PL-KF16

ASSEMBLY INSTRUCTIONS



PARTS LIST

PART	DESCRIPTION	QTY
A	UPRIGHT	1
B	BRACKET	2