


### 3.4.2 Via Wi-Fi


#### ! IMPORTANT

Before the MaxiCharger is powered on, ensure all the installation and wiring are secured and correct.


1. Power on the MaxiCharger, and tap on the icon \$ to open the Cost Details page.




2. Tap the upper-left corner of the screen to enter the next page.




3. Select **Device Maintenance**.




4. A password prompt will appear. Enter the password **1234** to continue.



5. Tap on the **Select Wi-Fi** button.



6. Select your local network and enter your password. The Wi-Fi icon  will appear at the bottom-right corner of the screen if the connection succeeds.

