

Please see the disassembly instructions below:

Carefully remove the cylinder from the base and the seat. When assembled, the cylinder is pressure fit into the adjustment control and the base so it may take some "elbow grease" to disassemble it.

1. Hold the stool off the ground by the cylinder. With a rubber mallet carefully tap on the base near where the cylinder enters. It may take a little time but the base will fall away from the cylinder.
2. Flip the stool upside down and hold the stool off the ground by the cylinder. With a rubber mallet (or a hammer but be sure to protect the metal of the adjustment control) carefully tap around on the underside of the seat. Again, it may take a little time but the top will fall away from the cylinder.