

INYOUTH



User Manual of the Touch Clock

Follow us! #Inyouths


 INYOUTHS

 inyouths

 @INYOUTHS

 @inyouths

TOUCH CLOCK



1. To enter the setting mode, long press the touch button. Use a short press to switch between different setting items.

-CLD ►► -HOW ►► -LPU





TOUCH CLOCK

2. **-CLD** In the time setting mode, long press the touch button. The setting sequence is as follows: **hour** → **minute (tens place)** → **minute (ones place)**. When the setting item is blinking, use a short press to increase its value. Long press to jump to the next setting item. After setting the minute (ones place), long press again to save the setting. If no action is taken within 10 seconds, the clock will automatically exit the setting mode without saving any changes.



3. **-HOU** To enter the time display mode setting, long press the touch button. Use a short press to switch between **12-hour** and **24-hour** display formats. The setting will be saved automatically.



INYOUTH S



INYOUTH S_MIRROR

Download the technical guide at
www.inyouths.com

Showroom Address:
5005 Ontario Mills Pkwy Ontario, CA 91764
E-mail: support@inyouths.com
Tel: +1(323)982 8683