

# 6 YEAR PRODUCT WARRANTY

Congratulations on purchasing Australia's finest power protection.

Unless otherwise stipulated in a separate and specifically superseding Product Guarantee, all THOR power protection products are guaranteed for a period of six (6) years from date of original purchase against damage or failure due to faulty components or workmanship. In addition in the event any THOR product is damaged or destroyed by a power related event while connected to the AC grid (including lightning), THOR may at its sole discretion repair or replace the damaged unit with a similar model for up to six (6) years from date of purchase.

Should you feel your THOR power board is malfunctioning, unplug the unit from the wall and contact our info-line 1300 766 140 during business hours (after hours please leave your details on the THOR info-line and we will return your call the following working day). Please have available at the time you speak with our service department the unit so you may identify the model number and the date of manufacture which is impressed on the back of the unit as well as a description of the difficulty you are experiencing and your retail invoice or bill of sale.

This warranty shall not cover normal and expected wear and tear, damage, malfunction or failure resulting from accident, misuse or misapplication, improper or unauthorised repair, neglect, modification or use of unauthorised replacement parts or accessories, operation of the unit beyond its technical and environmental specifications, infestation by insects or vermin or interfacing supplied by the customer or improper voltage. The warranty shall be void if the rating label or date code has been removed or altered.

This THOR product is sold by the Dealer or Agent as principal. The Dealer or Agent has no authority from THOR Technologies Pty Ltd to express any additional warranty or guarantee on the Company's behalf except as herein contained. This warranty only applies to the purchase and use of the product in Australia and New Zealand.

To the extent permitted by the relevant legislation in Australia and New Zealand, THOR Technologies Pty Ltd will not accept or have any other responsibility or liability whatsoever for negligence or liability for incidental, consequential, indirect or special damages, including without limitation, loss of actual or anticipated revenue or loss of data or for data being rendered inaccurate.

**Thor Technologies Pty Ltd**

1300 766 140

warranty@thortechnologies.com.au

Po Box 95, Karrinyup,  
Western Australia,  
Australia 6921

THOR TECHNOLOGIES COMMITMENT TO EXCELLENCE

# ALPHA 4

MODEL: A4

**Specifically built for home office equipment, computers, home theatre components, sewing machines, fridges, washing machines and for users wanting Thor's superior ac stepped power protection.**

PLEASE REVIEW THE FOLLOWING OPERATING INSTRUCTIONS TO ENSURE YOU RECEIVE MAXIMUM BENEFIT FROM THIS STATE OF THE ART FILTER AND PROTECTION DEVICE.

The THOR ALPHA 4, with 4 protected outlets, provides the highest specification premium-level protection available, significantly higher than our competitors. To receive optimum performance from this power board, please note these usage hints:

1. Plug the AC power cord from your ALPHA 4 into your wall outlet and observe the status of the two LED lights.
2. When lit, Power LED indicates the board is receiving power and all outlets will be allowing power through.
3. The PROTECTION ON LED indicator should always be on when the unit is plugged into a wall outlet. Failure for this LED to operate indicates the sacrificial circuitry has performed its function - preventing damaging spikes and surges from entering your equipment and the unit needs to be replaced. Contact THOR Technologies Pty Ltd for instructions on replacement.

**WHEN INSTALLING THE F TYPE PROTECTION FOR YOUR AERIAL (or ROUTER or MODEM), TV, FOXTEL YOU MUST ENSURE THE AC MAINS POWER CORD IS PLUGGED INTO A CORRECTLY INSTALLED WALL SOCKET FIRST.**

**THE PRODUCT MUST BE CONNECTED TO A CORRECTLY INSTALLED 240V MAINS WALL SOCKET WITH A PROTECTIVE EARTH CONNECTION BEFORE CONNECTING OR DISCONNECTING THE DATA/COMMUNICATIONS CABLES. CONNECTIONS, WHETHER SOCKET OUTLETS OR PRODUCTS MUST BE DONE BY QUALIFIED PERSONNEL AT ALL TIMES. IF THE SUPPLY CORD IS DAMAGED, IT SHALL BE REPLACED BY THE MANUFACTURER ITS SERVICE AGENT OR SIMILARLY QUALIFIED PERSON IN ORDER TO AVOID A HAZARD.**

This device has been designed for indoor use on AC mains and DC telecommunications systems which meet Australian and New Zealand AS/NZ standards.

1. Connect your incoming communication from your wall outlet directly to the INPUT F Type connector, marked Input on the end of ALPHA 4.
2. Now connect your equipment (TV, router, modem or other device with antenna connection) to the OUTPUT F Type connector.
3. Now all incoming data must pass through the protected outlet on your THOR ALPHA 4, providing you with the maximum protection and reliability your products deserve.



# THOR