


## WSWME31 and WSWME32

Tilt & Swivel Speaker Wall Mount For SONOS® Era 300™

INSTRUCTION MANUAL



### **We'll Make It Stress-Free**

If you have any questions along the way, just give us a call. **US:** +1 (800) 359-5520 • **EMEA:** +31 (0) 495 580 852 • **UK:** +44 (0) 800 056 2853

We're ready to help!

Texto en español, página 20

**Deutscher Text Seiten 24** 

Svensk text sida 28

中文文字说明请参见第 32 页

Texte français page 22

Nederlandse tekst op pagina 26

Русский текст: стр. 30

日本語は34ページ

## **IMPORTANT SAFETY INSTRUCTIONS**

— PLEASE READ ENTIRE MANUAL PRIOR TO USE — SAVE THESE INSTRUCTIONS

Before getting started, let's make sure this product is perfect for you!

#### This mount is designed to support only Sonos® Era 300™ speakers.

#### **A CAUTION:** Avoid potential personal injuries and property damage!


- Check your speaker owner's manual to see if there are any special requirements for mounting your speaker.
- Please read through these instructions completely to be sure you're comfortable with this easy install process.
- Do not use this product for any purpose not explicitly specified by manufacturer.
- Manufacturer is not responsible for damage or injury caused by incorrect assembly or use.
- The wall must be capable of supporting five times the weight of the speaker and mount combined.
- If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, contact Customer Service at +1 (800) 359-5520 (EMEA: +31 (0) 495 580 852; UK: +44 (0) 800 056 2853).


## **Speaker Weight Limit**DO NOT EXCEED





# Tools Needed Pencil Level Screwdriver | Intercolor | Int


## **Dimensions**














## **Supplied Parts and Hardware**


**A WARNING:** This product contains small items that could be a choking hazard if swallowed.


Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the damaged item to your dealer; contact Customer Service. Never use damaged parts!





**NOTE:** Not all hardware included will be used.

#### Quantities shown are for one speaker mount.












## BELOW Eye Level Installation







## ABOVE Eye Level Installation


(Speaker Upside Down)







## **Attach Speaker to Bracket**






Drywall covering the wall, must not be less than 1/2 in. (12.7 mm)










DO NOT use power tools for this step.


Both screws of MUST BE firmly tightened to prevent unwanted movement of the wall plate of Ensure the wall plate is securely fastened to the wall before continuing on to the next step, but DO NOT overtighten the screws.






- Drywall covering the wall, must not exceed 5/8 in. (16 mm)
- Minimum wood stud size: nominal 2 x 4 in. (51 x 102 mm) actual 1½ x 3½ in. (38 x 89 mm)
- Stud center must be verified










DO NOT use power tools for this step.


Both screws 06 MUST BE firmly tightened to prevent unwanted movement of the wall plate 05. Ensure the wall plate is securely fastened to the wall before continuing on to the next step, but DO NOT overtighten the screws.






- Mount the wall plate **05** directly onto the concrete surface (no wall covering)
- Minimum solid concrete thickness: 8 in. (203 mm)
- Minimum **concrete block** size: 8 x 8 x 16 in. (203 x 203 x 406 mm)










DO NOT use power tools for this step.


Both screws 06 MUST BE firmly tightened to prevent unwanted movement of the wall plate 05. Ensure the wall plate is securely fastened to the wall before continuing on to the next step, but DO NOT overtighten the screws.







## **Mount Assembly to Wall Plate**







## **Adjustments**








## **To Remove**





19



### **Thank you for choosing SANUS!** Please take a moment to let us know how we did:

#### Legrand AV Inc.

6436 City West Parkway Eden Prairie, MN 55344 USA

**US**: +1 (800) 359-5520

Legrand AV Netherlands B.V.

Franklinstraat 14 6003 DK Weert Netherlands

**UK**: +44 (0) 800 056 2853

**EMEA**: +31 (0) 495 580 852

**Authorized Representative for the UK** 

Starline Holding Technology Ltd. Unit C Island Road Reading RG2 ORP UK

Legrand AV Inc. and its affiliated corporations and subsidiaries (collectively, "Legrand"), intend to make this manual accurate and complete. However, Legrand AV makes no claim that the information contained herein covers all details, conditions, or variations. Nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

©2023 Legrand AV Inc. All rights reserved. SANUS is a brand of Legrand.
All other brand names or marks are used for identification purposes and are trademarks of their respective owners.