

FLEXI-ROLLER


AF-8000

PN. 093-8000



AGROWPLOW®


AF-8000 Frame Assembly



| Item No. | Description | Qty. | Part No. |
|----------|--------------------|------|----------|
| 1 | Frame | 1 | 093-3008 |
| 2 | Stand | 2 | 093-3057 |
| 3 | Top Linkage Pin | 1 | 140-006 |
| 4 | Bottom Linkage Pin | 2 | 140-005 |
| 5 | Lynch Pin | 3 | 140-041 |
| 6 | Top Stand Pin | 2 | 093-4135 |
| 7 | Bottom Stand Pin | 2 | 093-4136 |
| 8 | Circlip | 4 | 115-720 |
| 9 | R' Pin | 4 | 140-4012 |




AF-8000 Rotor Assembly



| Item No. | Description | Qty. | Part No. |
|----------|------------------------|------|------------|
| 1 | Rotor | 2 | 093-3008 |
| 2 | Ring | 132* | 093-3001 |
| 3 | Ring Stopper | 2 | see page 3 |
| 4 | Spacer | 4 | 093-4020 |
| 5 | Outer Bearing Assembly | 2 | see page 4 |
| 6 | Inner Bearing Assembly | 1 | see page 5 |
| | | | |

AGROWPLOW


AF-8000 Ring Stopper Assembly



| Item No. | Description | Qty. | Part No. |
|----------|------------------------|------|----------|
| 1 | Stopper Plate | 1 | 093-3014 |
| 2 | Bolt 3/4" UNC x 2 1/2" | 3 | 133-350 |
| 3 | Nut 3/4" UNC | 3 | 134-120 |
| | | | |
| | | | |
| | | | |

AGROWPLOW


AF-8000 Inner Bearing Assembly



| Item No. | Description | Qty. | Part No. |
|----------|--------------------|------|----------|
| 1 | Bearing Housing | 2 | 138-052 |
| 2 | Bearing | 2 | 115-704 |
| 3 | 5/8" Spring Washer | 4 | 135-070 |
| 4 | 5/8" UNC Nut | 4 | 134-090 |
| 5 | Bolt 5/8" UNC x 4" | 4 | 133-300 |
| | | | |
| | | | |



AF-8000 Outer Bearing Assembly



| Item No. | Description | Qty. | Part No. |
|----------|------------------------|------|----------|
| 1 | Bearing Housing | 2 | 138-052 |
| 2 | Bearing | 2 | 115-704 |
| 3 | 5/8" Spring Washer | 4 | 135-070 |
| 4 | 5/8" UNC Nut | 4 | 134-090 |
| 5 | Bolt 5/8" UNC x 2 1/2" | 4 | 133-260 |
| | | | |
| | | | |

AGROWPLOW