


**TREMORS™**  
by **HERQUAKE™**

INSTRUCTIONS



**HERQUAKE™**

## INSTRUCTIONS



### CHARGING:

Tremors uses any standard USB wall plug for charging (not included). Locate the piercable charging port on your toy and push the tip of the included USB cable through the skin to pierce it. The port is located on the side of your toy near the end with the button. Plug the other end into any standard USB port (the button will begin flashing) and let it charge fully before using. The button will stop flashing when it is fully charged and ready to use.

### USE:

Always use a body-safe, water-based personal lubricant to ensure the best experience. (Silicone-based lubes will break down the silicone covering of your toy.) Apply liberally to the toy and any intimate areas that it will come into contact with. You can never use too much lube!

Tremors will not accidentally turn on because it features an integrated travel lock. To turn Tremors on, hold the power button for 3 seconds (you will see the button light up). Press again to start the

first of seven vibration/thrusting/rumbling modes. A simple click of the button cycles through the different sensations.

Tremors can be enjoyed through internal or external stimulation, whatever it takes to fulfill your orgasmic desires.

To turn off Tremors after use and re-enable your travel lock, simply hold the button down for 3 seconds (the button light will turn off).

After use, clean and dry properly. Antibacterial Toy cleaners are highly recommended to ensure that you get to enjoy Tremors over and over again.

Always properly wash and sanitize all adult toys before and after use.