

S&G MECHANICAL LOCK OPENING DIRECTIONS



OPENING DIRECTIONS:

Important: Turn the combination dial slowly and evenly. Do not turn back to regain alignment if you rotate past the number. If an error is made, re-dial the entire combination. Do not count turns. Count how many times each number is aligned with the opening index (at the 12 o'clock position). Always view the dial and ring straight on, not at an angle.

To Open:

1. Turn dial left Counter-Clockwise, aligning the first number with the opening index the fourth time it comes to the index.
2. Turn dial right Clockwise, aligning the second number with the opening index the third time it comes to the index.
3. Turn dial left Counter-Clockwise, aligning the third number with the opening index the second time it comes to the index.
4. Turn dial right Clockwise until dial comes to a complete stop around 87.
5. To relock and secure the combination lock, turn the dial to the left Counter-Clockwise at least four revolutions.