ASTRO KITTY USER MANUAL

Formerly known as the C5. Same Great Product, Fresh Name!





855-386-2665 www.coolazone.com

THE BREEZE COLLECTION



Lunar Breeze



Polaris Breeze



Cosmic Breeze



Mercury Breeze



Neptune Breeze



Jupiter Breeze

THE CHILL COLLECTION



NebulaChill



AstroChill



MeteorChill



StratoChill

TABLE OF CONTENTS

Specifications ————	page 2
Safety ————	page 2
Quick Setup Guide————	page 3
Operating Instructions ————	page 3
Control Board Interface ————	page 3
Routine Maintenance ————	page 4
Exploded Drawing————	page 4
Limited Warranty —————	page 5
Troubleshooting ————	page 5
Frequently Asked Questions ———	page 5

SPECIFICATIONS

Desktop Evaporative Air Cooler		
Model Number	CAZ59EC	
Effective Cooling Area (sq ft)	up to 4	
Max Airflow (CFM)	59	
Water Tank (oz)	13.5	
Dimensions (in)	6.5 (h) x 6.5(w) x 6.5(d)	
Power (W)	5	
Voltage (V)	110	
Weight (lb)	2	
Made in China		

SAFETY

- Do not operate any evaporative cooler with a damaged cord or plug.
- Read the evaporative cooler's manual and labels thoroughly before use.
- Always unplug the evaporative cooler before performing maintenance or repairs.
- Do not stick your hands in the evaporative cooler while it is plugged in.
- Remove the plug from the electrical outlet by pulling on the plug, not the power cord.
- Operation near open flames or sparks is not recommended.
- When cleaning your evaporative cooler, ensure water does not get into the Fan Motor or electrical system to prevent damage.
- If the evaporative cooler is damaged or malfunctioning, do not operate it. Refer to the Limited Warranty or Troubleshooting sections of this manual.


QUICK SET UP GUIDE

- Move the unit to the desired location before filling.
 WARNING: Moving the unit with a full Water Tank will cause damage to the product housing.
- To fill the Water Tank, lift the Water Tank Fill Hatch located on top of the unit and pour <u>13.5 ounces</u> of water down into the Water Tank.
 WARNING: Do not overfill the Water Tank.
- 3. Using the USB cord (included with the fan) plug the unit into an electrical outlet.
- 4. Turn the unit on by the pressing the **ON/OFF** button on the Control Board Interface.
- 5. Set the speed to the desired level. Speed range: low and high.
- 6. Enjoy your Astro Kitty by Cool-A-Zone!

OPERATING INSTRUCTIONS

- 1. Press the **ON/OFF** button one time to power on the unit. Press this button again to turn the unit off.
- Press the LOW SPEED button to activate low speed.
- 3. Press the **HIGH SPEED** button to activate high speed.

CONTROL BOARD INTERFACE



ROUTINE MAINTENANCE

Ensure that **BEFORE** doing any cleaning or maintenance, your Cool-A-Zone unit is powered **OFF** and **UNPLUGGED!**

- 1. **Exterior Cleaning:** We recommend cleaning exterior surfaces with soap and water (or a mild cleaner) and a soft cloth. Avoid abrasive cleaners or alcohol-based chemical cleaning agents.
- Honeycomb Cooling Pad Cleaning: We recommend removing the Honeycomb Cooling Pad and cleaning with a soft-bristled brush every two weeks (more frequently if the unit is operated in a dust-heavy environment).
 - To deep-clean your Honeycomb Cooling Pad, soak in a 50/50 solution of water and vinegar. You may use a soft-bristled brush to gently scrub excess residue and debris from the Honeycomb Cooling Pad. Rinse thoroughly after cleaning.
- **3. Honeycomb Cooling Pad Drying:** The Honeycomb Cooling Pad should be dried if you are planning to store the unit.
- **4. Honeycomb Cooling Pad Replacement:** The Honeycomb Cooling Pad should be replaced every 9 to 12 months, or more frequently depending on environment, use or water hardness.
- **5. Water Tank Draining:** Drain water at the end of every use to increase longevity of the unit.
- **6. Water Tank Cleaning:** We recommend cleaning the tank by hand bimonthly. More frequent cleaning may be required for humid climates or dust-heavy environments.
- 7. Unit Storage: Prior to storing your unit, please ensure that you have cleaned and dried your Water Tank, Honeycomb Cooling Pad, and exterior housing. Store covered until needed again.

EXPLODED DRAWING

For the detailed exploded drawing with part names and numbers visit our website at www.coolazone.com/exploded-drawings

LIMITED WARRANTY

Visit our website at www.coolazone.com/warranty to learn about the Limited Warranty and to register your unit.

TROUBLESHOOTING

BEFORE performing any internal maintenance, be sure to **POWER OFF** and **UNPLUG** your unit!

If your unit malfunctions, unplug it for one minute before replugging and trying any of the following solutions.

Malfunction	Reason	Solution
The Fan Motor does not respond to the Control Board Interface	Power Control Board failure Control Board Interface failure	 Change the Power Control Board Change the Control Board Interface

FREQUENTLY ASKED QUESTIONS

1. Is the evaporative cooler an air conditioner?

Our line of evaporative coolers are not air conditioners, however we do offer a line of portable air conditioners and dual-use air conditioner/heater units.

2. Can I adjust the temperature on the evaporative cooler?

No, the temperature cannot be adjusted. The display is only reflecting the temperature of the air emitted from the unit.

3. What is the best way to reach the Cool-A-Zone team?

The best way to reach someone quickly is via the chat at www.coolazone.com, email us at info@coolazone.com, or call directly at 1-855-386-2665.

For answers to more questions please visit our website at www.coolazone.com/faq

Staying cool is a Breeze!





Customer Service Contact:

info@coolazone.com 1-855-386-2665

The digital version of this user manual is available for download. Visit www.coolazone.com or call 1-855-386-2665 for more information