



	Part Name
1	Top Panel
2	Capacitance of Compressor
3	Capacitance Clamp
4	Board Cover
5	Control Board
6	Power Top Panel of the Air Duct
7	Capacitance of Motor
8	Power Board
9	Up Duct Volute
10	Copper and Aluminum Evaporator
11	Up Evaporator
12	Evaporator Bracket Up
13	Up Air Inlet Network
14	Up Water Inlet Network
15	Wind Wheel
16	Down Duct Volute
17	Cover of Up Water Tank
18	Condensing Sheet
19	Power Cord
20	Synchronous Motor
21	Cross Blade Connecting Rod
22	Cross Blade Connecting Rod
23	Air Outlet Panel
24	Cross Blade
25	Float Switch
26	Sealing Water Plug
27	Down Water Intake Network
28	Down Air Intake Network

	Part Name
29	Evaporator Bracket Down
30	Down Evaporator
31	Back Panel
32	Up Water Tank
33	Safe Net
34	Vertical Fan Blade
35	Decorative Sheet
36	Vertical Fan Blade Fixing Frame
37	Left Panel
38	Air Suction Pipe
39	Escape Pipe
40	Right Panel
41	Water Tank Water Plug
42	Water Inlet Connecting Pipe
43	Water Inlet Cover
44	Bellows
45	Bellows of Up Water Tank
46	Water Tank Plug
47	Fixing Plug
48	Compressor
49	Cover of Condenser Pipe
50	Main Support
51	Main Support 2
52	Front Decorative Sheet
53	Water Pump in Down Water Tank
54	Condensor Pipe
55	Cover of Down Water Tank
56	Float Switch
57	32MM Support
58	Up Water Gauge
59	Down Water Tank
60	Down Water Gauge
61	Castor



StratoChill Exploded Drawing

