

Quick Start Guide

CK14/1 PRO 98147 / CK14/1 BSE 98145

1. Assembly



After first removing the handle screw, insert handle into the hole on top of the vacuum cleaner.



Line up the small hole on the handle with the small hole on the vacuum cleaner and insert the screw. Make sure the screw is tightly secured.

2. Operating Instructions



To turn the vacuum on, push the switch located the rear of the unit to the (I) position. To turn the vacuum off, push the switch to the (O) position.



To release the handle, step on the left rear corner of the vacuum cleaner and pull the handle back.

3. Additional Parts Required

There are no additional part required.