

Quick Start Guide

Windshear™ Downdraft 98784

1. Assembly

1



Remove the unit from the box, unwrap the cord. Insert the (4) casters into the (4) receivers in the bottom of the unit.

2. Operating Instructions

1



Plug in to a standard outlet with the correct voltage and amperage for the unit and place the dryer in the desired operating position.

2



Set the switch at the desired speed: low or high.

3. Additional Parts Required

There are no additional parts required for the unit.