

ALPINE SWAG

INSTRUCTION MANUAL



KSS1001

INSTRUCTION MANUAL

CONTENTS

- 1 x Alpine swag
- 3 x Aluminium swag poles
- 1 x 50mm high-density foam mattress
- 8 x Pegs
- 2 x Guy ropes
- 1 x Aluminium pole repair sleeve




PLEASE NOTE

Prior to first use of the Alpine swag, it is important to remove the mattress from its compression sleeve and allow it to expand.

Seasoning the swag is not essential but is recommended. For full instructions on seasoning your DARCHE swag, see How to Season Your Swag (page 7).


Step 1



Unroll the swag onto a flat, well-drained area free of sharp objects that may penetrate the swags PVC floor. Assemble the three aluminium poles. The poles are different in length, and correspond to specific placement on the swag. The head of the swag requires the longest pole, centre pole uses mid sized pole and foot pole requires the shortest length pole.


Step 2

Feed the head pole through the sleeve on the top of the swag and insert it into one of the pins, while you support the weight of the swag with your other hand.




NSTRUCTION MANUAL

Step 3




Before attempting to insert the aluminium pole into the second pin, ensure the pole sleeve is centred on the pole. Place you palm under the pole end, and push upward until there is a gap between the pole end and the second pin. Insert the second pin.

MPORTANT: DO NOT BEND THE POLE TO INSERT THE SECOND PIN.



Repeat this process for the other pole whilst correcting the swag skin as you assemble.


Step 4



Clip the swag to the aluminium poles. A good technique for attaching the clips is to alternate from one side to the other - top left, then top right, second left and then second right and so on. Repeat this process for assembling the centre and foot poles.



Step 5



Insert a guy rope through the eyelets at the ends of the swag, loop the guy rope around the steel pegs and secure to the ground. Tension the guy rope. Peg out the corners if necessary. Your Alpine swag set up is now complete.



INSTRUCTION MANUAL

PACK DOWN


- 1. Partially close all the zips, door covers and window flaps, leaving them slightly open will allow for the air to escape while rolling up. Remove pegs and guy ropes.
- 2. Unclip the swag from the aluminium poles one end at a time.
- 3. Disassemble the all poles in preparation for step 4 below.
- 4. While the swag is laid out flat, bring any overhanging canvas and ropes into the centre of the swag. Beginning from either end, start rolling the swag as tightly as possible in an attempt to expel as much air as possible to achieve a compact roll. Tip: Using your knees while rolling will assist in getting the swag as compact as possible. Just before completing the rolling process, place all the disassembled poles between the fabric and continue rolling process to the end.
- 5. Bring the two compression straps together and loop through the double D-rings, do not over tighten the straps.

NOTE

Allow a wet or damp swag to dry thoroughly before pack down. If this is not possible, unroll swag a soon as possible. Allow to fully dry out before re-packing and storing.

REPAIR KIT

Swag poles are the bones of your swag set up. At times mishaps or bad luck can play a part when they break, ruining a great day out. We provide a swag pole sleeve for a quick and easy fix, to have your swag up and in working order.





SPARE PARTS LIST

For a full list of Spare Parts available refer to DARCHE.COM.AU

HOW TO SEASON YOUR DARCHE SWAG

The best way to season your swag is to set up outdoors and completely soak the exterior material of the swag with a hose. Allow the swag to dry completely. Repeat this process 2-3 times. Seasoning the swag will allow the canvas material to swell and will help to fill any stitching holes, providing an additional level of weather protection. Ensure the swag is completely dry before packing away.

CARE & STORAGE INSTRUCTIONS

- 1. Remove dirt with a soft brush and cold water after use.
- 2. Do not clean with soap, detergent, petrol, oil or solvents.
- 3. Ensure swag is completely dry before storing.
- 4. Do not store directly on concrete floors. A dry shelf in your shed or a cupboard is a perfect spot for your swag when not in use.
- 5. If spot mould is visible, brush it off with a stiff bristle nylon brush and vacuum the area to get rid of any residual spores.
- 6. Leaving your swag rolled too tightly for long periods of time may result in the mattress taking a while to bounce back. If it's been a while since your last adventure, open your swag a few days before you leave and allow the mattress to expand. Re-pack your swag and have a great weekend.

INSTRUCTION MANUAL

Designed and tested in Australia for Australian conditions.

A brand by Charles Parsons.

Telephone 1300 367 695 I Email: info@DARCHE.com.au

75 Heyington Avenue, Thomastown VIC 3074, Australia.

DARCHE: LEADERS IN OUTDOOR DESIGN, PROUDLY AUSTRALIAN.

Due to our policy of continual product development, the specifications, colours and features may vary.

V1-April 2021



