

## Climbing Playset >> Pikler Triangle



# **Assembly** Instruction Manual



# Pikler Triangle Assembly Instruction Manual










Assembly time: Approx 20 mins.



(a) Allen key 1 No.

(b) Allen bolts (Large) 6 Nos. (attached in


material)

(c) Allen bolts (Small) 22 Nos. (attached in


beech rods)



(d) **Knob Screw** 2 Nos.



(A1-A2)Side Frame with Top Triangle 2 Nos.



(B1-B2)Side Frame 2 Nos.




**Beech Wood Rods** 15 Nos.

# Pikler Triangle Assembly Instruction Manual



### Step 1

Attach the beech wood rods to the red triangle-large frame structure. Use large allen bolts in the red triangle area (2 Large allen bolts on each side). To attach the remaining 6 beech wood rods use small allen bolts.




# Pikler Triangle

### **Assembly Instruction Manual**



## Step 2

Attach the small frame and beech wood rods with the red triangle with allen bolts. Large allen bolts should be used in the red triangle and in all other beech wood rods, small allen bolt should be used.



## Pikler Triangle

#### **Assembly Instruction Manual**



### Step 3

You will find three position holes in the red triangle. Position the side frame in such a way that the position hole in the side frame and red triangles aligns. Use the black screw knob to screw it to the position.

Three position holes in the red triangle will help you to position the pikler triangle in three different angles.

