

# Manual – performance set Brekr B4000

This manual explains the installation and operation of the performance set for the Brekr B4000. The installation of the performance set is explained in a step-by-step plan on page two of this document. If you have any questions about the installation, please send an email to: info@vdatuning.com.

| The use and consequences of the performance set is entirely at your own risk. |  |
|---|--|
|   |  |

## **Operations performance set Brekr B4000**

#### **Activation performance set:**

- **1. Put the Brekr in drive mode 4.** In other positions the performance set often does not work. This depends on which software is on the Brekr.
- 2. **Press the remote control.** Point the remote control towards the built-in performance set.
- **3. Drive mode 4 remains permanent.** It is no longer possible to switch to another drive mode. This is the sign that the performance set is active.

#### Deactivation performance set (several ways possible):

- 1. **Press the remote control again.** Point the remote control again towards the built-in performance set. The Brekr goes automatically into a different drive mode, this is also the sign that the performance set is deactivated. It is possible again to switch to another drive mode.
- 2. **Press the P button when stationary.** The performance set is deactivated and must be reenabled.
- **3. Fold out the side stand.** The performance set is deactivated and must be re-enabled.
- **4. Turn off the Brekr.** The performance set is deactivated and must be re-enabled.



.....



## Installation performance set

**Step 1:** Open the saddle and remove the battery.

**Step 2:** Hump with the Brekr key, the right plate to the front.



### Step 3:

Bend the plate carefully to the center. Slide the plate out of the left guide rail.





### Step 4:

Disconnect the JWPF connector using a small flat head screwdriver.





### Step 5:

Stick the Velcro strip vertically under the GPS cable.







**Step 6:** Connect the cables (see picture). There is only one way possible.





**Stap 7:**Stick the performance set on the Velcro strip.



Stap 8:

Bend the plate to the center and slide the left side back into the guide rail. Press the plate down slightly again so that it returns to its original state.







Stap 9:

Slide the battery back in and you're ready to go (fast)!