

LIGHTSON GARDEN PLUG & PLAY

OPEN
HERE



INSTRUCTIONS

Mounting of light source

Open the lamp by unscrewing the back end of the lamp cover (see image).



Mount the light source.

Screw back the lamp cover. Make sure it's properly tightened, to avoid water getting in.

Note! Do not open the lamp in the top glass area.