




Upper Bounce U-Bolt User Manual


Assembly, Installation, Care, Maintenance and Use Instructions.



U-BOLTS		
1.5 inch legs	1.75 inch legs	
UBHWD-UB-12 (Set of 12) UBHWD-UB-16 (Set of 16) Fits for Poles 1" and 1.5" Fits for Legs up to 1.5" diameter	UBHWD-1.75-UB-8 UBHWD-1.75-UB-12 UBHWD-1.75-16 	UBHWD-U-UB-12 UBHWD-U-UB-16 
Fits for Poles 1" and 1.5" Fits for Legs up to 1.75"		

MEASURING TIP FOR U BOLT:

Measure the diameter of your trampoline leg and make sure that you have the right size u-bolt. Example: the trampoline legs measures 1.5", you need a U-bolt for 1.5". Our U-bolts fit for connecting poles which measures 1" or 1.5". (If you have 1.75" connector, these U-bolts won't fit.)




STEPS FOR CONNECTING POLES USING U BOLT


- Take the clamp and clasp the trampoline pole into the rounded end of the clamp. Make sure that the black rubber cap of the lower pole faces down.

This step is optional for the 1.5" U-bolts
(This is NOT an option for the bigger size U-bolts)


- (a) If the pole fits too loosely, insert the green rounded piece before clamping the pole so clamp will tightly clasp the pole. If the pole is too thick and does not fit into the hole, remove the green rounded piece to create more space for the pole. You should then be able to clasp the trampoline pole into the clamp.




- (b) Once the pole is securely inserted into the clamp, you should now insert the plastic bracket until you reach the pole.




- Be aware that the mark on the lower pole needs to align with the trampoline frame. If there is no line on the pole then please have it attached 18" below the frame.



- The set comes with 2 clamps per pole. One being attached 2" below frame, while the other being attached 2" above the end of the lower pole.






- After inserting the plastic bracket, clasp the leg into the clamp. Secure tightly with the steel brackets and nuts.



Manual Version #02

REPLACEMENT PARTS LIST

If you need to replace any part of your trampoline, you can look for the Upper Bounce parts list below for each item model name :

SIZE	JUMPING MAT  Example UBMAT-7.5 (Frame size) -42 (Amt of springs) -5.5 (Spring size)	SAFETY PADS  Example UBPAD-S (Super) -7.5 (Frame size) -B (Blue) / P (Premium) / G (Green) / BG (Blue Green)	SAFETY NETS				WEATHER COVERS  Black Example UBWC-12 (Frame size) -BK (Black) Blue Example UBWC-14 (Frame size) -BL (Blue)
			Strap Type Net (Inside) Example UBNET-7.5 (Frame size) -6 (Amount of poles)-IS	Strap Type Net (Outside) Example UBNET-7.5 (Frame size) -6 (Amt of poles)-OS	Sleeves on Top - Net (Arch) Example UBNET-7 (Frame size) -3 (Amt of arches)-AST	For Curved Poles Example UBNET-8FG (Frame size) -6 (Amount of poles)	
			UBNET-7.5-6-IS UBNET-7.5-6-IS	UBNET-7.5-6-OS UBNET-7.5-6-OS	UBNET-6-3-AST UBNET-7-3-AST	UBNET-8FG-6 UBNET-11FG-6	
SIZE 6							
SIZE 7							
SIZE 7.5	UBMAT-7.5-42-5.5	UBPAD-S-7.5-B				UBWC-7.5	
SIZE 8	UBMAT-8-48-5.5 UBMAT-8-56-5.5 UBMAT-8-60-5.5	UBPAD-S-8-B				UBWC-8	
SIZE 10	UBMAT-10-56-5.5 UBMAT-10-64-5.5	UBPAD-S-10-B	UBNET-8-6-IS UBNET-8-4-IS	UBNET-10-8-OS		UBWC-10	
SIZE 11	UBMAT-11-60-5.5 UBMAT-11-72-5.5			UBNET-11-3-AST		UBWC-11	
SIZE 12	UBMAT-12-60-7 UBMAT-12-72-5.5 UBMAT-12-84-5.5 UBMAT-12-84-6.5 UBMAT-12-80-5.5	UBPAD-S-12-B UBPAD-S-12-G UBPAD-S-12-BG UBPAD-P-12-B	UBNET-12-8-IS UBNET-12-4-IS UBNET-12-6-IS	UBNET-12-4-OS UBNET-12-6-OS	UBNET-12-2-AST UBNET-12-3-AST UBNET-12-4-AST	UBWC-12-BK UBWC-12-BL	
SIZE 13	UBMAT-13-72-5.5 UBMAT-13-80-5.5 UBMAT-13-80-7	UBPAD-S-13-B	UBNET-13-6-IS UBNET-13-8-IS	UBNET-13-6-OS UBNET-13-8-OS	UBNET-13-2-ASTR UBNET-13-3-AST UBNET-13-4-AST	UBWC-13	
SIZE 14	UBMAT-14-72-5.5 UBMAT-14-72-7 UBMAT-14-80-5.5 UBMAT-14-80-7 UBMAT-14-84-7 UBMAT-14-84-8.5 UBMAT-14-88-7 UBMAT-14-88-8.5 UBMAT-14-80-7 UBMAT-14-96-7 UBMAT-14-96-8.5	UBPAD-S-14-B UBPAD-S-14-G UBPAD-S-14-BG UBPAD-P-14-B	UBNET-14-4-IS UBNET-14-6-IS UBNET-14-8-IS	UBNET-14-6-OS UBNET-14-8-OS	UBNET-14-3-AST UBNET-14-4-AST	UBWC-14-BK UBWC-14-BL	
SIZE 15	UBMAT-15-84-6.5 UBMAT-15-90-7 UBMAT-15-96-7 UBMAT-15-96-8.5 UBMAT-15-96-6.5 UBMAT-15-100-7	UBPAD-S-15-B UBPAD-S-15-G UBPAD-S-15-BG UBPAD-P-15-B	UBNET-15-6-IS UBNET-15-8-IS	UBNET-15-6-OS UBNET-15-8-OS	UBNET-15-3-AST UBNET-15-4-AST	UBWC-15-BK UBWC-15-BL	
SIZE 16	UBMAT-16-108-7.5	UBPAD-S-16-B	UBNET-16-6-IS			UBWC-16	
SIZE 17					UBNET-17FG-8		
		Safety Pads Square	Arch Net - Square	Oval Net	Universal Net Type		
	Square Mat	UBPADSQ-13	UBNETSQ-1313-4	UBNETO-1614 UBNETO-1715	UBNET-U1 UBNET-U2		
	Oval Mats	UBMATO-1614-96-7 UBMATO-1715-96-7					
	Band Mats	UB-BMAT-1273 UB-BMAT-1378 UB-BMAT-1484 UB-BMAT-1590					
	OTHER TYPE	UBMATSQ-13					