



# 键盘用户手册

## MOD007<sup>PC</sup> <sup>(EU)</sup>

User Manual  
Benutzerhandbuch


快速开始指南 ▶  
Quick Start Guide

# 感谢您购买及使用本产品



为了给您带来更好的使用体验，在使用产品前请仔细阅读本说明书，并请妥善保管，以便日后参观。

## 包装内容



## 系统需求


Windows®XP / Vista / 7 / 8 / 10或更高版本

## 安装步骤

将键盘USB连接线插入电脑的USB接口即可开始使用。

型号	MOD007PC-EU	类型	75%配列机械键盘
尺寸	约333*147*32mm	键盘结构	Gasket垫片式 单颗开槽PCB
重量	约1kg		
键帽	PBT材质	外壳	PC材质
轮询率	1000Hz	连接方式	Type-C to USB-A
热插拔	支持	多媒体键	支持Win/Mac
全键无冲	支持	按键自定义	支持Akko驱动 自定义设置

## MOD007PC 组合键功能




Fn+	F1	=	我的电脑
	F2	=	电子邮件
	F3	=	Windows搜索
	F4	=	浏览器主页
	F5	=	多媒体播放器

Fn+	F6	=	播放 / 暂停
	F7	=	上一首
	F8	=	下一首
	C	=	计算器
	I	=	Ins

Fn+	P	=	Print SCR
	w	=	将 W A S D 与 ↑ ↓ ← → 键对调

## MOD007PC 系统功能 (Windows)




锁Win键
Fn + 左Win

恢复出厂设置
长按 FN+~ 5秒

WIN系统 ⇌ MAC系统
Fn + O 3秒

切换成菜单键 (可记忆)
长按 Fn + 右CTRL 3秒

## MOD007PC 系统功能 (Mac)



F1 降低显示屏亮度

F2 增加显示屏亮度

F3 开放任务控制

F4 呼出Siri

F7 上一曲

F8 暂停/播放(音频)

F9 下一曲

F10 静音

F11 调低音量



F12 调高音量

左Win Option

左Alt Command

右Alt Command

## MOD007PC 旋钮功能说明



### 旋钮功能

按下静音切换  
旋钮为音量加减

## 按键自定义及驱动说明

1. 键盘可搭配驱动以实现按键自定义修改，最多可同时储存4个常规配置层和2个FN配置层
2. 驱动内可实现1-10档键盘灵敏度调节，去除按键抖动，以适应不同输入场景下的打字习惯
3. 支持宏定义录制，可实现各类组合键的快速触发。关于调用说明，请在Akkogear官网下载Akkogear Cloud驱动
4. 驱动下载地址：[akkogear.eu](http://akkogear.eu)

## Akko保修和服务声明

1. Akko为中国大陆的客户提供一个保修。对于其他地区，请联系您的卖家（Akko分销商）以了解具体的保修政策。
2. 如果保修期到期，客户需要支付维修费用。如果用户喜欢自己修理键盘，Akko也会提供说明。用户应对自行修复过程中发生的任何损失承担全部责任。
3. 在未经制造商/卖方指示的情况下拆开键盘将立即导致保修无效
4. 官方售后服务时间为每周一至周五上午10:00至下午18:00  
节假日以国家法定节日休息为准。
5. 退货和保修政策在不同的平台上可能有所不同，并在购买时取决于具体的经销商。

公司：深圳银宸科技有限公司

地址：深圳市宝安区松岗街道碧头第一工业区朗碧路33号

电话：0755-23216420

网址：[akkogear.eu](http://akkogear.eu)

产地：中国·深圳

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou First Industrial Zone, Bao'an District, Shenzhen, China



**WARNING:**  
Water and Beverages can't be  
poured into the Keyboard.




中国制造/Made in China

### 注意 事项

人为损坏不局限于键盘进水、高处坠落、过度用力拉扯线材等，键盘为电子产品  
请按照电子产品保护方式爱惜使用。

To provide you with a better user experience, please read this manual carefully before using the product.

## Packing List



## System Requirement


Windows®XP / Vista / 7 / 8 / 10 or higher version

## Connectivity Method

Connect the keyboard to your computer by plugging in the USB cable into an available USB port to start using it.

Model number	MOD007PC-EU	Type	75% Layout Mechanical Keyboard
Size	Approx. 333*147*32mm	Keyboard Construction	Gasket Mount
Weight	Approx. 1kg		Per-Key Flex-Cut PCB
Keycap	PBT Material	Case Material	PC Material
Polling Rate	1000Hz	Interface	Type-C to USB-A
Hot-swappable	5-Pin Socket	Multimedia Keys	Win/Mac Support
N-Key Rollover	Support	Key Customization	Support for Akko driver customisation

## MOD007PC HotKeys




Fn+	F1	File Explorer
	F2	E-mail
	F3	Windows Search
	F4	Browser Homepage
	F5	Media

Fn+	F6	Pause/Playback
	F7	Previous Song
	F8	Next Song
	C	Calculator
	I	Ins

Fn+	P	Print SCR
	w =	Swap W A S D with ↑ ↓ ← →

## MOD007PC System Commands (Windows)



### Lock Windows Key

Press Fn and  
Left Win Key

### Switch to Menu Key (Memorable)

Long press Fn to add  
Right CTRL for 3 seconds


### Restore Factory Settings

Hold down Fn and  
press ~ Key for 5S

### WIN system ⇌ MACsystem



Hold down Fn and  
press O Key for 3S

## MOD007PC System Commands (Mac)



F1	Decrease display brightness	F7	Skip back (Audio)	F11	Decrease Volume
F2	Increase display brightness	F8	Pause/Play (Audio)	F12	Increase Volume
F3	Open mission control	F9	Skip forward (Audio)	Left Win	Option
F4	Activate Siri	F10	Mute	Left Alt	Command
Right Alt	Command				

## MOD007PC Knob Function Description



### Knob function

Press Mute Toggle  
The knob adds or subtracts volume



## Key Customisation And Driver Instructions

1. The keyboard can be customised with the driver to achieve key customisation, with a maximum of 4 regular configuration layers and 2 FN configuration layers stored at the same time.
2. 1-10 levels of keyboard sensitivity adjustment can be achieved within the driver to remove key jitter to suit typing habits in different input scenarios.
3. Supports macro recording, allowing for quick triggering of various key combinations. For instructions, please download the Akko Cloud driver from the Akko website.
4. Download the driver at: [akkogear.eu](http://akkogear.eu)

## AKKO Warranty and Service Statement

1. Akko provides One-Year warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for specific warranty policy.
2. If the warranty window expires, customers need to pay for repairs. Akko will also provide instructions if users prefer to repair the keyboard by themselves. However, users shall take full responsibility for any loss happened during self-repair.
3. Disassembling the keyboard without manufacturer/seller's instruction will immediately void the warranty.
4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Bao'an District, Shenzhen, China

Tel: 0755-23216420

Website: [akkogear.eu](http://akkogear.eu)

Origin: Shenzhen, China



**WARNING:**

Water and Beverages can't be poured into the Keyboard.



[instagram.com/akkogear.de](https://www.instagram.com/akkogear.de)



[facebook.com/akkogear.eu](https://www.facebook.com/akkogear.eu)

中国制造/Made in China



[tiktok.com/@akkogear.de](https://www.tiktok.com/@akkogear.de)

### Precautions

Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.

