



M6 QMK User Manual

用户手册

Benutzerhandbuch

快速开始指南 ▶


Quick Guide

感谢您购买及使用本产品



为了给您带来更好的使用体验，在使用产品前请仔细阅读本说明书，并请妥善保管，以便日后参观。

包装内容



系统需求

Windows®XP / Vista / 7 / 8 / 10或更高版本


安装步骤

将键盘USB连接线插入电脑的USB接口即可开始使用。

独立指示灯

- 1.大小写指示灯：Cap键灯位，开启为白灯
- 2.锁Win指示灯：Win键灯位，锁Win为白灯

M6 QMK组合键功能




FN+	1	=	F1
	2		F2
	3		F3
	4		F4
	5		F5
	6		F6
	7		F7
	8		F8

FN+	9	=	F9
	0		F10
	-		F11
	=		F12
	ESC		~
	PGUP		Home
	PGDN		End
	I		insert

FN+	P	=	PrtSc
	C		计算机
	M		静音
	<		音量减小
	>		音量放大
	W		将WASD与上下左右调换

M6 QMK系统功能 (Windows)



锁Win键

FN + WIN


恢复出厂设置

FN + Backspace 3秒

WIN系统 ⇌ MAC系统

FN + O


M6 QMK系统功能 (Mac)



FN+	1	亮度-
	2	亮度+
	3	开放任务控制
	4	= 呼出siri
	7	上一曲
	8	播放/暂停
	9	下一曲

FN+	0	静音
	-	音量-
	=	音量+
	R_Alt	R_command
	L_Alt	L_command
	L_Win	L_option

M6 QMK灯光调节



FN+Del 按照QMK标准，切换18种灯效

FN+ ;	灯光速度变慢	FN+ ↑	灯光变亮	FN+ ←	切换灯光饱和度-
FN+ '	灯光速度变快	FN+ ↓	灯光变暗	FN+ →	切换灯光饱和度+

MONSGEEK保修和服务声明

1. MONSGEEK为中国大陆的客户提供一年保修。对于其他地区，请联系您的卖家（MonsGeek分销商）以了解具体的保修政策。
2. 如果保修期到期，客户需要支付维修费用。如果用户喜欢自己修理键盘，MonsGeek也会提供说明。用户应对自行修复过程中发生的任何损失承担全部责任。
3. 在未经制造商/卖方指示的情况下拆开键盘将立即导致保修无效
4. 官方售后服务时间为每周一至周五上午10:00至下午18:00
节假日以国家法定节日休息为准。
5. 退货和保修政策在不同的平台上可能有所不同，并在购买时取决于具体的经销商。

公司：深圳银宸科技有限公司

地址：深圳市宝安区松岗街道碧头第一工业区朗碧路33号

电话：0755-23216420

网址：www.monsgeek.cn

产地：中国·深圳

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou First Industrial Zone, Bao'an District, Shenzhen, China



WARNING:
Water and Beverages can't be
poured into the Keyboard.




中国制造/Made in China

**注意
事项**

人为损坏不局限于键盘进水、高处坠落、过度用力拉扯线材等，键盘为电子产品
请按照电子产品保护方式爱惜使用。

Packing List



System Requirement

Windows®XP / Vista / 7 / 8 / 10 or higher version


Connectivity Method

Connect the keyboard to your computer by plugging in the USB cable into an available USB port to start using it.

Independent Indicator


Status	Indicator Position	LED Indicator
Caps	Caps key LED	Steady white
Lock Win	Left Win key LED	Steady white

M6 QMK HotKeys




FN+	1	=	F1	FN+	9	=	F9	FN+	P	=	PrtSc
	2		F2		0		F10		C		Computer
	3		F3		-		F11		M		Mute
	4		F4		=		F12		<		Volume down
	5		F5		ESC		~		>		Volume up
	6		F6		PGUP		Home		W		Swap W A S D with ↑ ↓ ← →
	7		F7		PGDN		End				
	8		F8		I		Insert				

M6 QMK System Commands (Windows)



Lock Windows Key	Restore Factory Settings	Windows ⇌ Mac OSX
FN + Left Win	FN + Backspace 3s	FN + O


M6 QMK System Commands (Mac)



F+	1	Decrease display brightness
	2	Increases display brightness
	3	Open mission control
	4	Activate siri
	7	Previous song
	8	Pause/Play
	9	Next song

FN+	0	Mute
	-	Volume down
	=	Volume up
	R_Alt	Right command
	L_Alt	Left command
	L_Win	Left option

M6 QMK Backlight Settings



FN+Del Switch between 18 different lighting effects

FN+ ; Slower Animation

FN+ ↑ Bright

FN+← Light Saturation -

FN+ ' Faster Animation

FN+ ↓ Dim

FN+→ Light Saturation +

MONSGEEK Warranty and Service Statement

1. MONSGEEK offers a One-Year warranty for customers in mainland China. For other regions, please contact your seller (MonsGeek distributor) for specific warranty details.
2. If the warranty period expires, customers are responsible for repair costs. MONSGEEK provides instructions for self-repair if preferred, but users assume full responsibility for any losses incurred during the process.
3. Disassembling the keyboard without manufacturer/seller's instruction will void the warranty immediately.
4. Return and warranty policies may vary across platforms and are subject to the specific distributor's terms at the time of purchase.

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Bao'an District, Shenzhen, China

Tel: 0755-23216420

Website: www.monsgeek.com

Origin: Shenzhen, China



WARNING:

Water and Beverages can't be poured into the Keyboard.



中国制造/Made in China

Precautions

Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.

