




Product Instruction



Parts List / Teileliste



⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.




This is a permanent label. Do not remove!


**Slides Must Be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.**

Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.


Les glissières doivent être séparées avant l'assemblage.
Après la séparation, mettez de côté jusqu'au moment de l'assemblage.




STEP 1: Extend Slide
Extender la diapositiva
Extendre la diapositive




STEP 2: Push Lever UP
Empujar hacia arriba
Lever le levier





STEP 3: Remove Runner
Quitar el corredor
Enlever le coureur





Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

<p>A x 76+5</p>  <p>Ø6x35mm</p>	<p>B x 52+4</p>  <p>Ø15 x 11 mm</p>	<p>C x 36+3</p>  <p>Ø8x30mm</p>	<p>Dx 2</p>  <p>Ø6x25mm</p>	<p>E x 6</p>  <p>Ø 6X20mm</p>
<p>F x 20</p>  <p>Ø 6X35mm</p>	<p>G x 4</p>  <p>Ø 3X12mm</p>	<p>H x 2</p>  <p>Ø 4X18mm</p>	<p>J x 4</p>  <p>Ø 3.5X14mm</p>	<p>K x 1</p>  <p>L= 500 mm</p>
<p>L x 1</p>  <p>L= 350 mm</p>	<p>M x 24+2</p>  <p>Ø 3X12mm</p>	<p>N x 76+5</p> 	<p>P x 12</p>  <p>Ø 3X12mm</p>	<p>Q x 2</p>  <p>Ø 3. 5X14 mm</p>
<p>R x 24+2</p>  <p>Ø15x9.5mm</p>	<p>S x 24+2</p>  <p>Ø6x30mm</p>	<p>T x 24+2</p> 		

1

Ax1







Ø6x35mm






Bx1








Ø15 x 11mm



2

Qx1  Ø 3.5x14mm	Ax3  Ø6x35mm	Bx3  Ø15 x 11 mm	Cx1  Ø8x30mm	
--	---	---	---	---



3

Ax6






Ø6x35mm

Cx7



Ø8x30mm



4

Bx4





Ø 15 x 11mm

Dx1



Ø 6 X 25mm





5

Bx2



Ø 15 x 11mm



6

Fx1



∅6X35mm

Kx1



L= 500mm

Lx1







L= 350mm

Mx6



∅3.5X14mm



7

Ax2



Ø6x35mm

Bx1








Ø15x11mm

Cx1




Ø8x30mm



8

Qx1






Ø3.5X12mm

Bx1



Ø15 x 11 mm



9

Ax2







Ø6x35mm

Bx2



Ø15x11mm



10

Ax6





Ø6x35mm

Cx7



Ø8x30mm



11

Bx4





Ø15x11mm






Dx1




Ø6X25mm





12


Bx2  Ø15x11mm	Ax3  Ø6x35mm	Cx2  Ø8x30mm		 
--	---	---	--	---








13

Fx1

Ø6X35mm

Kx1

L= 500mm

Lx1

L= 350mm

Mx6

Ø3.5X14mm







14

Ax3



Cx6






15

Bx6



Ø15x11mm





16

Fx18



Ø6X35mm





17

Sx8



Ø6x30mm



18

Ex6







Ø6x20mm

Ax14



Ø6x35mm



19

Bx14





∅ 15 x 11 mm

Cx12



∅8x30mm



20

Gx4



Gx12



Ø 3x12mm



Jx4



Jx16



Ø 3.5x14mm







21

Gx12



Ø3x12mm



22




Jx4



Jx8



Ø 3.5x14mm








23

Ax20



Ø6x35mm



24

Rx4







∅15x9.5mm.





Bx9





∅15x11 mm



25

Rx4  Ø15x9.5mm.	Bx3  Ø15x11mm	Hx1  Ø4x18mm	
--	--	---	---




26

Mx6







∅ 3x12 mm



Kx1



L= 500mm



27



28

Ax16









Ø6x35mm

Sx16



Ø6x30mm






29

Rx6



Ø 15 x 9.5mm






30

Rx10



Ø 15 x 9.5mm



31

Mx6




∅ 3.5X14mm

Hx1






∅ 4X18mm

Lx1



L= 350mm



32

Nx76








Px12



∅ 3X12mm

T x 6



T

T

T

T

WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

AFTER-SALES CONTACT

