LED Lighting Manual

1 Pull cable out of Saguaro arm(s). Split cable at connection point, place in grooves.

2 Tighten cap nut. Pin will pierce the cable.

3 Strip the light wire 1/4" and pass it through the pipe nut.

4 Place wire into the hole with core and tighten pipe nut.

5 Pull wire to check connection.