


senelux

INSTRUCTION MANUAL

FAN HEATER



Model: H5

ENGLISH

TABLE OF CONTENTS

(i) Attention	02
(ii) Product Overview	05
(iii) Function Description	06
(iv) Instructions	07
(v) Cleaning & Maintenance	08
(vi) FAQ	09
(vii) Warranty	09
(viii) Information	10

1. ATTENTION

WARNING: This heater is not equipped with a device to control the room temperature.

Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

WARNING: Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

WARNING: To reduce the risk of fire, keep textiles, curtains, or any other flammable material a minimum distance of 1 m from the air outlet. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

This instruction can be also downloaded from our company website. Children of less than 3 years should be kept away unless continuously supervised.

This heater is not suitable for young children.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

WARNING: In order to avoid overheating, do not cover the heater.

Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.

The heater must not be located immediately below a socket outlet.

Do not use this heater with a programmer, timer, separate remote-control system or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.

There is possible danger of installation close to curtains and other combustible materials.

CAUTION — Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.

Do not use this heater if it has been dropped.

Do not use if there are visible signs of damage to the heater.

Use this heater on a horizontal and stable surface, as applicable.

ENVIRONMENTAL PROTECTION



Discarded electric appliances are recyclable and should not be discarded in the domestic waste! Please actively support us in conserving resources and protecting the environment by returning this appliance to the collection centres.

Please read the user manual carefully before use and keep it for future reference.

Safety warning:

1. Please keep the product away from water or other liquids and flammable detergents to avoid electric shock and fire disaster.
2. Do not spray any flammable materials such as pesticides or perfume around the product.

Notice:

1. Please check whether the voltage for the product is consistent with the local power supply voltage before connecting the product to the power supply.
2. Please check whether the power cord and plug are worn or damaged before use. If the power cord is damaged, it must be replaced by electricians or full-time personnel to prevent hazards from happening.
3. Do not use the product in places with curtains or things easy to be sucked into the product, as well as places with obstacles and unstable conditions.
4. Do not use the product in places with high temperature, humidity, dust or volatilization of acid, alkali and oil.
5. Do not use the product for heating around bathtubs, sprinkler heads or swimming pools.
6. Do not place the product directly under the air conditioner to prevent condensate water dropping into the product.
7. Do not insert the fingers or other objects into the air inlet or outlet to prevent the product from physical damages or failures.
8. It is strictly forbidden to use the product in the environment with inflammable and explosive materials. The temperature of the usage environment shall not exceed 30°C, and the product shall be placed at least 7 m away from combustibles to prevent the fire disaster.
9. The fire protection cover of the fan heater is used to prevent direct contact with heating elements. Therefore, when the heater works, the fire protection cover must be installed in place. However, the cover does not provide comprehensive protection for children and disabled people.
10. Please make sure to place and use the product on a stable, flat and horizontal surface.
11. In the process of using, it is forbidden to touch the air outlet protection screen or cover the air outlet with the hands to avoid scalding.

12. When the heater is working, do not insert hands, or any other objects into the machine body.
13. Please make sure to unplug the product after use and before cleaning or performing other maintenance.
14. The product cannot be operated by people with physical disabilities, mental disturbances or lack of relevant experience and skills (including children), unless they are instructed or explained by the personnel responsible for safety.
15. Children shall be supervised to ensure that they will not play with the fan heater.


2. PRODUCT OVERVIEW

This heater is designed to be used on a desktop or fixed platform.

The overall design of the product is fashionable, and it is convenient for operation to equip the control switch on the back. A mechanical anti-tilting switch can guarantee the safe use. The automatic horizontal wide-angle heating can be enabled with one click. The overall structure design of the product is compact and exquisite, which is suitable for using in homes, offices and other similar places.



Name of Part



Specification

Model	H5
Dimensions	131.5 × 131.5 × 228.5mm
Weight	0.9kg
Rated input voltage	AC 220-240V
Rated power	600w

3. FUNCTION DESCRIPTION

Anti-tilting function

The fan heater will power-off automatically when it is tilted or picked up, and the machine will return to work after put back on a flat surface.

Wide-angle heating

The product can perform horizontal wide-angle heating by swinging its head from side to side.

Overheating protection

The fan heater will stop working and cut off the power automatically when the machine is overheating by abnormal environment and mis-handled. It will be normal used after the whole machine comes cool and anomalies are resolved.

Swing mode and non-swing mode

Swinging mode&non-swinging mode for optional.

4. INSTRUCTIONS

Warnings:

- To avoid excessive temperature, it is forbidden to cover the fan heater.
- Please do not block the air inlet or outlet, and keep a distance of more than 30cm to the wall or other obstacles when placing.
- When the fan heater is working, please do not stay near the air outlet for a long time to avoid any scalding.
- Please clean the filter regularly to avoid any overheating protection caused by air intake.

Before startup, please check the following items:

1. Whether the power cord is in good condition.
2. Whether the power switch on the back of the fan heater is ned off.
3. Whether the output voltage of the power socket is consistent with that of the fan heater.

Usage:

When using the fan heater for heating:

1. Place the fan heater on a flat surface.
2. Plug the power cord in the power socket.
3. Turn on the fan heater and the swing mode by flipping the power switch up (the indicator turns on).
4. Turn on the fan heater by flipping the power switch down (the indicator turns on); and turn off the fan heater by flipping the power switch to the middle.

Storage :

- Turn off the machine (the indicator off)
- Unplug the power cord plug from the power socket.

5. CLEANING & MAINTENANCE

Attention:

1. Please make sure to turn off, off and unplug the power plug of the fan heater before cleaning or maintenance, and do not take any action before the fan heater comes cool.
2. Do not immerse the fan heater in water or any liquid
3. Do not clean any parts of the fan heater with abrasive, corrosive or flammable detergents (such as bleach or alcohol).

Cleaning:

1. Turn off the heater, unplug the power plug and wait until the heater is cooled.
2. Clean the air inlet/outlet, and wipe the shell of the fan heater with neutral detergent and soft cotton cloth.

Attention: Do not drop any liquids into the fan heater when clean the air outlet.

Storage

1. Turn off the fan heater and unplug the power plug; arrange and strap the power cord neatly after the heater is cooled.
2. Clean the air inlet/outlet, and wipe the machine body with neutral detergent and soft cloth.
3. Put on the dust cover/bag and place the fan heater in a well-ventilated place without direct sunlight after the machine body is completely dried.
4. When the fan heater is spared for a long time, it shall be powered on for a few minutes from time to time to ensure a good performance.

6. FAQ

Question	Cause
No working	<ul style="list-style-type: none">• Is the plug plugged into the power socket? Is there a power cut?• Is the leakage switch or fuse cut off?• Is the power switch turned on or not?• Is the anti-tilting switch at the bottom of the fan heater invalid?
Excessive noise	<ul style="list-style-type: none">• Is the air inlet/outlet blocked by other Objects, or is the temperature of the air inlet/outlet too high to exceed the protection value of the temperature controller due to insufficient space of air inlet and outlet?• Is the anti-tilting switch at the bottom of the fan heater invalid?

Notice:

When the above FAQ can't help your problems and need maintenance, please contact the supplier or customer service centre, please do not disassemble the fan heater and make any maintenance by yourself..

8. WARRANTY

All Senelux products are covered from the date of original purchase by a standard 2-year warranty. To register your warranty, please visit www.senelux.co.uk

If in the unlikely event that your product has any manufacturing defect, please contact our customer service team at support@senelux.co.uk. Please quote your order number and any other relevant details regarding the issues you are facing. FAQs and help regarding all our products are available on our website.

Any unauthorised repair of this product invalidates your warranty.

9. INFORMATION

If you would like any further information regarding the use of this product or any of our products, please contact us via the details below.

Senelux Ltd
Unit 5-6
105 Boundary Street
Liverpool
L5 9YJ
United Kingdom
Email – info@senelux.co.uk
Website – www.senelux.co.uk



Be sure to tag us in your photos on social media using #seneluxathome to be featured



@senelux



@senelux



Thank you very much for using our products.
Please read the user manual carefully before use and keep it for future reference.