


Water temperature & diagnostic message display

LED lit when spa is heating



Controls light and pump

Controls water temperature



## Temperature Adjustment (80°F - 104°F)

The last measured water temperature is constantly displayed. To display the set temperature, press “Warm” or “Cool” once.



To change the set temperature, press a temperature button again before the display stops flashing. After three seconds, the display will stop flashing and begin to display the current spa temperature.

**Temperature range (80°F - 104°F/26.0°C - 40.0°C)** The last measured temperature is constantly displayed on the LCD.



## Pump

Press Jets button to turn pump on/off, and to shift between low and high speeds (if equipped). The low-speed will turn off after 4 hours. High-speed will turn off after 15 minutes. Low-speed may run automatically at times, during which it cannot be deactivated from the panel, but high-speed may be operated.



## Light

Press this key to turn the light on and off, an automatic timer will turn the light off after 4 hours of operation.