

Davit Strap Installation Guide

Forward Lifting Strap

Step 1) Pass metal rings through the forward most lifting handles and throw excess strap over the bow of the boat. Adjust the strap so that it is laying flat with no twists.



Step 2) Use the buckles to adjust strap length as needed and connect both looped rings to your davit system



Rear Lifting Strap

Step 3) Loop transom straps around lower transom bar and back through the buckles



Step 4) After adjusting the length, lock the buckles by looping strap back through the buckle and connect the ring to your davit lifting system

