# **Technical Instructions**

NIGHTSIDE

NIGHTSIDE • COM

#### **Technical Instructions**

#### 01 Getting Started

Positioning the Nightside Lamp Spotlight Feature

#### 02 Safety Considerations

Avoid Looking into the Spotlight

#### 03 Cleaning & Care

Cleaning the Lenses Washing the Fabric Shade Damage & Repair

#### 04 Technical Specifications

Power Supply LED Specifications

Your Nightside lamp comes fully assembled and ready to use. Simply connect the USB-C cable into the port on the back of the lamp, and then into the included wall plug. Use the dimmer knob to turn the lamp on and off, and to adjust the brightness.

## Positioning the Nightside Lamp

For convenience, position the lamp where you can use the spotlight feature with minimal adjustment each time. If next to a bed, position the lamp where you can easily reach the dimmer knob.

## Spotlight Feature

**Extending the spotlight:** To use the spotlight, push down on the rubber nub on the top of the lamp. The top reflector will extend to its full height, allowing you to tilt the reflector to the desired angle. To rotate the spotlight, simply rotate the lamp itself.

Retracting the spotlight: To retract the spotlight, angle the reflector downward, then push down on the rubber nub until the reflector retracts back into the lamp. You will hear a 'click' as the reflector locks into place.

## Avoid Looking into the Spotlight

Never look directly into the reflector while the spotlight is extended. The Nightside lamp uses an optical projection system that creates an extremely bright and focused light that could cause injury to eyes.

#### Cleaning the Lenses & Reflector

It is natural for dust and debris to gradually accumulate on the reflector, and on the inside of the lamp. Over time this dust can affect the brightness of the spotlight. To avoid scratching the lenses and reflector, only clean using the included microfiber cloth.

Follow these steps to clean the lenses:

- Remove the reflector assembly by first extending the reflector and then gently removing the rubber nub. Use a Phillips head screwdriver to remove the screw, then lift off the reflector assembly.
- Use the included mini screwdriver to carefully loosen the mini screw that secures the top plastic ring. Try to remove the ring without removing the screw, as it can easily become lost.
- Once the top plastic ring is removed, the shade can be easily lifted off.

#### Washing the Fabric Shade

Follow the steps listed in "Cleaning the Lenses" to remove the shade. Gently remove the fabric sleeve from the plastic shade. In order to avoid shrinkage, hand wash it in cold water only, then air dry. Replace the fabric sleeve so the seam is toward the back and aligns with the notch in the top plastic ring.

## Damage & Repair

If you have received a damaged or defective item, email a photo of the damage or defect along with your order number to support@nightside.com within 5 days following the delivery date of your order. Our customer service team will work with you to resolve the issue. We stand by the quality of our products and our goal is to ensure your satisfaction with every purchase.

You can always contact us for any return questions at support@nightside.com.

## **Power Supply**

Model: AQ15A-050A

Input: 100-240V~ 50-60Hz 0.5A

Output: 5V-3A

Manufacturer: PHIHONG USA CORP.

Made in China

## **LED Specification**

Model: XPLAWT-00-0000-000HU40E7

Color Temperature: 3000 K Luminous Flux: 340 lm

Color Rendering Index (CRI): 80

Power Rating: 3 W

Manufacturer: CREE LED

Remember, there is nothing in the dark that isn't there when the lights are on.